



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





## LCD Digital Storage Oscilloscope

# Operating Instructions

Model: 06201P, 06201KP, 06202KP

## 1. Accessories

- 1) Simple probe
- 2) AC/DC Power adapter (universal input voltage range)



## 2. Precautions

- 1) Do not apply voltage higher than the specified maximum input voltage to the instrument.
- 2) Do not attempt to directly measure wall power supply without a transformer.
- 3) Do not use power supply with voltage higher than 12V (DC or rms)

## 3. Panel Descriptions

Fig 1 shows the screen and various controls of the front panel. They are explained below.




Fig. 1

### Screen

- 1) Y position indicator – the left small triangle – shows 0V position
- 2) Trig level indicator – the small right triangle – shows trigger threshold voltage level
- 3) Window position indicator – indicates the displayed portion of sample memory.
- 4) “HOLD” is displayed when the oscilloscope is in HOLD state, which means capturing is halted until

HOLD state is released.

- 5) Scope setting indicators – their meanings are shown in Fig. 2.

#### Power Supply Connector

Located at bottom right of the panel. 9 – 12V DC power supply (minimum 300mA capacity) can be connected to this connector.

#### Signal Input Connector

Located at bottom left of the panel.




Fig. 2

#### Coupling Select Switch

This switch selects the coupling method to be used, i.e. AC coupling or DC coupling. When “Freq. M.” is selected, input is connected to frequency measurement circuit. The input to scope is internally disconnected.

#### Y Sensitivity Select Switches

There are two switches for Y sensitivity selection. The first one selects base value. The second selects multiplier. The two settings are combined to determine actual Y sensitivity. For example, when switch Y SEN. 1 is put at “0.1V” position and switch Y SEN 2 is placed at “X2” position, this means actual Y sensitivity is 0.2V per division.

#### SEC/DIV

Selects horizontal timebase. When this button is pressed, timebase display will be highlighted and timebase setting can be adjusted by pressing [ + ] and [ - ] buttons.

#### V.POS

Selects vertical position. When this button is pressed, the vertical position adjustment indicator will be highlighted and vertical position can be adjusted with [ + ] and [ - ] buttons.

#### H.POS

Selects horizontal position. When this button is pressed, horizontal position adjustment indicator will be highlighted and the displayed portion of capture buffer can be adjusted horizontally with [ + ] and [ - ] buttons.

#### MODE

Selects trig modes. When this button is pressed, trig mode adjustment indicator will be highlighted and trig mode can be selected with [ + ] and [ - ] buttons.

#### SLOPE

Selects trigger polarity. When this button is pressed, slope select indicator will be highlighted. Trigger slope will be toggled between rising and falling. Alternatively, trig slope can be changed with [ + ] and [ - ] buttons when the indicator is highlighted.

#### LEVEL

Selects trigger level. When this button is pressed, trig level adjustment indicator will be highlighted and trig level can be adjusted with [ + ] and [ - ] buttons. **Pressing this button again will select trig source between internal and external and enable/disable trig output.**

#### OK

Switches oscilloscope between HOLD and RUN states. When this button is held down for more than 3 seconds the instrument will switch between Oscilloscope Mode and Frequency Meter Mode.




Fig. 3

## 4. General Measurement

### Example 1 Observe the test signal (Practice for basic operations)

- 1) Connect power supply and probe.
- 2) Connect the red clip to the test signal terminal located at top-left corner of the panel, as shown in Fig. 3.
- 3) Set Y sensitivity switch 1 (middle switch) to 1V position.
- 4) Set coupling switch to DC position.
- 5) Press [ V.POS ] button, adjust 0V indicator to the second to last vertical scale as shown in Fig. 3.

- 6) Press [ SEC/DIV ] button, set timebase to 1ms.
- 7) Set Y sensitivity switch 2 (top switch) to X2 position. Waveform similar to that shown in Fig. 3 should be seen.
- 8) Change position of Y sensitivity switch 2 and you should see that the waveform amplitude changes accordingly.
- 9) Change timebase setting to 0.5ms, for instance, and you should see the signal waveform is widened accordingly. Experiment with other settings.
- 10) Now, select AC with the coupling switch and you should see that the waveform is shifted down to a position where the Y Pos. indicator is at its mid point. What you now see is a pure alternating signal.

### Example 2 Observe saw signal (Learn how to use trigger modes)

Fig. 4 is a simple saw signal generator. We can use the scope to observe its output. Build the circuit according to Fig. 4 and connect power and the scope.

- 1) Select DC coupling. Set Y sensitivity switch 1 to 1V position and Y sensitivity switch 2 to X2 position. Adjust the 0V point to the second to last vertical scale. Select 0.1ms timebase.
- 2) Connect probes as shown in Fig. 4. Power the circuit. You should see a waveform similar to that shown in Fig. 5.
- 3) Select AUTO trigger mode and change the trigger level. You should be able to observe that the waveform stabilizes itself when it intersects with trigger level (internal trig source should be selected here). Otherwise, it would jitter.
- 4) Change the trigger mode to NORM and vary the trigger level. Notice that the waveform only updates when there is an intersection with the trigger level (internal trig source should be selected here). Otherwise, it remains unchanged.
- 5) Press [ OK ] to put the oscilloscope into the HOLD state. "HOLD" is displayed. Now you can shift the waveform back and forth to view the rest of the signal that is not shown before. Pressing [ OK ] again will release the HOLD state and put oscilloscope back to capture state.




Fig. 4




Fig. 5

## 5. How to Use the Frequency Meter

Place the coupling switch in the "Freq. M." position and hold down [ OK ] for more than 3 seconds. This will enter Frequency Meter mode. Signal frequency will be displayed. Please note that peak signal amplitude should be greater than 3V as the instrument can only read TTL-level signals in this mode.

Holding button [ OK ] again will make it return to Oscilloscope Mode.

## 6. How to Use External Trig

- 1) **Connection of external trig signal** Usually external trig signal can be connected to pin 12 of J5 through a 10K resistor (this resistor is for protection and is necessary). For convenience, it can also be connected to the Test Signal terminal (protective resistor can be omitted). To use the Test Signal terminal, pin 12 of J5 must be shorted to pin 4 of J5. When J5's pin 12 and pin 4 are shorted, the Test Signal will be automatically disabled if external trig is selected. Note: remember to keep external trig signal within the allowed range of 0 - +15V.
- 2) **Select trig source** Press [ LEVEL ] to highlight the trig level indicator. Press [ LEVEL ] again to toggle trig source. To use the external trig make sure that external trig source is selected (letter "e" is displayed).
- 3) **Connect signal to be viewed to the scope input.**
- 4) **Adjust trig level to generate triggering.**

**Note:** The trig level for external trig is independent of that for internal trig and does not relate to any Y sensitivity settings. Its minimum level is close to 0V (when the triangle is at the bottom position) and the maximum level is close to +5V (when the triangle is at the top position). To effectively use the external trig, users should have some idea about the frequency and amplitude of the external trig signal to be used.

## 7. How to Use Trig Output

The oscilloscope reuses the Test Signal output terminal as trig output terminal. When trig output is enabled the Test Signal is automatically disabled.

- 1) **Enable trig output** Press [LEVEL] so that trig level indicator is highlighted. Press [LEVEL] repeatedly so as the letter 'o' is displayed at the right of trig mode indicator (This is the same spot where trig source indicator displays). **Please note that when trig output is enabled trig source will be automatically set to use internal.**
- 2) **Use the signal** The trig output is a signal with 5V in amplitude. Its normal (i.e. no trig happening) state is HIGH (+5V). When trig happens it jumps to LOW (0V). The negative going edge marks the moment when trig is generated. This LOW level will be kept to the beginning of next capture cycle.

## 8. How to Save Captures

- 1) Freeze the waveform you want to save by pressing [ OK ] (enter HOLD state).
- 2) Press [ VPOS ] and use [ + ] or [ - ] to select one of the 6 buffers.
- 3) Press [ OK ] to save the frozen waveform to the buffer selected.

## 9. How to Display Saved Captures

- 1) Enter HOLD state by pressing [ OK ].
- 2) Press [ SLOPE ] and use [ + ] or [ - ] to select the buffer to be displayed.
- 3) Press [ OK ] to display the waveform in the buffer selected.

## 10. How to Send Screen to PC as Bitmap File

The oscilloscope screen can be transferred to a PC as a bitmap file through a serial connection. The transfer protocol is Xmodem. Communication format is 38400bps, 8 data bits, 1 stop bit, no parity, no flow control. To do this, follow the steps below:

- 1) Connect the scope to PC via a serial level converter. (For how to make a serial connection and level converter, please refer to related documents and products at [www.jyotech.com](http://www.jyotech.com) website.)
- 2) Launch Windows HyperTerminal (or any other communication tool that can handle the Xmodem protocol) and prepare it for file reception. Please make sure that the filename of received file has ".bmp" extension. **(Suggestion: it is a good idea to put vertical scale info into filename for future reference.)**
- 3) Put scope into HOLD state and display an interesting portion of a capture on screen.
- 4) Press [ LEVEL ] then [ OK ]. Scope screen will be sent to PC as a bitmap file.

## 11. How to Use FFT

- 1) Enter FFT mode by holding [ MODE ] for 2 – 3 seconds under normal oscilloscope mode.
- 2) Use [ HPOS ] to select FFT size (256 or 512).
- 3) Use [ + ] or [ - ] to select sampling rate.
- 4) Push [ MODE ] to exit FFT mode and return back to oscilloscope mode.

## 12. Features & Specifications

Oscilloscope	Max Sample Rate	5M samples/second *
	Resolution	8 bits
	Sample Memory Depth	256 bytes
	Analog Bandwidth	1MHz
	Vertical Sensitivity	100mV/Div – 5V/Div
	Input Impedance	1MΩ
	Max Input Voltage	50Vpp
	Coupling	DC/AC
	Trigger Modes	Auto, Normal, and Single
	Trigger Polarity	Rising/Falling
	Trig position	1/4 of sample buffer (fixed)
	External Trig Input Range	0 – 15V
	Trig output amplitude	5V
	Trig output polarity	Falling edge
	Save up to 6 captures to EEPROM	
Display saved captures		

	Transfer screen as bitmap file to PC via serial port	
	Backlit LCD display	
	Power Supply Voltage	9 DC
	Power Supply Current	< 280mA
Frequency Meter	Frequency Range	5MHz
	Sensitivity	3Vpp
	Max Input Voltage	15Vpp
FFT	FFT Size	256 points and 512 points selectable
	FFT Sampling Rate	1Ksps – 2Msps
	Window	Hamming
Overall	Dimension	110mm X 65mm X 25mm
	Weight	70 grams (board & probe)

\* 5Msps only works in AUTO mode