



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





Operation Manual

Water-Water Cooler WW 3001



Version 1.0

Laird Technologies GmbH
Borsigstrasse 1
D-24568 Kaltenkirchen
www.lairdtech.com

Protection Notice

Dissemination as well as copying of this document, utilization or posting of its contents is not permitted unless formally granted. Violations entail claims for compensation. All copyrights, including rights due to patent grant or registration of a utility model or design, are reserved.

All product names used in this manual are trademarks of the corresponding manufacturers.

Technical modifications are subject to change.

Table of Contents

| | | |
|-------|---|---|
| 1 | About this Manual | 6 |
| 1.1 | Terms of Guarantee..... | 6 |
| 1.2 | Contact Information..... | 7 |
| 2 | Product Identification..... | 8 |
| 2.1 | Unit Specifications..... | 8 |
| 2.2 | Identification Plate | 8 |
| 3 | Safety Regulations..... | 9 |
| 3.1 | Hazard classes..... | 9 |
| 3.2 | Safety Symbols | 9 |
| 3.3 | Hints for Safe Operation | 10 |
| 3.3.1 | Prevent Hazards | 10 |
| 3.3.2 | Hints Regarding the Electrical Equipment..... | 11 |
| 3.3.3 | Environmental Issues..... | 11 |
| 3.3.4 | Exclusion Criteria | 11 |
| 3.3.5 | Protective Gear | Fehler! Textmarke nicht definiert. |
| 3.4 | Safety Equipment..... | 12 |
| 3.4.1 | Safety and Signalling Equipment included in the Unit..... | 12 |
| 3.4.2 | Guards..... | 13 |
| 3.4.3 | Caution Labels | 13 |
| 3.5 | In Case of Accidents..... | 14 |
| 4 | Product Description | 15 |
| 4.1 | Intended Use | 15 |
| 4.2 | Non-Conformity with the Intended Use..... | 15 |
| 4.3 | Unit Components..... | 16 |
| 4.3.1 | Functional principle | 16 |
| 4.4 | Specifications..... | 17 |
| 4.5 | Setting-up Requirements..... | 18 |
| 4.5.1 | Installation Location..... | 18 |
| 4.5.2 | Environmental Conditions | 18 |
| 4.5.3 | Infrastructure | 18 |
| 5 | Transport..... | 19 |

- 5.1 Safety Indications for Transportation and Setting-up 19
- 5.2 Transportation of the Unit 19
- 5.3 Unpacking and Disposal of Packaging Material 19

- 6 Initial Operation..... 20
 - 6.1 Safety Indications Related to Initial Operation 20
 - 6.2 Setting to Work 20
 - 6.2.1 Placement 20
 - 6.2.2 Cooling Circuit Connection and Filling..... 21
 - 6.2.3 Electrical Connections 22
 - 6.2.4 Carrying out Setting to Work..... 23
 - 6.3 Daily Start-up 24
 - 6.4 Setting to work after Storage 24

- 7 Controlling the Unit 25
 - 7.1 Safety Indications for Controlling the Unit 25
 - 7.2 Switching-on the Unit 25
 - 7.3 Switching-off the Unit 25
 - 7.4 Settings..... 26
 - 7.4.1 Flow Control Device 26
 - 7.4.2 By-pass Valve 26
 - 7.4.3 Temperature Controller 26

- 8 Disruptions..... 29
 - 8.1 Safety Instructions in the Event of Malfunction 29
 - 8.2 Disruption in Operation..... 29
 - 8.2.1 Trouble Shooting..... 30

- 9 Maintenance and Cleaning 31
 - 9.1 Maintenance Schedule..... 31
 - 9.2 Cleaning of Plate Heat Exchanger Fehler! Textmarke nicht definiert.
 - 9.3 Refilling of Coolant..... 31
 - 9.4 Cleaning of Strainer..... 32
 - 9.5 Cleaning of Unit Body 33

- 10 Repair 33
 - 10.1 Safety Instructions on Repair 33
 - 10.2 Repair Procedures..... 33

11 Dismounting, Disposal, Storage..... 34

 11.1 Temporary Placing out of Operation 34

 11.2 Re-packaging of the unit..... 35

 11.3 Storing the Unit..... 35

 11.4 Disposal 35

 11.5 Disposal of Operating Materials..... 35

 11.6 Return of the unit to LAIRD 35

12 Wear Parts and Spare Parts 36

 12.1 General Information 36

 12.2 Parts Overview..... 37

Addendum 38

 Flow scheme 38

 Wiring diagram..... 39

History of Changes

| Date | Index | Reason for Change | Name | Page |
|-------------|-------|-------------------|-----------|------|
| 24-Apr-2014 | 1.0 | | Edom/Gimm | |

1 About this Manual

This document is the English translation of the original Operation Manual in German language for the Water-Water Cooler WW 3001 (called unit in the following). It is based on German safety regulations. In your country other regulations may apply.

This Operational Manual addresses the needs of the user of the unit. Its intention is to allow the safe operation of the unit. Thus, it should be read carefully and be kept in a space accessible for the users of the unit at any time.

All chapters of this Operation Manual can be read independently and thus can be used for look-up purposes.

1.1 Terms of Guarantee

General sale and delivery terms of LAIRD apply. The buyer accepts these terms, at the latest when signing the contract of purchase.

The particular terms of guarantee and duration of guarantee of the device in question can be taken from the contract documents as well as from the order confirmation.

Warranty claims and liability are excluded in case of one of the following situations:

- Use of the unit in an unintended way
- Inaccurate installation, putting into service, operation, repair or maintenance of the product by people that are not fully authorized
- Use of the product despite of defect, wrongly implemented or non-functional safety devices or protective gear
- Unauthorized or forbidden modifications by the user concerning the electrical equipment of the unit
- Unauthorized or forbidden modifications by the user concerning the mechanical structure of the unit
- Unauthorized or forbidden modifications by the user concerning the operating parameters
- Use of unauthorized tools
- Use of unauthorized operating supplies
- Exceedance of mandatory maintenance intervals
- Cases of disaster caused by foreign matter influence or act of nature beyond control

PLEASE NOTE

Any form of unintended use of the unit and any structural change caused by the user without prior authorization in written form by LAIRD will lead to the termination of warranty as well the termination of the declaration of conformation and will free LAIRD from product liability. This concern includes safety devices as well.

In case of authorized changes or when adding optional equipment it is the sole responsibility of the customer to assure the accurate implementation of the required safety devices.

1.2 Contact Information

If you have questions with respect to this unit please use the contact information given below. Always communicate the following:

- Your name and address
- Name of contact at your address
- Product data as on identification plate: Type of unit, serial number and year of manufacture

Company contact:

Mail: Laird Technologies GmbH
Borsigstrasse 1
D-24568 Kaltenkirchen
Deutschland

Internet: <http://www.lairdtech.com>

E-Mail: info-lcs@lairdtech.com

Phone: +49 (0)4191 9993-0

Fax: +49 (0)4191 9993-33

2 Product Identification

2.1 Unit Specifications

| | |
|-----------------|-------------------------|
| Manufacturer | Laird Technologies GmbH |
| Type of product | Water-water cooler |
| Type of unit | WW 3001 |
| Article number | 1104.00 |

Table 1: Unit specifications

2.2 Identification Plate

The identification plate is attached to the front side of the unit (see picture 1).




Fig. 1: Position of identification plate

| | |
|---|----------------------|
| 1 | Identification plate |
|---|----------------------|



Fig. 2: Unit specific identification plate

| | | | |
|---|--------------------------|---|---------------------|
| 1 | Unit type | 2 | Date of manufacture |
| 3 | Article number | 4 | Serial number |
| 5 | Electrical specification | | |

3 Safety Regulations

3.1 Hazard classes

In this document safety instructions are using standardized representation and symbols. Depending on the probability of their incidence and the severeness of consequences three hazard classes are used.



DANGER

Reference to direct danger for humans.
Inobservance will lead to irreversible injuries or exitus.



CAUTION

Reference to noticeable danger for humans or possible damage to property.
Inobservance may lead to reversible injuries or to damage to property.

3.2 Safety Symbols

In this Operation Manual concrete safety instructions are given in order to point out unpreventable residual risks when operating the device. These risks include danger for

- Human beings
- The device and other equipment
- The environment

The safety symbols used in this manual are indicated below. The main reason for their use is to point the reader to the safety instruction given in the text field beside.



| Symbol | Meaning |
|---|--|
|  | Warning with respect to general danger or damage to property |
|  | Warning with respect to electrical hazard |

Table 2: Warning signs


| Symbol | Meaning |
|---|---|
|  | This symbol indicates the requirement of disconnecting from mains |

Table 3: Signs giving orders

3.3 Hints for Safe Operation

PLEASE NOTE

Conduct inspections on a regular time base.

This will ensure that the appropriate measures will actually be carried out.

The unit is operational safe. It was built according to the state-of-the-art.

Despite this the unit could cause hazards if it

- is used in a way it was not intended for
- is used improperly
- is operated under unsuitable conditions

3.3.1 Prevent Hazards

Hazards can be prevented by safety-conscious and anticipatory behaviour of staff.

Everybody working with the unit should keep the following in mind:

- Make this Operation Manual available for everybody at the operational location of the unit in a complete and perfectly readable state!
- Use the unit exclusively for what it was intended!
- The unit must be operational and errorfree. Check the condition of the unit before working with it and within a regular time frame!
- Make sure that nobody can injure himself by any part of the unit!
- Any disruption or recognizable change concerning the unit should be reported to the responsible person!
- Stick to the accident prevention regulations as well as any regional regulations!

3.3.2 Hints Regarding the Electrical Equipment



DANGER

Danger to life through electrical shock when working on the electrical equipment of the unit!

- Switch-off the unit before starting your work!
- Disconnect the unit from mains by pulling the mains plug!
- Verify that the installation is dead (volt-free)!
- Carry out earthing or short-circuiting!



When working on electrical installations the following principles should be observed:

- Works on the electrical installations may only be accomplished by qualified electrical staff.
- When connecting electrical equipment to mains regional regulations have to be observed. Be aware of the wiring diagram information.
- The unit is powered by electricity. Electrical shock hazard exists, if the electrical installations are defective or the insulation fails during operation.
- When switched-off the unit is not disconnected from mains. This is only the case when the mains plug is pulled.
- Any changes regarding the control elements of the unit can have an influence on the safe operation. All intended changes must be authorized by the manufacturer.
- After implementation of any change the operativeness of the safeguards must be verified.
- No unauthorized changes on the unit are allowed. All intended changes must be authorized by the manufacturer.

3.3.3 Environmental Issues

Environmentally conscious and anticipatory behaviour of staff avoids environmentally hazardous impacts.

The following principles apply for environmentally conscious behaviour:

- Environmentally hazardous substances must not get into the ground or in the drains. They should be kept in appropriate containers.
- Environmentally hazardous substances must be fed to utilization or disposal according to regional regulations.

When dealing with operating supplies always keep aware of the safety data sheet of the corresponding manufacturer.

3.3.4 Exclusion Criteria

PLEASE NOTE

Operating Staff

Staff is only allowed to operate the unit. They are neither allowed to open the unit chassis, remove parts, connect or disconnect power or coolant fluids nor to do maintenance.

3.4 Safety Equipment

PLEASE NOTE

The safety equipment listed below must be integrated in the local control environment by the customer, unless otherwise noted. These works must be carried out solely by trained experts. All required information can be taken from the wiring diagram shown in the addendum.

Safety equipment must not be modified, removed or taken out of operation. All parts of the safety equipment must be accessible at all times.

Familiarize yourself with all safety equipment. This can prevent or minimize bodily harm and/or unit failure in case of disaster.

3.4.1 Safety and Signalling Equipment included in the Unit

The unit is equipped with safety devices at critical spots (see Fig. 2).

- Water throughput is controlled by a flow switch that must be integrated in the potential-free safety circuit of the device to be cooled.
- The maximum temperature of the cooling circuit is controlled by a fixed thermostat with an opener contact that must be integrated into the safety circuit of the device to be cooled.
- The maximum pump pressure is limited by a safety valve that by-passes the liquid stream when the pressure pre-set is exceeded.
- The level of the cooling fluid container can be monitored against the state "empty"




Fig. 3: Safety devices

| | | | |
|---|--------------|---|--------------------------------|
| 1 | Safety valve | 2 | Thermostat |
| 3 | Flow switch | 4 | Cooling container level sensor |

3.4.2 Guards

Direct access to hazardous parts or areas of the unit is restricted by the unit cover. The cover may only be removed for the purpose of maintenance or repair works and shall be replaced prior to taking the unit back into operation. The unit cover is fixed by four M5 screws.

The electrical terminal area is accessible after removing the back cover. For opening/closing of the fasteners an AF8 wrench is required.




Fig. 4: Guards

| | | | |
|---|----------------------|---|--|
| 1 | Unit body | 2 | Access bushing for electric terminal block |
| 3 | Removable back cover | | |

3.4.3 Caution Labels

Danger spots on the unit are indicated in correspondence to German safety regulation BGV A8 "Sicherheits- und Gesundheitsschutzkennzeichnung am Arbeitsplatz".

Caution labels on the unit must be easily readable at all times. Illegible caution labels must be exchanged immediately.



Fig. 5: Caution labels on the unit

| | |
|---|--|
| 1 | Hint on electrical hazardous area at the back of the unit body |
|---|--|

3.5 In Case of Accidents

Should you or an other person be injured when working with the unit:

- Stay calm
- Render first aid
- Call the company first-aider without exception

4 Product Description

4.1 Intended Use

The water-water cooler WW 3001 is used for the cooling of a water circuit. As a coolant pure water or a water/antifreeze mixture may be used. The coolant circulates between the cooling unit and the device to be cooled. The maximum cooling capacity depends on the difference between the temperature of the water supply intake and the temperature of the coolant forward flow. Its value is 3000 Watts for a temperature difference of 12 K.

The unit is exclusively intended for use in industrial and commercial environments. The intended use also includes the observance and following of all hints given in this Operation Manual.

4.2 Non-Conformity with the Intended Use

Operation of the unit under improper operational conditions is not allowed, as otherwise the safe operation can not be assured.

When using the unit in a way not compliant with the intended use, hazardous situations may occur.

Operation of the unit is not allowed under the following conditions:

- The unit is used for a purpose other than the one it is intended for.
- The unit or parts of it are damaged, the electrical installation is not correct or the insulation is broken.
- Protective or safety equipment is not functional or defect, improperly installed or missing.
- The unit is not working properly.
- The unit has been modified in any way.
- Controlling devices were modified in a way that is not permitted.
- Operational parameters were changed in a way that is not permitted.
- Operation in areas exposed to explosion hazards
- Operation with cooling media not according to specification
- Use of unauthorized tools
- Exceedance of the compulsory maintenance intervals

PLEASE NOTE

The manufacturer is not liable for damage occurring when using the unit in a way it was not intended for. When using the unit in a way it was not intended for, the manufacturer's warranty given by LAIRD will expire.

4.3 Unit Components

The unit consists of the following sub-assemblies .Additional information can be retrieved from the flow scheme shown in the addendum.




Fig. 6: Main components

| | | | |
|---|--|---|-----------------|
| 1 | Coolant container and plate heat exchanger | 2 | Cooling circuit |
| 3 | Body | | |

4.3.1 Functional principle

In the cooling circuit the coolant is driven by the pump to the device that is to be cooled and back via the return flow. The heat is transferred to the water supply intake through a plate heat exchanger following the principle of opposing flows. The heat is then expelled from the unit through the water supply outlet.

The water temperature is controlled by an electric thermostat, whereas water throughput is controlled by a flow control device. Both indications are made potential-free and must be integrated into the safety circuit of the device to be cooled.

4.4 Specifications

Dimensions and weight

| | |
|-------------------|-----------------|
| Length: | 450 mm |
| Width: | 270 mm |
| Height: | 400 mm |
| Weight: | 24.0 kg (empty) |
| Coolant contents: | 8.5 Liters |

Table 4: *Dimensions and weight*

Performance data

| | |
|-------------------|------------------------------------|
| Cooling capacity: | 3.0 kW at 5.0 l/min, water at 22°C |
| Throughput: | > 5.4 lpm @ 4.0 bars |
| Mains voltage: | 230 VAC, 50/60 Hz |
| Current draw: | 1.8 A |
| Operating noise: | ≤ 47 dB (50 Hz) @ 1 m distance |

Table 5: *Performance data*

Environmental conditions

| | |
|------------------------|-------------------------|
| Operating temperature: | +0°C ... +40°C |
| Storage temperature: | -20°C ... +70°C (empty) |
| Relative humidity: | 10% ... 90% |

Table 6: *Environmental conditions*

Settings

| | |
|--------------------------|-------------------|
| Maximum pressure | 6.0 bar ± 0.2 bar |
| Flow switch off | 4.0 lpm |
| Water supply temperature | 25°C |
| Maximum temperature | 35°C ± 3°C |

Table 7: *Settings*

4.5 Setting-up Requirements

4.5.1 Installation Location

- The location must be even.
- When choosing the installation location the following must be kept in mind:
 - the air flow of the cooling air for the motor must not be restricted
 - forward and back flow connections must be easily accessible
 - all tubes must be installed without sharp bends

4.5.2 Environmental Conditions

 **CAUTION**

Risk of damage due to unsuitable environmental conditions!

Damage to the unit and corrosion damage may result and are not covered by manufacturer's liability.

- The unit is only authorized for use in indoor environments.
- The unit must not be stored or operated in aggressive, humid environments.
- The unit must not be stored or operated outdoor.

Pay attention to the environmental conditions as given in the specifications on page 17.

4.5.3 Infrastructure

The following infrastructure is required for connecting the unit:

| Parameter | Rated value |
|-------------------|------------------|
| Operating voltage | 230 VAC, 50/60Hz |

Table 8: Required infrastructure

5 Transport

5.1 Safety Indications for Transportation and Setting-up

CAUTION

Risk of injury by lifting the unit!

The weight of the unit is **almost 24 kg (empty)**.

- Do not lift the unit manually!
- Always use proper auxiliary means such as a forklift or a jack lift!

CAUTION

Risk of damage by improper transportation!

The attachments of different components inside the unit **are not secured with transportation locks**. In case of improper transportation these can be damaged without repair and would need to be replaced.

- Transport the unit in upright position!
- Do not tilt the unit or expose it to impacts!

5.2 Transportation of the Unit

The unit is delivered packaged and shrunk in foil on a transportable pallet. Leave the unit on the pallet until bringing it into service. Use a forklift or jack lift for transportation to the installation location.

5.3 Unpacking and Disposal of Packaging Material

Remove the foil before setting up the unit. Inspect the unit with regard to:

- Damage caused by transportation
- Completeness of delivery

Lift the unit with a forklift or jack lift off the transportable pallet. Dispose of the packaging material in accordance with regional regulations.

PLEASE NOTE

LAIRD advises to keep the transportable pallet and packaging material for later transportation of the unit.

6 Initial Operation

6.1 Safety Indications Related to Initial Operation

CAUTION

Danger of malfunction caused by faulty connections during initial operation!

Before switching on the unit make sure that:

- All safety equipment of the unit is implemented and functional.
- All connections were properly made.

Please follow the rules in chapter Safety Regulations on page 9.

6.2 Setting to Work

6.2.1 Placement




Fig. 7: Minimum clearance for air entrance and air exit

- 1) Move the unit to its installation location as mentioned in chapter 5.2.
- 2) Place the unit in a way that air entrance and air exit are not obstructed. **Wall clearance on the left side (facing the unit) must not be less than 0,5 m, otherwise operating capacity may be restricted**

PLEASE NOTE

In case of storage of the unit at temperatures lower than 5°C or higher than 40°C for longer periods please wait 3 hours prior to initial operation to allow for temperature adjustment.

6.2.2 Cooling Circuit Connection and Filling



CAUTION

Risk of damage by using improper cooling hoses!

This may lead to damage to persons, damage to the unit or corrosion damage!

- When choosing cooling hoses pay attention to sufficient burst strength and compatibility with coolant!
- Only use cooling hoses without any signs of damage!
- In case pure water is being used as coolant, ensure that non-transparent hoses are used to prevent the growth of algae in the water. Otherwise appropriate additives have to be used.

The cooling hoses with an internal diameter of 9 mm are connected to the unit by means of hose nipples. Water outlet and water inlet are indicated with respective symbols.



Fig. 8: Labelling of water inlet and water outlet

- 1) Connect a suitable hose to the hose nipples for cooling water inlet and cooling water outlet and secure it with a clamp, respectively.
- 2) Connect a suitable hose to the hose nipples for coolant inlet and coolant outlet and secure it with a clamp, respectively.
- 3) Connect the hoses to the corresponding nipples of the device to be cooled.

PLEASE NOTE

When connecting the cooling hoses pay attention to flow direction. Follow the documentation released by the manufacturer of the device to be cooled.




Fig. 9: Cap of coolant container

| | |
|---|--------------------------------------|
| 1 | Cap (version for transport is shown) |
|---|--------------------------------------|

- 4) Open the coolant container by removing the cap.
- 5) Fill the coolant container with about 8.5 liters of water or the water/antifreeze mixture.
- 6) Close the coolant container by fitting the cap. Make sure to use the red cap for operation mode.

PLEASE NOTE

LAIRD recommends GLYCOSHELL as antifreeze in the following concentration (based on 8.5 l water). Ensure to blend the antifreeze with the water prior to filling it into the coolant tank. Thus it is ensured that the maximum contents are not exceeded.

| Ambient temperature [°C] | +15 | +10 | +5 | 0 | -5 | -10 | -15 | -20 | -25 | -30 |
|--------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| GLYCOSHELL [Liter] | 0,0 | 0,1 | 0,6 | 1,1 | 1,6 | 2,1 | 2,6 | 3,1 | 3,6 | 4,1 |

Table 9: Amount of antifreeze depending on ambient temperature (based on 8.5 l water)

6.2.3 Electrical Connections



DANGER

Danger to life through electrical shock when working on the electrical equipment of the unit!



- Switch off the unit before starting your work!
- Disconnect the unit from mains by pulling the mains plug!
- Verify that the installation is dead (voltage-free)!
- Carry out earthing or short-circuiting!



CAUTION

Risk of damage through improper connections!

Improper integration of the unit into the safety circuit of the device to be cooled will lead to the inoperativeness of the safety equipment listed in chapter 3.4.1 on page 12.

- All connections required must be incorporated according to the wiring diagram shown in the addendum.
- Ensure yourself that all connected safety equipment is properly functioning.
- All works should be carried out by expert.

PLEASE NOTE

The unit is delivered without a mains cable. The electrical connection as well as the integration into the safety circuit of the device to be cooled are the customer's responsibility and must be accomplished by expert staff.

Information required can be taken from the specifications listed on page 17 and the wiring diagram in the addendum.




Fig. 10: Electrical terminal behind unit body

| | | | |
|---|--------------------------|---|----------------|
| 1 | Electric terminal stripe | 2 | Cable bushings |
|---|--------------------------|---|----------------|

- 1) Remove the back pannel after unscrewing the 4 screws.
- 2) Feed the mains cable through one of the cable bushings and make the connection to the terminal. Then do the same with the wires for the implementation of the safety circuit.
- 3) Remount the back panel.

After installation of the mains cable connect the unit to mains by inserting the mains plug or making a mains connection as required by the particular periphery.

6.2.4 Carrying out Setting to Work

After connecting the cooling circuit, filling the coolant container and finishing the electrical connections follow the steps below for the setting to work for the unit:

- 1) Remove the cap on the coolant container.
- 2) Switch on the unit and let it run for about 10 minutes in order to fill and vent the cooling circuit. Continously check the filling level during this procedure.



CAUTION

Lack of coolant may destroy the pump!

When looking into the filling plug of the coolant container the filling level must always be at least at **2/3 of the tank height**.



- 3) If required, refill coolant.
- 4) Check the compliance with the operational parameters as specified on page 17.
- 5) Remount cap on coolant container.
- 6) Switch off the unit.

The unit is ready for operation.

6.3 Daily Start-up

Switch on the unit about 1 minute prior to using the device to be cooled.

6.4 Setting to work after Storage

Setting-to-work after storage will have to follow the same procedures as required for initial operation (see chapter 6.2).

7 Controlling the Unit

The unit is controlled using the controls of the equipment that is to be cooled.

All alarm and error signalling is only indicated on the control panel of the equipment that is to be cooled.

7.1 Safety Indications for Controlling the Unit

CAUTION



Lack of coolant may destroy the pump!

- Operate the unit only when the filling of coolant container is sufficient!
- Check the filling level of the coolant container regularly!

Also pay attention to the hints given in the chapter Safety indications from page 9 on.

7.2 Switching-on the Unit

➤ The unit is ready for switching-on.

- 1) Switch on the unit about 1 minute prior to operation of the device to be cooled using the appropriate control of that device.
- 2) Check the compliance with the operational data according to the specifications listed on page 17.

The unit is running.

7.3 Switching-off the Unit

➤ Cooling operation has come to an end

- 1) Switch off the unit using the control of the device to be cooled.
- 2) Close all valves that may exist in the extension of the hoses running to and from the unit.

The unit is out of operation.