



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts,Customers Priority,Honest Operation,and Considerate Service",our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





Software and Support Activation

Quick Start Guide



WELCOME

Welcome to the Freescale Software Development tools and support activation guide. This document guides you through the registration and activation of your Freescale Software and Support contracts.

Section 1: How to register your software product and access your software

Section 2: How to download and license your products

Section 3: Describes the different registration codes and product options

Section 4: How to register your support entitlements

Section 5: Managing Accounts: Shared and personal accounts

NOTE: For additional information on any of the topics in this quick start, refer to the CodeWarrior Suite FAQs at www.freescale.com/CodeWarriorSuitesFAQ

Step-by-Step Activation Instructions

1 Register your Software!

You may have acquired your software through the Freescale web site or an Authorized Freescale Distributor. As a result, you have received the registration code labeled on your physical product delivery, or through your order confirmation e-mail.

This registration code is needed to register your software or support contract.




Figure 1: Freescale SW case

Step-by-Step Activation Instructions (cont.)

Below is an example of the digital download confirmation e-mail:




Figure 2: Order received e-mail.

If you received this email, click on “Register Now”.

Note: If you receive a confirmation email without a registration code, your order may still be in process, please wait until Freescale completes your purchase, and once fulfilled you will receive your Registration Number.

You can also get to the software registration code by logging into **www.freescale.com**, and navigating to “View My Orders” from your “My Freescale” homepage




Figure 3: Buy Confirmation page

Or go to **www.freescale.com/activation**. Please input your license registration code where prompted.



Figure 4: www.freescale.com/activation

3-step-3-step Activation Instructions (cont.)

Next, select an account to host your software:

- Select Personal Account to register the product to your personal freescale.com account
- Add or select an existing shared account to share the product with others.

Note: When creating a new shared account, all members you invite will have to be required on freescale.com prior to receiving access to the product.




Figure 5: Account selection

After selecting the account the confirmation page will appear.



Figure 6: Registration Confirmation Screen

By clicking on “View Products”, the product information page will be displayed, from this page you are able to view and access the list of products available to be licensed and or downloaded.




Figure 7: Product Information with a single product

2-step-2-step Activation Instructions (cont.)

2 How to download and license your products

You can access your Software products by logging in to Freescale.com > Software Licensing and Support. You can also get to the products from “View My Orders” from your “My Freescale” homepage.

All activated products will be available in the product list

Software & Support

- Product List
- Product Search
- Order History
- Recent Product Releases
- Recent Updates
- Licensing
 - License List
- FAQ
 - Download Help
 - Table of Contents
 - FAQs

Product Information

Freescale Software

Your choice contains a suite of products. Please select one of the product lines below:

- CodeWarrior Development Suite - Basic
- CodeWarrior Development Suite - Professional
- MCX Add-on Software

Figure 8: Product information with more than one SW.

To activate one of your software products

Click the title of the product that you wish to access, the product details show a list of products you are entitled to license.

freescale

Products Applications Software & Tools Training & Communities Sample & Dev About

Home > Software & Support > CodeWarrior Development Suite - Professional > CodeWarrior for MCU Professional Edition (Windows - Eclipse)

Product Download

CodeWarrior for MCU Professional Edition (Windows - Eclipse)

File System Files Select Download Help

Licensing

License Code

FAQ

Download Help
Table of Contents
FAQs

The software you are about to download is subject to export control laws and regulations. By downloading this software, you agree that you will not re-export, redistribute, or otherwise make this software available to any unauthorized third party, directly or indirectly, and any software downloaded from this website is not prohibited distribution, end user, or air gap.

To receive necessary installation of license code, update, and obtain the software module to install in the control center. Please ensure you have the CodeWarrior installation or go to date. Contact Support.

Complete updates and MCX Plug-in updates require installed software license update license code.

Product or Export control for new license can be added with Professional Export Update. Professional Export Update requires the device specific license pack has already been installed. However, the installation order should be following (if not in this order):

- MCU 101 Update (License Update)
- MCU 101 Compiler Update
- MCU 101 Processor Export Update
- MCU 101 AT91MC Plug-in Update
- Device-specific license pack
- Device-specific Processor Update

For installation information for specific device packs, update or patches, please mail the URL back to us.

View All Files

File Name	File Size	File Type
license	402.4 KB	CodeWarrior for Microcontrollers (Windows - Eclipse) Install - ZIP file
Service Pack	1.1 MB	CodeWarrior for MCUs (Windows - Eclipse) Service Pack v1.0 ZIP
Service Pack	280.9 KB	CodeWarrior for MCUs (Windows - Eclipse) Service Pack v1.0 ZIP
Service Pack	4.0 MB	CodeWarrior v10.1.0.0 (Windows - Eclipse) Service Pack v1.0 ZIP
Service Pack	1.1 MB	CodeWarrior for MCUs (Windows - Eclipse) Service Pack v1.0 ZIP

Figure 9: Product Download

3-step-3-step Activation Instructions (cont.)

On the product download site, you will have access to files, licenses, and also any notes for this product that you may need to add.

Files tab: you will have access to all files related to this product (Installers, Service Packs, Updates and Patches)

Generation of a license file:

1. To generate the license that will activate your product, please click on the License Keys tab located below the product title
2. The License Information page will appear and will display the license file for your product




Figure 10: License information

3. Click on the Generate button located after the Item Description box.
4. Enter your host ID information.
 - A. If you are using a Node-Lock License you will be required to enter your Disk Serial Number, Ethernet MAC address or Dongle FlexID



You can get your host details from your system running CMD with the commands “vol” for Disk Serial num (8 digits)



Step-by-Step Activation Instructions (cont.)

Or “ipconfig /all” for Ethernet MAC.

```
Administrator: C:\windows\system32\cmd.exe
Microsoft Windows [Version 4.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.

C:\Users\832212>ipconfig /all
```

B. For floating license enter your server Disk Serial Num or Ethernet address plus the name or IP address.

Note: Redundant server configuration is optional. If you need to have triple redundancy, please complete the host information for servers 2 and 3. If you have a single server please discard this option and leave the fields blank.

5. Click on Generate.

6. The View Licenses page appears with the file to activate your product.

License Application to Product:	Number of Licenses Available	Number of Licenses to Generate
120000: 00000000 MPCo Co-Processor for MPCo Professional Edition (Windows - Edges)	1	1*

* May Not Be Deleted

Select an existing License Host from the list or enter a new one

Existing License Hosts

Server Host ID:

Server Name (IP Address):

Port:

Host Description:

For high availability environments, license files can run in a redundant 3 - license server cluster. If you want to use this option, enter both redundant server hosts as well as the primary server above, including port numbers. Redundant license servers are not required. (Optional)

Red Server Host ID:

Red Server Name (IP Address):

Port:

Host Description:

Red Server Host ID:

Red Server Name (IP Address):

Port:

Host Description:

Click on Save All to save the license files into the appropriate location within your specific software installation. Download the file and locate this license.dat file per the examples below:

3-step-3-step Activation Instructions (cont.)

Classic-CodeWarrior (versions 9.x and lower):

Path = by default is = Program Files\
Freescale\ CodeWarrior for [Platform]
[Version]

Example

C:\Program Files\Freescale\CodeWarrior
for ColdFire v7.2

Eclipse-based CodeWarrior (versions 10.0 and higher):

Drive\Freescale\ CW [Platform][Version\
[Platform]

Example

C:\Program Files\Freescale\CW MCU
v10.0\MCU

3 Entitlements and products options

There are different products you may register on your Freescale Software and Support portal.

You can register softwares, Support contracts, Standalone Processor Expert products, Automotive software, enablement and evaluation Softwares.

Here are some examples of these entitlements:

CodeWarrior Software—CodeWarrior Software contains several CodeWarrior products unique to specific Freescale architectures. For more information, please select the link below:

www.freescale.com/webapp/sps/site/overview.jsp?code=CW_SUITES&tid=CWH

Examples:

DLA-STANDARD-FL_DDAXXX4548
CWA-PRO-NL_DDAWCZXXX

3-step-by-3-step Activation Instructions (cont.)

Node-Locked vs. Floating Licenses

CodeWarrior Development Suites can be purchased with either a node-locked or floating license model. If you chose the node-locked option, you can either lock your suite to a single computer or to a USB dongle. If you chose the floating license option, you will lock your suite to a license server.

Note: You will find more details about these license options at www.freescale.com/licensingFAQ

All CodeWarrior Development Suites come with one year of technical support and maintenance, the year of technical support begins on registration date of the suite.

For the CodeWarrior Perpetual Suite, the first year of support and maintenance is included in the price of your initial purchase and must be renewed yearly to continue to receive all the benefits listed below.

For the CodeWarrior Annual Subscription Suite, support and maintenance is always bundled with the purchase of the CodeWarrior Development Suite, and the subscription itself must be renewed annually.

With a current Technical Support Contract you receive:

- Access to Technical Support via email, web and phone
- Ability to query outstanding service requests submitted by the customer
- On-line support
- Free product version upgrades within the development suite as they become available
- Access to all CodeWarrior products within the development suite
- Service Packs in support of new silicon releases
- Software patches and updates

Step-by-Step Activation Instructions (cont.)

Freescale Support Contracts are offered for **MQX™ RTOS** support, **QorIQ Linux** software development kit (SDK), **Layerscape Application Solutions Kit (ASK)** and **Reference Design System Support**. These prioritized support options will streamline your development efforts, whether you are just getting started or getting deep into your development cycle. Check more information on Section 4.


Examples:

DL-MQXLVL2-P_KBPIEYXXXX
 SDK-SUPPORT_OUGQWXXXX

Standalone Products

Processor Expert Software & components is a development system to create, configure, optimize, migrate, and deliver software components that generate source code for Freescale silicon. These are available as licensable add-ons, as well as integrated within Freescale software products such as CodeWarrior.

For the Processor Expert Component add-ons, you can activate these thru a license key. Combine the features of your processor expert with your CodeWarrior license by copying and pasting the license increments to the CodeWarrior license file



Example

DLP-MCF-TERM-CX_TQFASFXXX



Step-by-Step Activation Instructions (cont.)

4 Register your Support Contract

Accelerate your design success with prioritized support contracts. You can register these contracts just as you do with Software products.


1. Go to www.freescale.com/activation to start the registration process.
2. Enter valid support contract registration code

3. Select an account to assign the Software Support contract.

4. Complete the online form to submit your project details to the support team for final set up.

Note: In order to complete the form, you are required to accept the Agreements Terms. If you do not agree, stop and contact your Freescale representative.


5-step-5-step Activation Instructions (cont.)



The screenshot shows a web form titled "MQX Support Form". It contains several input fields for project and user information. The "Entitlement ID" field is pre-filled with "DL-LVL2MQX-050_VUTMIO5081". Below the form, there is a checkbox for "I Accept Agreement terms:" which is checked. At the bottom, there are "Cancel" and "Submit" buttons.

Figure 13: Support Project details Form

- This completes the registration process, a confirmation screen will be displayed.



The screenshot shows a "Registration Confirmation" screen. It displays the following information:

- Thanks for registering [MQX Commercial Support Package - 50 Hours - 12 Months]
- Registered to Freescale - Hold Account
- Registered Date: 11/18/2014
- Expiration Date: 11/18/2015
- Quantity: 1
- Support Hours: 0
- Reg. Code: DL-LVL2MQX-050_VUTMIO5081
- SWLIC_DEFAULT_INS
- Teamsite Abstract (WIP)
- Default Instructions

Figure 14: Confirmation Screen

5 Shared and personal accounts

You are now able to manage your software accounts and share your products.

You will be able to create new Shared accounts when registering a product if you are planning to share this software with your development team.

3-step-by-3-step Activation Instructions (cont.)

Creating a shared Software account:

Software and Support Activation
Product
 CodeWarrior Development Suite - Basic Edition, Annual Subscription, Node-locked License
 CWA-BASIC-AL_W9HQU564
 (Register a different product)

Account

Add product to:

Select

New Shared Account Shared Accounts allow multi users to access to a registered product

1. To create a new shared account click on “New Shared Account” on the “Add Product To” section
2. Enter a name for the shared account and add the members that will have access.

Software and Support Activation
Product
 CodeWarrior Development Suite - Basic Edition, Annual Subscription, Node-locked License
 CWA-BASIC-AL_W9HQU564
 (Register a different product)

New Account:

Account Name:

Members:

email Address:

email Address:

email Address:

email Address:

email Address:

Add Member

Add

Note: Members added in this account must have a registered profile in Freescale.com in order to access to the shared account.

A Shared Account Invitation will be sent to the members added.

Moving between Accounts

You are a member of multiple licensing accounts and are currently viewing **Shared Account To Which Account?**

Software & Support
 Product List
 Product Search
 Order History
 Recent Product Releases
 Recent Updates
 License Lists
 FAQ

Your login ID shows that you are a member on multiple accounts. Please select the account you wish to use for the current session or login as another user:

Product Name	Group	Role
Freemove - Internal	Group: Freemove	CS&S (L) (MS)
QIP Account	Group: Freemove	CS&S (L) (MS)
Group: Freemove Software Account	Group: Freemove	CS&S (L) (MS)
MSL_Prot	Group: Freemove	CS&S (L) (MS)
Freemove_Jump	Group: Freemove	CS&S (L) (MS)
Team_ Account	Group: Freemove	CS&S (L) (MS)

Download Lists
 If you think this account should be merged please contact Support!
 FAQs

Figure 15: Account Selection, New shared account

You can move between Accounts to select different groups and projects.

Freescale > Software & Support > Product Information: Freescale Software

You are a member of multiple licensing accounts and are currently viewing **Shared Account To Which Account?**

Software & Support
 Product List
 Product Search
 Order History
 Recent Product Releases
 Recent Updates
 License Lists
 FAQ

Product Information
Freescale Software
 Your choice contains a suite of products. Please select one of the product lines below:

CodeWarrior Development Suite - Professional
 CodeWarrior Development Suite - Standard

Download Lists

Step-by-step Activation Instructions (cont.)

Adding or removing members

You can add or remove members by entering a Service request.

**[www.freescale.com/webapp/
servicerequest.create_SR.framework](http://www.freescale.com/webapp/servicerequest.create_SR.framework)**
and selecting the Category: Software
Product Support and the Topic:
License Issue.

*Required Fields

Step 1 :	Category* :	<input type="text" value="Software Product Support"/>
Step 2 :	Topic* :	<input type="text" value="License Issue"/>





Support

Visit freescale.com/support for a list of phone numbers within your region.

Warranty

Visit freescale.com/warranty for complete warranty information.

For more information, visit freescale.com

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Tower is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. © 2014 Freescale Semiconductor, Inc.



Doc Number: SWSUPPACTQS REV 0