mail

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



QUICK START GUIDE FOR DEMONSTRATION CIRCUIT DC806 OCTAL 16 BIT 200KSPS ADC

LTC1867

DESCRIPTION

Demonstration circuit 806 features the LTC1867 Octal 16 bit ADC. The LTC1867 can be software programmed for a unipolar 0 to 4.096V or bipolar +/-2.048V input range. The 8 channel multiplexer can be programmed for 8 single-ended inputs with respect to ground, 7 single-ended inputs with respect to the COM/CH7 pin, 4 differential inputs, or any combination of these.

The LTC1867's DC performance is outstanding with a +/-2LSB INL specification and no missing codes over temperature.

The signal-to-noise ratio (SNR) for the LTC1867 is typically 89dB. Housed in a compact, narrow 16-pin SSOP package, the LTC1863/LTC1867 is ideal for space-sensitive and low-power applications.

Design files for this circuit board are available. Call the LTC factory.

✓, LTC are registered trademarks of Linear Technology Corporation.





QUICK START PROCEDURE

Connect DC806 to a DC590 USB serial controller using the supplied 14 conductor ribbon cable. Connect DC590 to a host PC with a standard USB A/B cable. Run the evaluation software supplied with DC590 or download it from <u>www.linear.com</u>. The correct control panel will be loaded automatically. Click the COLLECT button to begin reading the ADC. Change the channel and range by right-clicking over the channel or range indicator in the display.

Complete software documentation is available from the Help menu item, as features may be added periodically.



Figure 2. Software Screenshot



HARDWARE SET-UP

JUMPERS

JP1 – Select reference, either internal or the onboard LT1019 reference.

ANALOG CONNECTIONS (TURRET POSTS)

GND (3X) – Ground plane connections. DC806 can also be grounded to an application circuit by the exposed ground planes at the edges of the board.

CHO – CH7/COM – Analog inputs to LTC1859. Each input has a 100 / 1000pF filter to reduce wideband noise pickup.

VREF – Reference pin on LTC1859. When JP2 is set to INT, the LTC1867 uses its internal reference, or an ex-

ternal reference can be connected to this pin, overdriving the internal reference. When JP2 is set to LT1019, this turret should only be used for monitoring the reference voltage.

GROUNDING AND POWER CONNECTIONS

DC806 does not require any external power source when used with the DC590 USB controller board. However, an external 5V power source can be connected to the Vcc and ground turrets if the power supply on DC590 has been disabled. Refer to the DC590 quick start guide for more information.

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT DC806 OCTAL 16 BIT 200KSPS ADC



4