



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



Capacitance Meter Manual

Features

- About 1% accuracy. No calibration needed.
- Measuring range: 1pF - 500μF
- Automatic range select
- Zeroing available
- Real time serial output of measurement read-outs with time stamp
- Low cost and easy to build

How to assemble

It is pretty straightforward to assemble the cap meter. Install all parts included in the kit onto the PCB by following schematic and labels. Double check to ensure no soldering errors. If every thing ok then the cap meter can be powered up and put into use. No adjustment needed.

How to Use

Measurement:

Insert the capacitor to be tested into J5. Capacitance will be displayed. Alternatively caps not fitting into J5 can be connected through J3 with a pair of clips. Usually large caps take longer to show results but should not longer than 2 seconds.

Zeroing:

Remove cap (if any) from J5 and J3. Press the "ZERO" button. "C0 " will display. Wait for it to disappear. Now the stray capacitance is compensated. The compensation value is stored in EEPROM and will remain in effect until another zeroing is performed. **To obtain good measurement results for small capacitance shielding is required. To do this put the board into a metal box and connect the ground of the meter to the enclosure.**

Serial Data Format:

The ASCII outputs from TXD pin of J4 include sequence number, measurement time (in seconds), and measured capacitance. The baud rate is 38.4Kbps fixed. The data format is 8 data bits, 1 stop bit, and no parity.

Specifications

Error:	< 2%
Range:	1pF – 500μF
Power Supply voltage:	8 – 16 DC
Power Supply current:	<30mA

Revision History

Version	Date	Descriptions
01	2008.09.17	First created
02	2008.11.28	Modified for 109-06000-00B PCB. Removed reworking instructions since errors in previous PCB had been corrected.