

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China











Operator's Manual PP016 Passive Probe



© 2013 Teledyne LeCroy, Inc. All rights reserved.

Unauthorized duplication of Teledyne LeCroy documentation materials other than for internal sales and distribution purposes is strictly prohibited. However, clients are encouraged to distribute and duplicate Teledyne LeCroy documentation for their own internal educational purposes.

WaveAce and Teledyne LeCroy are registered trademarks of Teledyne LeCroy, Inc. Windows is a registered trademark of Microsoft Corporation. Other product or brand names are trademarks or requested trademarks of their respective holders. Information in this publication supersedes all earlier versions. Specifications are subject to change without notice.

Warranty

Teledyne Lecroy warrants this oscilloscope accessory for normal use and operation within specification for a period of one year from the date of shipment. Spare parts, replacement parts and repairs are warranted for 90 days.

In exercising its warranty, Teledyne Lecroy, at its option, will either repair or replace any assembly returned within its warranty period to the Customer Service Department or an authorized service center. However, this will be done only if the product is determined by Teledyne Lecroy's examination to be defective due to workmanship or materials, and the defect is not caused by misuse, neglect, accident, abnormal conditions of operation, or damage resulting from attempted repair or modifications by a non-authorized service facility.

The customer will be responsible for the transportation and insurance charges for the return of products to the service facility. Teledyne Lecroy will return all products under warranty with transportation charges prepaid.

This warranty replaces all other warranties, expressed or implied, including but not limited to any implied warranty of merchantability, fitness or adequacy for any particular purposes or use. Teledyne Lecroy shall not be liable for any special, incidental, or consequential damages, whether in contract or otherwise.

922209-00 Rev A January 2013

Safety Instructions

This section contains instructions that must be observed to keep this oscilloscope accessory operating in a correct and safe condition. You are required to follow generally accepted safety procedures in addition to the precautions specified in this section. The overall safety of any system incorporating this accessory is the responsibility of the assembler of the system.

Symbols

These terms and symbols may appear on the probe body or in this manual to alert you to important safety considerations.



High Voltage, risk of electric shock.



CAUTION of potential damage to equipment, or **WARNING** of potential for bodily injury. Attend to the accompanying information/product manual to protect against personal injury or damage. Do not proceed until conditions are fully understood and met.



DOUBLE INSULATION



PROTECTIVE (EARTH) TERMINAL

Precautions

To avoid personal injury or damage to property, review and comply with the following safety precautions. **Use product only as specified.**

Connect only to grounded instruments. Use only with compatible Teledyne LeCroy oscilloscopes that have their BNC input connected to an earth ground. Do not connect the probe reference lead to any point which is at a potential other than earth ground.

Connect and disconnect properly. Connect probe to the oscilloscope before connecting the probe to the test circuit. Disconnect the probe input and reference lead from the test circuit before disconnecting the probe from the oscilloscope. To avoid injury or death due to electric shock, do not connect or disconnect probes or probe accessories while they are connected to a voltage source.

2 922209-00 Rev A

Do not overload. To avoid electric shock or fire, do not apply any potential to the probe leads that exceeds the maximum rating of the probe.

Comply with voltage derating curve. When measuring higher frequency signals, comply with the Voltage vs. Frequency Derating Curve.

Observe all terminal ratings. To avoid electric shock or fire, observe all markings on the oscilloscope before connecting. Consult the respective oscilloscope product manual for further ratings information.

Do not remove probe casing. Removing the probe's case or touching exposed connections may result in electric shock.

Use only within operational environment listed. Do not use in wet or explosive atmospheres. Keep product surfaces clean and dry.

Use only accessories compatible with the probe.

Handle with care. The probe tip is extremely sharp and may puncture skin or cause other bodily injury if not handled properly.

Keep fingers behind the finger guard of probe body and accessories.

Do not operate with suspected failures. Before each use, inspect the probe and accessories for any potential damage such as tears or other defects in the probe body, cable jacket, accessories, etc. If any part is damaged, cease operation immediately and sequester the probe from inadvertent use.

Operating Environment

The accessory is intended for indoor use and should be operated in a clean, dry environment. Before using this product, ensure that its operating environment is maintained within these parameters:

Temperature: Operating, 5° to 40° C; Non-operating, - 20° to 60° C

Humidity: 5% to 85% relative humidity (%RH) up to +30° C

5% to 65% RH above +30° C to 40° C

5% to 45% RH above 40° C

Altitude: Up to 3000 m (9842 ft)

Introduction

The probe PP016 described in this manual is a passive probe to be used with Teledyne LeCroy WaveAce oscilloscopes.

Accessories

Following is the standard accessory kit included with the PP016.

Standard Ground Lead	1
Sprung Hook	1
Color Coding Rings (set)	2
Adjustment Tool	1
Ground Attachment	1
Replacement Probe Tip	2
BNC Adaptor	1
IC Test Tip	2

The part number for the Standard Accessory Replacement Kit is PKIT3-5MM-101.

4 922209-00 Rev A

Specifications



Attenuation 1: 1 10:1 Bandwidth (MHz) 10 300 Input R (M Ω) 1 10 Input C (pF) 46 12 Compensation Range (pF) NA 10-35

Maximum Input Voltage 600 V (DC + AC_{peak}) CAT II

Cable Length 1.2 m
Connector Type BNC

Operating Temperature 5° to 40° C Storage Temperature -20° to 60° C

Humidity 5% to 85% relative humidity (%RH) up to +30° C


5% to 65% RH above +30° C to 40° C

5% to 45% RH above 40° C

Operating Altitude Up to 3000 m

NOTE: The maximum input voltage derates when frequency response is approximately 30 kHz or higher. See Voltage Derating curve below.

Voltage Derating




Cleaning

The outside of the probe should cleaned with a soft cloth dampened with either deionized / distilled water or isopropyl alcohol. Allow the surface to dry completely before returning the probe to service. Never immerse the probe in any liquid.

Probe Compensation

Proper compensation of the probe is required to assure good amplitude accuracy in the dynamic portions of the waveform being measured. LF compensation matches the probe to differences in oscilloscope input capacitance. The LF compensation should always be checked and adjusted as needed when first connecting a passive probe to the oscilloscope input. HF compensation matches time constants within the probe to compensate for normal component tolerances. It is typically not necessary to adjust HF compensation unless the probe is being used with an oscilloscope with large differences in input characteristics than the oscilloscope model it was designed for.

LF compensation is performed by connecting the input of the probe to a low frequency square wave, such as the oscilloscope calibrator signal set to 1 kHz. The compensation is adjusted by rotating the adjustment accessible through the small hole in the center of the housing near the BNC connector. Use the tool supplied with the probe for this adjustment.



6 922209-00 Rev A

Certifications

This section certifies the probe' Safety and Environmental compliance.

EC Declaration of Conformity - Safety

The probe meets intent of EC Directive 2006/95/EC for Product Safety. Compliance was demonstrated to the following specifications as listed in the Official Journal of the European Communities:

EN 61010-031/A1:2008 Safety requirements for electrical equipment for measurement, control, and laboratory use – Part 031: Safety requirements for hand-held probe assemblies for electrical measurement and test.

- Measurement Category II (CAT II), measurements performed on circuits directly connected to the low-voltage installation.
- Pollution Degree 2, operating environment where normally only dry nonconductive pollution occurs. Conductivity caused by temporary condensation should be expected.

Environmental Compliance

END-OF-LIFE HANDLING



The instrument is marked with this symbol to indicate that it complies with the applicable European Union requirements to Directives 2002/96/EC and 2006/66/EC on Waste Electrical and Electronic Equipment (WEEE) and Batteries.

The instrument is subject to disposal and recycling regulations that vary by country and region. Many countries prohibit the disposal of waste electronic equipment in standard waste receptacles. For more

information about proper disposal and recycling of your Teledyne LeCroy product, please visit teledynelecroy.com/recycle.

RESTRICTION OF HAZARDOUS SUBSTANCES (ROHS)

This instrument has been classified as Industrial Monitoring and Control Equipment and is outside the scope of the 2011/65/EU RoHS Directive until 22 July 2017 (per Article 4, Paragraph 3).

Contact Teledyne LeCroy

Teledyne LeCroy Service Centers

United States and Canada -World Wide Corporate Office

Teledyne LeCroy Corporation 700 Chestnut Ridge Road

Chestnut Ridge, NY, 10977-6499, USA Ph: 800-553-2769 / 845-425-2000

FAX: 845-578-5985 teledynelecrov.com

Support:

contact.corp@teledynelecrov.com

Sales:

customersupport@teledynelecroy.com

United States - Protocol Solutions Group

Teledyne LeCroy Corporation 3385 Scott Boulevard Santa Clara, CA, 95054, USA

FAX: 408-727-0800 teledynelecrov.com

Sales and Service:

Ph: 800-909-7211 / 408-727-6600 contact.corp@teledynelecroy.com

Ph: 800-909-7112 / 408-653-1260 psqsupport@teledynelecrov.com

European Headquarters

Teledvne LeCrov SA 4. Rue Moïse Marcinhes Case postale 341 1217 Meyrin 1 Geneva. Switzerland Ph: + 41 22 719 2228 / 2323 /2277

FAX:+41 22 719 2233 contact.sa@teledynelecrov.com applications.indirect@teledynelecroy.com

teledynelecroy.com/europe **Protocol Analyzers:** Ph: +44 12 765 03971

Singapore, Oscillosocpes

Teledyne LeCrov Singapore Pte Ltd. Blk 750C Chai Chee Road #02-08 Technopark @ Chai Chee

Singapore 469003 Ph: ++ 65 64424880 FAX: ++ 65 64427811

Singapore, Protocol Analyzers

Genetron Singapore Pte Ltd. 37 Kallang Pudding Road, #08-08 Tong Lee Building Block B Singapore 349315

Ph: ++ 65 9760-4682

Teledyne LeCroy Corporation Beijing Rm. 2001 - Office; Rm. 2002 - Service Center Unit A. Horizon Plaza

No. 6. Zhichun Road, Haidian District

Beijing 100088, China

Ph: ++86 10 8280 0318 / 0319 / 0320

FAX:++86 10 8280 0316

Service:

Rm. 2002

Ph: ++86 10 8280 0245

Korea

Teledyne LeCroy Korea 10th fl. Ildong Bldg.

968-5 Daechi-dong, Gangnam-gu

Seoul 135-280. Korea Ph: ++ 82 2 3452 0400 FAX: ++ 82 2 3452 0490

Taiwan

LeColn Technology Co Ltd. Far East Century Park, C3, 9F No. 2, Chien-8th Road,

Chung-Ho Dist., New Taipei City, Taiwan

Ph: ++ 886 2 8226 1366 FAX: ++ 886 2 8226 1368

Japan

Teledyne LeCroy Japan Hobunsya Funchu Bldg, 3F 3-11-5, Midori-cho, Fuchu-Shi Tokyo 183-0006, Japan Ph: ++ 81 4 2402 9400

FAX: ++ 81 4 2402 9586 teledynelecroy.com/japan



700 Chestnut Ridge Road Chestnut Ridge, NY 10977 USA

teledynelecroy.com