



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



LANTRONIX®



PremierWave® XC HSPA+ Intelligent Gateway User Guide

Part Number 900-678
Revision D February 2017

Intellectual Property

© 2017 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

Lantronix and *PremierWave* are registered trademarks of Lantronix, Inc. in the United States and other countries. *DeviceInstaller* is a trademark of Lantronix, Inc.

Patented: patents.lantronix.com; additional patents pending

Windows and *Internet Explorer* are registered trademarks of Microsoft Corporation. *Mozilla* and *Firefox* are registered trademarks of the Mozilla Foundation. *Chrome* is a trademark of Google Inc. *Safari* is a registered trademark of Apple Inc. *Wi-Fi* is a trademark of Wi-Fi Alliance Corporation. All other trademarks and trade names are the property of their respective holders.

Warranty

For details on the Lantronix warranty policy, please go to our web site at www.lantronix.com/support/warranty.

Contacts

Lantronix, Inc.
7535 Irvine Center Drive
Suite 100
Irvine, CA 92618, USA

Toll Free: 800-526-8766
Phone: 949-453-3990
Fax: 949-453-3995

Technical Support

Online: www.lantronix.com/support

Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix web site at www.lantronix.com/about/contact.

Disclaimer

All information contained herein is provided “AS IS.” **Lantronix undertakes no obligation to update the information in this publication.** Lantronix does not make, and specifically disclaims, all warranties of any kind (express, implied or otherwise) regarding title, non-infringement, fitness, quality, accuracy, completeness, usefulness, suitability or performance of the information provided herein. Lantronix shall have no liability whatsoever to any user for any damages, losses and causes of action (whether in contract or in tort or otherwise) in connection with the user’s access or usage of any of the information or content contained herein. **The information and specifications contained in this document are subject to change without notice.**

Revision History

Date	Rev.	Comments
October 2016	F	Updated document to firmware release 8.0.0.0R19. Changes include: <ul style="list-style-type: none">◆ Added Modbus, IPv6, and Initial Send content.◆ Updated Flash and SNMP information.◆ Removed Query Port content.
May 2013	A	Initial document for firmware release 7.7.0.0R27.
April 2014	B	Updated document to firmware release 7.8.0.0.
August 2014	C	Updated document to firmware release 7.9.0.0.
February 2017	D	Updated document to firmware release 8.0.0.0. Changes include adding IPv6, TCP Keep Alive, IKEv2, log verbosity, cellular modem IO, and cellular network traffic information.

Table of Contents

Intellectual Property	2
Warranty	2
Contacts	2
Disclaimer	2
Revision History	3
List of Figures	11
List of Tables	12
1: Using This Guide	15
Purpose and Audience	15
Summary of Chapters	15
Additional Documentation	16
2: Introduction	17
Key Features	17
Applications	18
Protocol Support	18
Troubleshooting Capabilities	19
Configuration Methods	19
Addresses and Port Numbers	19
Hardware Address	19
IP Address	20
Port Numbers	20
Product Information Label	20
3: Installation of the PremierWave XC HSPA+ Device	21
Package Contents	21
User-Supplied Items	21
Hardware Components	22
Front/Top Panel	22
Back Panel	26
Installing the PremierWave XC HSPA+ Unit Device	26
4: Device Discovery and Quick Setup	29
Accessing the PremierWave XC HSPA+ Device Using UPnP	29
Accessing the PremierWave XC HSPA+ Device Using DeviceInstaller	30
Device Detail Summary	30

5: Configuration Using Web Manager 32

Accessing Web Manager _____	32
Device Status Page _____	33
Web Manager Components _____	34
Navigating Web Manager _____	35

6: Network Settings 38

Network 1 Status _____	38
Network 1 (eth0) Interface Settings _____	38
To Configure Network 1 Interface Settings _____	40
Network 1 (eth0) Link Settings _____	41
To Configure Network 1 Link Settings _____	41
Network 1 (eth0) QoS _____	41
To Configure Network 1 QoS Settings _____	42
Network 1 (eth0) Failover _____	43
To Configure Network 1 Failover Settings _____	43
Network 2 Status _____	44
Network 2 (Cellular “wwan0”) Interface Settings _____	44
To Configure Network 2 Interface Settings _____	45
Network 2 (Cellular “wwan0”) Link Settings _____	45
To Configure Network 2 Link Settings _____	45
Network 2 (Cellular “wwan0”) QoS _____	46
To Configure Network 2 QoS Settings _____	47
Gateway _____	47
Status _____	47
WAN _____	47
WAN MAC Address Filters _____	48
To Configure Gateway WAN Settings _____	48
Port Forwarding _____	48
To Configure Gateway Port Forwarding Settings _____	49
Static Routes _____	49
To Configure Gateway Static Route Settings _____	50
DHCP Server _____	50
To Configure Gateway DHCP Server Settings _____	51
Static Lease Listing _____	51
Routing Protocols _____	51
To Configure Gateway Routing Protocol Settings _____	52
Virtual IP _____	52
To Configure Gateway Virtual IP _____	53
DDNS _____	53
To Configure Gateway WAN Settings _____	54
VPN _____	54

To Configure VPN Settings _____	56
GRE Settings _____	56
To Configure Tunnel Serial Settings _____	57
7: Cellular	58
To Configure Cellular Settings _____	58
Typical Cellular Error (errcodes) _____	59
8: Input/Output Ports	60
Relay Output _____	60
To Configure Relay Settings _____	60
Digital Input _____	61
To Configure Digital Input Settings _____	61
9: Action Settings	62
Alarms and Reports _____	62
Actions _____	62
To Configure Action Settings _____	63
Python _____	64
IDE _____	64
Applications _____	65
To Configure Application Settings _____	66
10: Line and Tunnel Settings	67
Line Statistics _____	67
Line Settings _____	67
To Configure Line Settings _____	67
To Configure Line Command Mode _____	69
Tunnel Statistics _____	70
To View Tunnel Statistics _____	70
Tunnel Settings _____	70
Serial Settings _____	70
To Configure Tunnel Serial Settings _____	71
Packing Mode _____	71
To Configure Tunnel Packing Mode Settings _____	72
Accept Mode _____	72
To Configure Tunnel Accept Mode Settings _____	75
Connect Mode _____	75
Connecting Multiple Hosts _____	78
Host List Promotion _____	79
Disconnect Mode _____	79
To Configure Tunnel Disconnect Mode Settings _____	79

Modem Emulation _____	80
To Configure Tunnel Modem Emulation Settings _____	81
11: Terminal and Host Settings	82
Terminal Settings _____	82
To Configure the Terminal Network Connection _____	83
To Configure the Terminal Line Connection _____	83
Host Configuration _____	83
To Configure Host Settings _____	84
12: Network Services	85
DNS Settings _____	85
To View or Configure DNS Settings: _____	85
FTP Settings _____	86
To Configure FTP Settings _____	86
Syslog Settings _____	86
To View or Configure Syslog Settings _____	87
HTTP Settings _____	87
To Configure HTTP Settings _____	88
To Configure HTTP Authentication _____	89
RSS Settings _____	89
To Configure RSS Settings _____	90
SNMP Settings _____	90
To Configure SNMP Settings _____	91
Discovery _____	91
To Configure Discovery _____	91
SMTP Settings _____	92
To Configure SMTP Settings _____	92
Email Settings _____	92
To View, Configure, and Send Email _____	93
13: SMS Settings	94
Inbound SMS _____	94
Outbound SMS _____	94
To Configure Inbound SMS _____	95
To Configure Outbound SMS _____	95
14: Updating Firmware	96
Obtaining Firmware _____	96
Loading New Firmware through Web Manager _____	96
Loading New Firmware through FTP _____	98

15: Security Settings 99

Public Key Infrastructure _____	99
TLS (SSL) _____	99
Digital Certificates _____	100
Trusted Authorities _____	100
Obtaining Certificates _____	100
Self-Signed Certificates _____	100
Certificate Formats _____	100
OpenSSL _____	101
SSH Settings _____	101
SSH Server Host Keys _____	101
SSH Client Known Hosts _____	102
SSH Server Authorized Users _____	102
SSH Client Users _____	103
To Configure SSH Settings _____	104
SSL Settings _____	105
Create a New Credential _____	105
To Create a New Credential _____	105
Upload Certificate _____	106
Certificate and Key Generation _____	106
To Configure an Existing SSL Credential _____	107
Trusted Authorities _____	108

16: Maintenance and Diagnostics Settings 109

Filesystem Settings _____	109
Statistics _____	109
To View Statistics _____	109
File Display _____	109
To Display Files _____	110
File Modification _____	110
File Transfer _____	110
To Transfer or Modify Filesystem Files _____	111
Protocol Stack Settings _____	111
IP Settings _____	111
To Configure IP Protocol Stack Settings _____	112
ICMP Settings _____	112
To Configure ICMP Protocol Stack Settings _____	112
To View ICMP Protocol Stack Settings _____	112
ARP Settings _____	113
To Configure ARP Network Stack Settings _____	113
Diagnostics _____	114
Hardware _____	114

To View Hardware Information	114
IP Sockets	114
To View the List of IP Sockets	114
Ping	114
To Ping a Remote Host	115
Traceroute	115
To Perform a Traceroute	115
Log	116
To Configure the Diagnostic Log Output	116
Memory	116
To View Memory Usage	116
Processes	117
To View Process Information	117
Threads	117
To View Thread Information	117
Clock	118
To Specify Clock Setting Method	118
System Settings	119
To Reboot or Restore Factory Defaults	119

17: Management Interface Settings **120**

Command Line Interface Settings	120
Basic CLI Settings	120
To View and Configure Basic CLI Settings	120
Telnet Settings	121
To Configure Telnet CLI Settings	121
SSH CLI Settings	121
To Configure SSH Settings	122
XML Settings	122
XML: Export Configuration	122
To Export Configuration in XML Format	123
XML: Export Status	123
To Export in XML Format	123
XML: Import Configuration	124
To Import Configuration in XML Format	125

18: Branding the PremierWave XC HSPA+ Device **126**

Web Manager Customization	126
Short and Long Name Customization	127
To Customize Short or Long Names	127

Appendix A: Technical Specifications **128**

Network	128
Cellular	128
Ethernet	128
Serial Interface	128
Serial Connector	128
USB Interface	128
USB Connector	129
I/O Interface	129
Input	129
Output	129
I/O Connectors	129
LED Indicators	129
Routing/Gateway	129
Protocol Support	130
Event Triggers and Actions	130
Security	130
Management	130
Software	130
Power	131
Environmental	131
Dimensions	131

Appendix B: Compliance **132**

Appendix C: Lantronix Technical Support **135**

Appendix D: Binary to Hexadecimal Conversions **136**

Converting Binary to Hexadecimal	136
Conversion Table	136
Scientific Calculator	136

List of Figures

Figure 2-1 PremierWave Unit Product Label	20
Figure 3-1 PremierWave XC HSPA+ Unit	22
Figure 3-5 PremierWave XC HSPA+ Male DB9 DTE Serial Ports	24
Figure 3-6 PremierWave XC HSPA+ Pinout Configuration for RS-232	24
Figure 3-7 PremierWave XC HSPA+ Pinout Configuration for Full Duplex RS-422/485 (4-wire)	25
Figure 3-8 PremierWave XC HSPA+ Pinout Configuration for Half Duplex RS-422/485 (2-wire)	25
Figure 3-11 PremierWave XC HSPA+ Bottom/Back Panel View	26
Figure 3-13 SIM Card Insertion	27
Figure 3-14 PremierWave XC HSPA+ Unit Dimensions in Inches (in)	28
Figure 5-1 Device Status Page	33
Figure 5-2 Components of the Web Manager Page	34
Figure 14-1 Uploading New Firmware	97
Figure D-2 Windows Scientific Calculator	137
Figure D-3 Hexadecimal Values in the Scientific Calculator	137

List of Tables

Table 3-2 PremierWave XC HSPA+ LEDs and Descriptions	22
Table 3-3 Fault Conditions Indicated by Blink Patterns	23
Table 3-4 Cellular Signal Strength Indicator	23
Table 3-9 Left Ethernet LED	25
Table 3-10 Right Ethernet LED	25
Table 3-12 PremierWave XC HSPA+ Connections (Side)	26
Table 5-3 Web Manager Pages	35
Table 6-1 Network Interface Settings	38
Table 6-2 Network 1 (eth0) Link Settings	41
Table 6-3 Network 1 (eth0) QoS Settings	42
Table 6-4 Adding or Deleting Network 1 (eth0) QoS Settings	42
Table 6-5 Network 1 (eth0) Failover Settings	43
Table 6-6 Network 2 (wwan0) Interface Settings	44
Table 6-7 Network 2 (wlan0) Link Settings	45
Table 6-8 Network 2 (wwan0) QoS Settings	46
Table 6-9 Adding or Deleting Network 2 (wwan0) QoS Settings	46
Table 6-10 WAN Configuration	47
Table 6-11 Adding a New MAC Address Filters	48
Table 6-12 Port Forwarding Rules List	49
Table 6-13 Adding a New Port Forwarding Rule	49
Table 6-14 Static Route Setting Routes	49
Table 6-15 Adding a New Static Route	50
Table 6-16 DHCP Settings	50
Table 6-17 Static Lease Listing	51
Table 6-18 Add a Static Lease	51
Table 6-19 Routing Protocol Settings	52
Table 6-20 Virtual IP Settings	52
Table 6-21 Adding a Virtual IP	53
Table 6-22 DDNS Configuration	53
Table 6-23 VPN Configuration	54
Table 6-24 GRE Settings	56
Table 8-1 Relay Output Settings	60
Table 8-2 Digital Input Settings	61
Table 9-1 Action Settings	62
Table 9-2 Script Settings	65

Table 10-1 Line Configuration Settings	68
Table 10-2 Line Command Mode Settings	69
Table 10-3 Tunnel Serial Settings	70
Table 10-4 Tunnel Packing Mode Settings	71
Table 10-5 Tunnel Accept Mode Settings	73
Table 10-6 Tunnel Connect Mode Settings	76
Table 10-7 Tunnel Disconnect Mode Settings	79
Table 10-8 Tunnel Modem Emulation Settings	80
Table 11-1 Terminal on Network and Line Settings	82
Table 11-2 Host Configuration	83
Table 12-1 DNS Settings	85
Table 12-2 FTP Settings	86
Table 12-3 Syslog Settings	86
Table 12-4 HTTP Settings	87
Table 12-5 HTTP Authentication Settings	89
Table 12-6 RSS Settings	89
Table 12-7 SNMP Settings	90
Table 12-8 Discovery Settings	91
Table 12-9 SMTP Settings	92
Table 12-10 Email Configuration	92
Table 13-1 Inbound SMS Settings	94
Table 13-2 Adding a New SMS Settings	94
Table 13-3 Outbound SMS Settings	94
Table 15-1 SSH Server Host Keys	101
Table 15-2 SSH Client Known Hosts	102
Table 15-3 SSH Server Authorized Users	103
Table 15-4 SSH Client Users	103
Table 15-5 Create New Keys	104
Table 15-6 Create a New Credentials	105
Table 15-7 Upload Certificate Settings	106
Table 15-8 Certificate and Key Generation Settings	106
Table 15-9 Trusted Authority Settings	108
Table 16-1 File Statistics	109
Table 16-2 File Display Settings	109
Table 16-3 File Modification Settings	110
Table 16-4 File Transfer Settings	110
Table 16-5 IP Protocol Stack Settings	111
Table 16-6 ICMP Protocol Stack Settings	112

Table 16-7 ARP Protocol Stack Settings	113
Table 16-8 Ping Settings	114
Table 16-9 Traceroute Settings	115
Table 16-10 Log Settings	116
Table 16-11 Clock Settings	118
Table 16-12 System Settings	119
Table 17-1 CLI Configuration Settings	120
Table 17-2 Telnet Settings	121
Table 17-3 SSH Settings	121
Table 17-4 XML Exporting Configuration	122
Table 17-5 Exporting Status	123
Table 17-6 Import Configuration from Filesystem Settings	124
Table 18-1 Short and Long Name Settings	127
Table D-1 Binary to Hexadecimal Conversion	136

1: Using This Guide

Purpose and Audience

This guide provides the information needed to configure, use, and update the Lantronix® PremierWave® XC HSPA+ intelligent gateway. It is intended for software developers and system integrators who are installing this product into their designs.

Summary of Chapters

The remaining chapters in this guide include:

Chapter	Description
2: Introduction	Main features of the product and the protocols it supports. Includes technical specifications.
3: Installation of the PremierWave XC HSPA+ Device	Instructions for installing the PremierWave XC HSPA+ device.
4: Device Discovery and Quick Setup	Instructions for viewing the device and configuration using UPnP and the DeviceInstaller™ utility.
5: Configuration Using Web Manager	Instructions for accessing Web Manager and using it to configure settings for the device.
6: Network Settings	Instructions for configuring network settings.
7: Cellular	Instructions for configuring cellular settings.
8: Input/Output Ports	Instructions for configuring relay output and digital input settings.
9: Action Settings	Instructions for configuring alarm settings.
10: Line and Tunnel Settings	Instructions for configuring line and tunnel settings.
11: Terminal and Host Settings	Instructions for configuring terminal and host settings.
12: Network Services	Instructions for configuring DNS, FTP, HTTP and Syslog settings.
13: SMS Settings	Instructions for configuring SMS Settings.
14: Updating Firmware	Instructions for obtaining and updating the latest firmware for the device.
15: Security Settings	Instructions for configuring SSL security settings.
16: Maintenance and Diagnostics Settings	Instructions to view statistics, files, and diagnose problems.
17: Management Interface Settings	Instructions for configuring CLI and XML settings.
18: Branding the PremierWave XC HSPA+ Device	Instructions on how to brand your device.
Appendix A: Technical Specifications	Technical specifications for the device.
Appendix B: Compliance	Lantronix compliance information.
Appendix C: Lantronix Technical Support	Instructions for contacting Lantronix Technical Support.
Appendix D: Binary to Hexadecimal Conversions	Instructions for converting binary values to hexadecimals.

Additional Documentation

Visit the Lantronix Web site at www.lantronix.com/support/documentation for the latest documentation and the following additional documentation.

Document	Description
PremierWave XC HSPA+ Intelligent Gateway Command Reference	Instructions for accessing Command Mode (the command line interface) using a Telnet connection, SSH connection or through the port. Detailed information about the commands. Also provides details for XML configuration and status.
PremierWave XC HSPA+ Intelligent Gateway Quick Start	Instructions for getting the PremierWave XC HSPA+ device up and running.
DeviceInstaller™ Utility Online Help	Instructions for using the Windows® operating system-based utility to locate the intelligent gateway and to view its current settings.
Com Port Redirector Quick Start and Online Help	Instructions for using the Windows operating system-based utility to create virtual com ports.
Secure Com Port Redirector User Guide	Instructions for using the Windows operating system-based utility to create secure virtual com ports.

2: Introduction

The PremierWave XC HSPA+ intelligent gateway is an industrial grade GSM/GPRS 3.5G cellular solution that enables customers to quickly connect their machines and assets for out-of-the-box Internet access, remote monitoring, control and cloud platform connectivity.

With highly configurable and easy to use software offering enterprise level security, the PremierWave XC HSPA+ intelligent gateway makes it possible to combine multiple application use cases in a compact, ruggedized platform.

Key Features

Communicate with Industrial Equipment and Machines Remotely and Securely

- ◆ Setup secure communication channels with serial and Ethernet based devices

Cellular Routing

- ◆ Ethernet to Cellular Routing
- ◆ NAT, Port Forwarding, Firewall

WAN Failover and Failback Support

- ◆ Support mission critical applications with a secondary path to the internet via cellular WAN

Device Server Application Suite

- ◆ Control and monitor serial port based devices over the IP network
- ◆ Supporting multiple virtual serial connections
- ◆ Multiple connection modes and configuration options to enable transparent tunneling of hundreds of serial protocols

Event Triggers and Actions

- ◆ Multiple configurable actions for pre-defined event triggers
- ◆ Simple PLC operations and system state change notifications
- ◆ Actions include sending email, posting to a Web Service, sending SMS, triggering relay output

Enterprise Class Management Features

- ◆ Powerful and flexible Web browser based UI
- ◆ CLI for advanced administration tasks
- ◆ XML for batch configuration and status

Advanced SMS Features

- ◆ SMS Control and Status Features
- ◆ SMS Actions on Event Triggers
- ◆ Number White-listing by application

Global Cellular Coverage

- ◆ Penta-band UMTS/HSPA+ (800/850/900/1900/2100 MHz)
- ◆ Quad Band GSM/GPRS/EDGE (850/900/1800/1900 MHz)

Industrial Grade

- ◆ **Temperature Range:** Operating temperature at -40°C to +70°C. Storage temperature at -40°C to +85°C

Wide Voltage Range: 9 - 30VDC input voltage through locking barrel connector

Flexible Connectivity Options

- ◆ **Serial Ports:** Two RS-232/422/485 ports with support from 300 to 921 kbps data rate
- ◆ **Ethernet port:** Auto-Sensing and Auto MDIX (cross-over) 10/100
- ◆ **Digital Inputs:** Two configurable inputs suitable for TTL input levels and tolerant up to 30VDC input voltage
- ◆ **Relay Output:** One independently isolated mechanical form-C relay
- ◆ **USB:** One USB host port

Applications

The PremierWave XC HSPA+ intelligent gateway is very suitable for these application scenarios:

Remote Monitoring/Control

- ◆ Data Display Services/Digital Signage
- ◆ Oil and Gas Exploration
- ◆ Smart Metering
- ◆ Street Lighting
- ◆ Gas Station Pump Control
- ◆ Irrigation Pump Control
- ◆ Industrial Controls and Instrumentation
- ◆ Fixed Telemetry
- ◆ Railway Maintenance
- ◆ Food and Beverage Temperature Control
- ◆ Security and Access Control Panels
- ◆ In-home Monitoring

Out-of-Band Connectivity

- ◆ Point-of-Sale/Kiosks
- ◆ Call Boxes

Business Continuity Solutions

- ◆ Primary WAN Link
- ◆ Secondary WAN Failover/Failback

Protocol Support

The PremierWave XC HSPA+ intelligent gateway contains a full-featured IP networking stack:

- ◆ ARP, HTTP, HTTPS, SMTP AUTH, SNMP v1/v2c/v3, UDP/IP, TCP/IP, SSH, SSL, TLS, RSS, UPnP, ICMP, BOOTP, DHCP, Auto IP, Telnet, SNTP, FTP, FTPS, DNS, TFTP, XML and Syslog for network communications and management
- ◆ FTP and HTTP/HTTPS web server for firmware upgrades and uploading/downloading files
- ◆ TCP/IP, UDP/IP, Telnet, SSH, SSL, TCP AES and UDP AES for command/response based data acquisition application or alarm triggered connection
- ◆ HTTP/HTTPS web based monitoring of input readings, chart and data logging
- ◆ SMTP AUTH, SMS, HTTP/HTTPS Post, FTP/FTPS Put and SNMP Traps for alarm-triggered notification
- ◆ SNTP and Cellular Network for device clock synchronization

Troubleshooting Capabilities

The PremierWave XC HSPA+ device server offers a comprehensive diagnostic toolset that lets you troubleshoot problems quickly and easily. Available from the CLI or Web Manager, the diagnostic tools let you:

- ◆ View critical hardware, memory, buffer pool, IP socket information and routing table
- ◆ Perform ping and traceroute operations
- ◆ Conduct forward or reverse DNS lookup operations
- ◆ View all processes currently running on the PremierWave XC HSPA+ intelligent gateway including CPU utilization
- ◆ View system log messages

Configuration Methods

After installation, the PremierWave XC HSPA+ unit requires configuration. For the unit to operate correctly on a network, it must have a unique IP address on the network. There are four basic methods for logging into the PremierWave XC HSPA+ intelligent gateway and assigning IP addresses and other configurable settings:

- ◆ **Web Manager:** View and configure all settings easily through a web browser using the Lantronix Web Manager. (See [Configuration Using Web Manager on page 32.](#))
- ◆ **DeviceInstaller:** Configure the IP address and related settings and view current settings on the PremierWave XC HSPA+ intelligent gateway using a Graphical User Interface (GUI) on a PC attached to a network. You will need the latest version of the Lantronix® DeviceInstaller™ utility. (See [Accessing the PremierWave XC HSPA+ Device Using DeviceInstaller on page 30.](#))
- ◆ **Command Mode:** There are a few methods for accessing Command Mode (CLI): making a Telnet connection, or connecting a PC or other host running a terminal emulation program to the unit's serial port. (See the *PremierWave XC HSPA+ Intelligent Gateway Command Reference* for instructions and available commands.)
- ◆ **XML:** The PremierWave XC HSPA+ intelligent gateway supports XML-based configuration and setup records that make device configuration transparent to users and administrators. XML is easily editable with a standard text or XML editor. (See the *PremierWave XC HSPA+ Intelligent Gateway Command Reference* for instructions and commands).

Addresses and Port Numbers

Hardware Address

The hardware address is also referred to as the Ethernet address, physical address, or MAC address. The first three bytes of the Ethernet address are fixed and identify the unit as a Lantronix product. The fourth, fifth, and sixth bytes are unique numbers assigned to each unit. Sample hardware address:

- ◆ 00-80-A3-14-1B-18
- ◆ 00:80:A3:14:1B:18

3: Installation of the PremierWave XC HSPA+ Device

This chapter describes how to install the PremierWave XC HSPA+ intelligent gateway. It contains the following sections:

- ◆ [Package Contents](#)
- ◆ [User-Supplied Items](#)
- ◆ [Hardware Components](#)
- ◆ [Installing the PremierWave XC HSPA+ Unit Device](#)

Package Contents

The PremierWave XC HSPA+ package includes the following items:

- ◆ PremierWave XC HSPA+ intelligent gateway
- ◆ RJ-45 Ethernet Straight CAT5 cable
- ◆ Two External antennas with an SMA connector
- ◆ One Power Supply 12 VDC with international adapters (PXC2102H2-01-S) or One DC Power Cable (PXC2101H2-01-02-S)
- ◆ Mounting components (DIN rail mounting adapter, cover plates, and rubber feet)
- ◆ *PremierWave XC HSPA+ Quick Start Guide*

User-Supplied Items

To complete your installation, you need the following items:

- ◆ RS-232/422/485 serial devices that require network connectivity
- ◆ Devices and sensors that require network connectivity.
 - A serial cable, as listed below, for each serial device. One end of the cable must have a female DB9 connector for the serial port.
 - A null modem cable to connect the serial port to another DTE device.
 - A straight-through modem cable to connect the serial port to a DCE device.
- ◆ An available connection to your Ethernet network and an Ethernet cable.
- ◆ A working AC power outlet if the unit will be powered from an AC outlet using the included 12 VDC power supply
- ◆ If the unit uses the DC power cable (PXC2102H2-01-02-S) then a DC power supply with terminal blocks or screw terminals
- ◆ A network SIM card (and data services) from a service provider

Hardware Components

Front/Top Panel

Figure 3-1 shows the top panel view of the PremierWave unit. Table 3-2, Table 3-3, and Table 3-4 list and explain the behavior of the LEDs on the top panel.

LED Indicators: 1 Power LED, 2 Serial Activity LEDs, 1 USB LED, 1 Cellular Status LED, 5 Signal Strength LEDs (two of which are dual-colored), 1 Diagnostic LED, and 2 Ethernet LEDs (on the RJ45 port).

Figure 3-1 PremierWave XC HSPA+ Unit



Table 3-2 PremierWave XC HSPA+ LEDs and Descriptions

LED	Description
Power	<ul style="list-style-type: none"> ◆ GREEN - displays a solid light when power is properly supplied ◆ OFF - no power supplied
Cellular (Cell) Status	<ul style="list-style-type: none"> ◆ GREEN - displays solid when there is a connection to the packet domain on the cellular network (e.g., a data or GPRS/UMTS/HSPA connection) ◆ AMBER - displays solid when there is a connection to the cellular network (e.g., a GSM connection) ◆ OFF - indicates WWAN (cellular) interface is inactive or disabled
Serial 1	<ul style="list-style-type: none"> ◆ GREEN - flashes when Serial port 2 is transmitting data ◆ AMBER - flashes when Serial port 2 is receiving data ◆ OFF - when no data is being transmitted or received through Serial port 2
Serial 2	<ul style="list-style-type: none"> ◆ GREEN - flashes when Serial port 2 is transmitting data ◆ AMBER - flashes when Serial port 2 is receiving data ◆ OFF - when no data is being transmitted or received through Serial port 2
USB	<ul style="list-style-type: none"> ◆ GREEN - displays a solid light when a USB device is connected to and is functioning properly ◆ OFF - when no USB device is connected
Signal Strength	<ul style="list-style-type: none"> ◆ Indicates cellular signal strength when connection is established (see Table 3-2)

Table 3-3 Fault Conditions Indicated by Blink Patterns

Note: The fault LED blink patterns in this table are listed in order of priority.

Fault Conditions	Blink Pattern
No Ethernet link when eth0 (Ethernet Network) is enabled.	Long, long, short, short, 2 seconds off (pattern repeats)
No IP obtained from Ethernet network when eth0 interface is enabled.	Long, long, short, short, short, 2 seconds off (pattern repeats)
No link (no SIM detected)	Long(pattern repeats)
No cellular link when wwan0 (Cellular Network) is enabled	Long, long, long, long, short, 2 seconds off (pattern repeats)
No IP obtained from cellular networkwhen wwan0 (Cellular Network) is enabled and bridge mode is disabled	Long, long, long, short, short, short, 2 seconds off (pattern repeats)
When the internal device temperature is above operating limit.	Long, short, short, short, 2 seconds off (pattern repeats)
When the internal device temperature is below operating limit.	Short, short, short, short, 2 seconds off (pattern repeats)
Primary power source (barrel connector) is under-volt (below 9 volts).	Long, short, short (pattern repeats)
Secondary power source (terminal) is under-volt (below 9 volts).	Long, short, short, short (pattern repeats)

Table 3-4 Cellular Signal Strength Indicator

Signal Strength	Color & Number of LED Signal Bars
Greater than or equal to -64 dBm	5 Green
Greater than or equal to -85 dBm and less than -64 dBm	4 Green
Greater than or equal to -75 dBm and less than -85 dBm	3 Green
Greater than or equal to -86 dBm and less than -75 dBm	2 Amber
Greater than or equal to -112 dBm and less than -86 dBm	1 Amber
Less than -113 dBm or unmeasurable	All Off

Notes:

- ◆ For [Table 3-3](#) above, a “long” blink is 0.7 seconds of light followed by 0.3 seconds of no light. A “short” blink is a light that is on for only 0.2 seconds and followed by 0.2 seconds of no light.
- ◆ The diagnostic blink patterns reflect the highest priority fault condition. Also, the Diagnostic LED will give an initial, identifying blink pattern to indicate the type of diagnostic information it will display. All power and other non-network related diagnostic patterns, with the exception of Temperature events and No SIM Card events, begin with one long blink. All wired LAN related diagnostics patterns begin with two long blinks. All cellular-related diagnostics patterns begin with four long blinks.

The PremierWave device has two male DB9 serial ports that support RS-232/422/485. [Figure 3-5](#) shows the front view of the device. The default serial port settings are 9600 baud, 8 bits, no parity, 1 stop bit, no flow control.

Figure 3-5 PremierWave XC HSPA+ Male DB9 DTE Serial Ports




Figure 3-6 PremierWave XC HSPA+ Pinout Configuration for RS-232




Figure 3-7 PremierWave XC HSPA+ Pinout Configuration for Full Duplex RS-422/485 (4-wire)





Figure 3-8 PremierWave XC HSPA+ Pinout Configuration for Half Duplex RS-422/485 (2-wire)



Ethernet LEDs

The Ethernet port (see [Figure 3-11](#)) has two LEDs that indicate the status of the connection as described in the [Table 3-9](#) and [Table 3-10](#) below:

Table 3-9 Left Ethernet LED

Color/Status	Solid Light	Blinking Pattern
Green	100 Mbps Link	100 Mbps Activity
Amber	10 Mbps Link	10 Mbps Activity

Table 3-10 Right Ethernet LED

Color/Status	Solid Light
Green	Full Duplex
OFF	Half Duplex

The Ethernet port can connect to an Ethernet (10 Mbps) or Fast Ethernet (100 Mbps) network.

Reset Button

You can reset the PremierWave XC HSPA+ intelligent gateway to factory defaults, including clearing the network settings. The IP address, gateway, and netmask are set to 00s. To reset the unit to factory defaults, perform the following steps.

1. Place the end of a paper clip or similar object into the reset opening (see [Figure 3-5](#)) and press and hold down micro switch during a power cycle for 10-15 seconds.