



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.



User's Manual

QB-78K0KX2

In-Circuit Emulator

Target Devices

78K0/KB2

78K0/KC2

78K0/KD2

78K0/KE2

78K0/KF2

Document No. U17341EJ5V0UM00 (5th edition)
Date Published September 2006 N CP(K)

© NEC Electronics Corporation 2004
Printed in Japan

[MEMO]

IECUBE is a trademark of NEC Electronics Corporation.

PC/AT is a trademark of International Business Machines Corporation.

- **The information in this document is current as of September, 2006. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC Electronics data sheets or data books, etc., for the most up-to-date specifications of NEC Electronics products. Not all products and/or types are available in every country. Please check with an NEC Electronics sales representative for availability and additional information.**

- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.

- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.

- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of a customer's equipment shall be done under the full responsibility of the customer. NEC Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.

- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.

- NEC Electronics products are classified into the following three quality grades: "Standard", "Special" and "Specific".

The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics product before using it in a particular application.

"Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.

"Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).

"Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

(Note)

(1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.

(2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

[MEMO]

General Precautions for Handling This Product

1. Circumstances not covered by product guarantee

- If the product was disassembled, altered, or repaired by the customer
- If it was dropped, broken, or given another strong shock
- Use at overvoltage, use outside guaranteed temperature range, storing outside guaranteed temperature range
- If power was turned on while connection to the AC adapter, USB interface cable, or target system was in an unsatisfactory state
- If the cable of the AC adapter, the USB interface cable, the emulation probe, or the like was bent or pulled excessively
- If an AC adapter other than the supplied product was used
- If the product got wet
- If this product is connected to the target system when there is a potential difference between the GND of this product and GND of the target system.
- If the connectors or cables are plugged/unplugged while this product is in the power-on state.
- If excessive load is applied to the connectors or sockets (As for handling, please see **2.5 Mounting and Connecting Connectors**).
- If the product is used or stored in an environment where an electrostatic or electrical noise is likely to occur

2. Safety precautions

- If used for a long time, the product may become hot (50°C to 60°C). Be careful of low temperature burns and other dangers due to the product becoming hot.
- Be careful of electrical shock. There is a danger of electrical shock if the product is used as described above in **1 Circumstances not covered by product guarantee**.

INTRODUCTION

Readers This manual is intended for users who wish to perform debugging using the QB-78K0KX2. The readers of this manual are assumed to be familiar with the device functions and usage, and to have knowledge of debuggers.

Purpose This manual is intended to give users an understanding of the basic specifications and correct usage of the QB-78K0KX2.

Organization This manual is divided into the following sections.

- General
- Setup procedure
- Settings at product shipment
- Differences between target interface circuit and target device
- Notes

How to Read This Manual It is assumed that the readers of this manual have general knowledge in the fields of electrical engineering, logic circuits, and microcontrollers.

This manual describes the basic setup procedures and how to set switches.

To understand the overall functions and usages of the QB-78K0KX2

→Read this manual according to the **CONTENTS**. The mark <R> shows major revised points. The revised points can be easily searched by copying an "<R>" in the PDF file and specifying it in the "Find what:" field.

To know the manipulations, command functions, and other software-related settings of the QB-78K0KX2

→See the user's manual of the debugger (supplied with the QB-78K0KX2) to be used.

Conventions

Note: Footnote for item marked with **Note** in the text

Caution: Information requiring particular attention

Remark: Supplementary information

Numeric representation: Binary ... xxxx or xxxxB

Decimal ... xxxx

Hexadecimal ... xxxxH

Prefix indicating power of 2

(address space, memory

capacity):

K (kilo): $2^{10} = 1,024$

M (mega): $2^{20} = 1,024^2$

Terminology

The meanings of the terms used in this manual are described in the table below.

Term	Meaning
Target device	This is the device to be emulated.
Target system	This is the system to be debugged. This includes the target program and the hardware provided by the user.
78K0/Kx2	Generic name indicating 78K0/KB2, 78K0/KC2, 78K0/KD2, 78K0/KE2, and 78K0/KF2.
IECUBE™	Generic name for NEC Electronics' high-performance/compact in-circuit emulator.

Related Documents

Please use the following documents in conjunction with this manual.

The related documents listed below may include preliminary versions. However, preliminary versions are not marked as such.

Documents Related to Development Tools (User's Manuals)

Document Name		Document Number
QB-78K0KX2 In-Circuit Emulator		This manual
RA78K0 Assembler Package Ver. 3.80	Operation	U17199E
	Language	U17198E
	Structured Assembly Language	U17197E
CC78K0 C Compiler Ver. 3.70	Operation	U17201E
	Language	U17200E
ID78K0-QB Ver. 2.90 Integrated Debugger	Operation	U17437E
PM plus Ver. 5.20		U16934E

Caution The related documents listed above are subject to change without notice. Be sure to use the latest version of each document for designing, etc.

CONTENTS

CHAPTER 1 GENERAL	9
1.1 Hardware Specifications	10
1.2 System Specifications.....	11
1.3 System Configuration	12
1.4 Package Contents	16
CHAPTER 2 SETUP PROCEDURE	19
2.1 Names and Functions of Hardware.....	20
2.2 Removal of Acrylic Board	22
2.3 Clock Settings.....	22
2.3.1 Overview of clock settings	22
2.3.2 Clock setting methods	23
2.3.3 Main system clock.....	23
2.3.4 Subsystem clock	25
2.4 Software Settings	25
2.5 Mounting and Connecting Connectors	25
2.5.1 Mounting NQ in target system	25
2.5.2 Mounting YQ on NQ.....	26
2.5.3 Plugging EA into YQ.....	27
2.5.4 Notes on handling NQ, YQ, and YS	27
2.5.5 Notes on mounting NQ and IC	28
2.6 Connecting QB-78K0KX2 to Target System	28
2.7 Notes on Power Supply and GND Pin Connection	32
2.8 Connecting USB Interface Cable and AC Adapter.....	32
2.9 Switching Power On and Off	32
CHAPTER 3 SETTINGS AT PRODUCT SHIPMENT	33
CHAPTER 4 DIFFERENCES BETWEEN TARGET INTERFACE CIRCUIT AND TARGET DEVICE	34
4.1 For 78K0/KB2 Emulation.....	35
4.2 For 78K0/KC2 Emulation.....	37
4.3 For 78K0/KD2 Emulation.....	39
4.4 For 78K0/KE2 Emulation	41
4.5 For 78K0/KF2 Emulation	43
CHAPTER 5 NOTES	45
APPENDIX A REVISION HISTORY	46

CHAPTER 1 GENERAL


The QB-78K0KX2 is an in-circuit emulator for emulating the 78K0/Kx2.

Hardware and software can be debugged efficiently in the development of systems in which the 78K0/Kx2 is used. This manual describes basic setup procedures, hardware specifications, system specifications, and how to set switches.

1.1 Hardware Specifications

Table 1-1. QB-78K0KX2 Hardware Specifications

Parameter		Specification
Target device		78K0/KB2, 78K0/KC2, 78K0/KD2, 78K0/KE2, 78K0/KF2
Operating voltage		1.8 to 5.5 V
Operating frequency	Main system clock	V _{DD} = 4.0 to 5.5 V: 20 MHz V _{DD} = 2.7 to 5.5 V: 10 MHz V _{DD} = 1.8 to 5.5 V: 5 MHz
	Internal oscillation clock	Internal high-speed oscillation clock V _{DD} = 2.7 to 5.5 V: 8 MHz (TYP.) Internal low-speed oscillation clock V _{DD} = 2.7 to 5.5 V: 240 kHz (TYP.) (120 to 480 kHz)
	Subsystem clock	V _{DD} = 1.8 to 5.5 V: 32.768 kHz
Operating temperature range		0 to 40°C (No condensation)
Storage temperature range		-15 to 60°C (No condensation)
External dimensions		See figure below
Power consumption	AC adapter for QB-78K0KX2	15 V, 1 A
	Target system power supply	Voltage: 1.8 to 5.5 V Current: target device's current consumption + 10 mA (approx.)
Weight		300 g
Host interface		USB interface (1.1, 2.0)



- Notes**
1. Does not include projection of power switch
 2. Includes projection of screw that fixes rear space adapter
 3. Dimension when rear space adapter is made shortest (88 mm when longest)
 4. Front space adapter can vary from 20 mm (longest) to 5 mm (shortest)

1.2 System Specifications

This section shows the QB-78K0KX2 system specifications.

Table 1-2. QB-78K0KX2 System Specifications

Parameter		Specification
Emulation memory capacity	Internal ROM	128 KB (MAX.)
	Internal high-speed ROM	1 KB (MAX.)
	Internal expansion RAM	6 KB (MAX.)
Program execution functions	Real-time execution function	Go, Start from Here, Go & Go, Come Here, Restart, Return Out, Ignore break points and Go
	Non-real-time execution function	Step execution
Break functions	Event break	Execution: 8 points Access: Byte 8 points, word 2 points
	Software break	2000 points
	Pre-execution break	16 points
	Fail-safe break	Exists
	Other	Forcible break, trace full break, trace delay break, timeout break, timer overflow break
Trace functions	Trace data types	Program address, program data, access address, access data, status
	Trace modes	Full trace, section trace, qualify trace
	Trace functions	Delay function, full stop function
	Memory capacity	128K frames
Real-time RAM monitoring function		All spaces
Time measurement functions	Measurement clock	50 MHz or CPU clock
	Measurement objects	Beginning through end of program execution Start event through end event
	Maximum measurement time	Approximately 48 hours and 50 minutes (Resolution 41 μ s)
	Minimum resolution	20 ns (Measuring time: 85 seconds)
	Number of timers for measurement	Start through end of program execution: 1 Start event through end event: 2
	Measurement results	Maximum, minimum, average, cumulative, number of passes (between events)
	Other	Timer overflow break function, timeout break function
Other functions		Mapping function, event function, coverage function, snapshot function, DMM function, stub function, power-off emulation function, pin mask function


1.3 System Configuration

This section shows the system configuration when using the QB-78K0KX2 connected to a PC (PC-9821 series, PC/AT™ compatible). Connection is possible even without optional products.

Table 1-3. Devices Subject to Emulation by 78K0/Kx2

Device Name (Common Name)	Package	Device Name
		Flash Memory Version
78K0/KB2	30-pin SSOP (MC)	μ PD78F0500, μ PD78F0501, μ PD78F0502, μ PD78F0503, μ PD78F0503D
	36-pin FLGA (FC)	
78K0/KC2	44-pin LQFP (GB)	μ PD78F0511, μ PD78F0512, μ PD78F0513, μ PD78F0513D
	48-pin LQFP (GA)	μ PD78F0511, μ PD78F0512, μ PD78F0513, μ PD78F0514, μ PD78F0515, μ PD78F0515D
78K0/KD2	52-pin LQFP (GB)	μ PD78F0521, μ PD78F0522, μ PD78F0523, μ PD78F0524, μ PD78F0525, μ PD78F0526, μ PD78F0527, μ PD78F0527D
78K0/KE2	64-pin LQFP (GB, GC, GK)	μ PD78F0531, μ PD78F0532, μ PD78F0533, μ PD78F0534, μ PD78F0535, μ PD78F0536, μ PD78F0537, μ PD78F0537D
	64-pin TQFP (GA)	
	64-pin FLGA (FC)	
78K0/KF2	80-pin LQFP (GC, GK)	μ PD78F0544, μ PD78F0545, μ PD78F0546, μ PD78F0547, μ PD78F0547D

Figure 1-1. System Configuration



- | | |
|---|---|
| <p><1> Host machine:</p> <p><2> ID78K0-QB Disk/Accessory Disk^{Note1}:</p> <p><3> USB interface cable:</p> <p><4> AC adapter:</p> <p><5> QB-78K0KX2:</p> <p><6> Check pin adapter^{Note2}:</p> <p><7> Emulation probe:</p> <p><8> Exchange adapter^{Note3}:</p> <p><9> Space adapter^{Note3}:</p> <p><10> YQ connector^{Note3}:</p> <p><11> Target connector^{Note3}:</p> <p><12> Mount adapter^{Note3}:</p> <p><13> Device</p> | <p>PC-9821 series, PC/AT compatible can be used
Debugger, USB drivers, manual, etc.</p> <p>Cable connecting QB-78K0KX2 to host machine</p> <p>Can support 100 to 240 V by replacing AC plug
This product</p> <p>Adapter used when observing waveforms on oscilloscope</p> <p>Flexible type of emulation probe</p> <p>Adapter that performs pin conversion</p> <p>Adapter for height regulation</p> <p>Connector that connects exchange adapter to target connector</p> <p>Connector soldered to target system</p> <p>Adapter for socket mounting target device</p> <p>Target device</p> |
|---|---|

Refer to 1.4 **Package Contents** for the purchase forms of the above products.

- Notes 1.** Obtain device files from the NEC Electronics website.
<http://www.necel.com/micro/ods/eng/index.html>
- 2.** Please refer to [**Related Information**] on the following URL about attachment method for pin header cover.
<http://www.necel.com/micro/english/iecube/index.html>
- 3.** As for handling of connectors, refer to **2.5 Mounting and Connecting Connectors.**

Table 1-4. Check Pin Adapters

Package	Check Pin Adapter
Common	QB-144-CA-01

Table 1-5. Exchange Adapters

Package	Exchange Adapter
80GC	QB-80GC-EA-01T
80GK	QB-80GK-EA-01T
64FC	QB-64FC-EA-01T
64GA	QB-64GA-EA-01T
64GB	QB-64GB-EA-04T
64GC	QB-64GC-EA-03T
64GK	QB-64GK-EA-04T
52GB	QB-52GB-EA-02T
48GA	QB-48GA-EA-02T
44GB	QB-44GB-EA-03T
36FC	QB-36FC-EA-01T
30MC	QB-30MC-EA-02T

Table 1-6 Emulation Probes

Package	Emulation Probe
Common	QB-80-EP-01T

Table 1-7. YQ Connectors

Package	YQ Connector
80GC	QB-80GC-YQ-01T
80GK	QB-80GK-YQ-01T
64FC	_ Note
64GA	QB-64GA-YQ-01T
64GB	QB-64GB-YQ-01T
64GC	QB-64GC-YQ-01T
64GK	QB-64GK-YQ-01T
52GB	QB-52GB-YQ-01T
48GA	QB-48GA-YQ-01T
44GB	QB-44GB-YQ-01T
36FC	_ Note
30MC	QB-30MC-YQ-01T

Note Both 36FC and 64FC do not have YQ connectors, space adapters, and mount adapters.

Table 1-8 Space Adapters

Package	Space Adapter
80GC	QB-80GC-YS-01T
80GK	QB-80GK-YS-01T
64FC	<small>_ Note</small>
64GA	QB-64GA-YS-01T
64GB	QB-64GB-YS-01T
64GC	QB-64GC-YS-01T
64GK	QB-64GK-YS-01T
52GB	QB-52GB-YS-01T
48GA	QB-48GA-YS-01T
44GB	QB-44GB-YS-01T
36FC	<small>_ Note</small>
30MC	QB-30MC-YS-01T

Table 1-9. Target Connectors

Package	Target Connector
80GC	QB-80GC-NQ-01T
80GK	QB-80GK-NQ-01T
64FC	QB-64FC-NQ-01T
64GA	QB-64GA-NQ-01T
64GB	QB-64GB-NQ-01T
64GC	QB-64GC-NQ-01T
64GK	QB-64GK-NQ-01T
52GB	QB-52GB-NQ-01T
48GA	QB-48GA-NQ-01T
44GB	QB-44GB-NQ-01T
36FC	QB-36FC-NQ-01T
30MC	QB-30MC-NQ-01T

Note Both 36FC and 64FC do not have YQ connectors, space adapters, and mount adapters.

<R>

Table 1-10. Mount Adapters

Package	Mount Adapter
80GC	QB-80GC-HQ-01T
80GK	QB-80GK-HQ-01T
64FC	_Note
64GA	QB-64GA-HQ-01T
64GB	QB-64GB-HQ-01T
64GC	QB-64GC-HQ-01T
64GK	QB-64GK-HQ-01T
52GB	QB-52GB-HQ-01T
48GA	QB-48GA-HQ-01T
44GB	QB-44GB-HQ-01T
30MC	_Note
30MC	QB-30MC-HQ-01T

Note Both 36FC and 64FC do not have YQ connectors, space adapters, and mount adapters.

Remark For notes on target system design and package drawings, refer to [Related Information] on the following URL.
<http://www.necel.com/micro/english/iecube/index.html>

1.4 Package Contents

The following items have been placed in the QB-78K0KX2 packing box. Please check the contents.

Products supplied with QB-78K0KX2-ZZZ

- 1: QB-78K0KX2
- 2: AC adapter
- 3: USB interface cable (2 meters)
- 4: User registration
- 5: Simplified flash programmer (PG-FPL3 or QB-MINI2)
- 6: ID78K0-QB Disk (CD-ROM)
- 7: Accessory Disk (CD-ROM)
- 8: IECUBE Setup Manual

Products supplied with QB-78K0KX2-T80GC

- 1 to 8
- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-80GC-EA-01T
- 11: YQ connector QB-80GC-YQ-01T
- 12: Target connector QB-80GC-NQ-01T

Products supplied with QB-78K0KX2-T80GK

- 1 to 8
- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-80GK-EA-01T
- 11: YQ connector QB-80GK-YQ-01T
- 12: Target connector QB-80GK-NQ-01T

Products supplied with QB-78K0KX2-T64FC

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-64FC-EA-01T
- 12: Target connector QB-64FC-NQ-01T

Products supplied with QB-78K0KX2-T64GA

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-64GA-EA-01T
- 11: YQ connector QB-64GA-YQ-01T
- 12: Target connector QB-64GA-NQ-01T

Products supplied with QB-78K0KX2-T64GB

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-64GB-EA-04T
- 11: YQ connector QB-64GB-YQ-01T
- 12: Target connector QB-64GB-NQ-01T

Products supplied with QB-78K0KX2-T64GC

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-64GC-EA-03T
- 11: YQ connector QB-64GC-YQ-01T
- 12: Target connector QB-64GC-NQ-01T

<R>

Products supplied with QB-78K0KX2-T64GK

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-64GK-EA-04T
- 11: YQ connector QB-64GK-YQ-01T
- 12: Target connector QB-64GK-NQ-01T

Products supplied with QB-78K0KX2-T52GB

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-52GB-EA-02T
- 11: YQ connector QB-52GB-YQ-01T
- 12: Target connector QB-52GB-NQ-01T

Products supplied with QB-78K0KX2-T48GA

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-48GA-EA-02T
- 11: YQ connector QB-48GA-YQ-01T
- 12: Target connector QB-48GA-NQ-01T

Products supplied with QB-78K0KX2-T44GB

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-44GB-EA-03T
- 11: YQ connector QB-44GB-YQ-01T
- 12: Target connector QB-44GB-NQ-01T

Products supplied with QB-78K0KX2-T36FC

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-36FC-EA-01T
- 12: Target connector QB-36FC-NQ-01T

Products supplied with QB-78K0KX2-T30MC

1 to 8

- 9: Emulation probe QB-80-EP-01T
- 10: Exchange adapter QB-30MC-EA-02T
- 11: YQ connector QB-30MC-YQ-01T
- 12: Target connector QB-30MC-NQ-01T

The following products are sold as single items.

- Emulation probe
- Exchange adapter
- YQ connector^{Note}
- Target connector
- Check pin adapter
- Space adapter^{Note}
- Mount adapter^{Note}

Note Both 36FC and 64FC do not have YQ connectors, space adapters, and mount adapters.


CHAPTER 2 SETUP PROCEDURE

This chapter explains the QB-78K0KX2 setup procedure.

Setup can be completed by performing installation setup in the order in which it appears in this chapter.


Perform setup along the lines of the following procedure.

See **2.1 Names and Functions of Hardware** for clock board positions.



2.1 Names and Functions of Hardware

Figure 2-1. Names of Parts of QB-78K0KX2



(1) TCN1, TCN2

These are connectors for connecting a check pin adapter or emulation probe.

(2) OSC1

This is a socket for mounting the oscillator.

(3) CN4^{Note}

This is a connector for the shipment inspection.

Note It is not necessary for user to use CN4.

(4) POWER (Red LED)

This is an LED that shows whether or not the power supply of the QB-78K0KX2 is switched on.

LED State	QB-78K0KX2 State
Lit	Power switch ON
Not lit	Power switch OFF or AC adapter not connected to QB-78K0KX2
Blinking	Internal error occurred (Contact an NEC Electronics sales representative or distributor)

(5) TARGET (Green LED)

This is an LED that shows whether or not the power supply of the target system is switched on.

LED State	Target System State
Lit	Target system power supply ON
Not lit	Target system power supply OFF or target system not connected

(6) Power switch


This is the power switch of the QB-78K0KX2.

It is OFF at shipment.

2.2 Removal of Acrylic Board

To modify the clock setting, the acrylic board on the bottom of the QB-78K0KX2 must be removed. The acrylic board can be removed by lifting it up.

Figure 2-2. Acrylic Board Removal Method



<R> 2.3 Clock Settings

2.3.1 Overview of clock settings

The following 5 types of clock settings are available.

For details, see **2.3.2 Clock setting methods**.

Main system clock:

- (1) Using the clock generated in the emulator (with high-speed internal oscillator used)
- (2) Supplying a clock (square wave) from the target system
- (3) Using the oscillator (OSC1) mounted in the emulator

Subsystem clock:

- (1) Using the clock generated in the emulator
- (2) Supplying a clock (square wave) from the target system

2.3.2 Clock setting methods

This section shows the clock settings.

Table 2-1. Main System Clock Setting

Type of Clock to Be Used	OSC1	Debugger Setting
(1) Using the clock generated in the emulator (with high-speed internal oscillator used)	–	System
(2) Suppling a clock (square wave) from the target system ^{Note}	–	External
(3) Using the oscillator (OSC1) mounted in the emulator	Mount oscillator	Clock Board

Note Do not select this setting when the TARGET LED is not lit.

Remarks 1. Settings other than those above are prohibited.

2. Selection of (1) or (2) is possible regardless of whether or not the oscillator is mounted onto OSC1.

Table 2-2. Subsystem Clock Setting

Type of Clock to Be Used	Remarks
(1) Using the clock generated in the emulator	System
(2) Suppling a clock (square wave) from the target system ^{Note}	External

Note Do not select this setting when the TARGET LED is not lit.

Remark Settings other than those above are prohibited.

2.3.3 Main system clock

(1) Using the clock generated in the emulator (with high-speed internal oscillator used)

Select “System” in the configuration dialog box of the debugger and select the desired frequency from the dialog menu.

(2) Suppling a clock (square wave) from the target system

Select “External” in the configuration dialog box of the debugger to use the clock input from the target system. To input the clock from the target system, input to the clock pin (X2) the square wave^{Note} with the same potential as the target device (inputting the inverted waveform to the X1 pin is unnecessary).

Note Square waves from oscillators using a resonator are not supported.