



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





Starter kit User Guide

SK-FM3-48PMC-MB9BF524K

SK-FM3-48PMC-9BF524K-JL

Hardware V1.1 / Documentation V1.1

Warranty and Disclaimer

- The use of the deliverables (deliverables shall include, but not limited to, software, application examples, hardware, target boards, evaluation boards, starter kits, schematics, engineering samples of IC's etc.) is subject to the terms and conditions of Spansion LLC and its affiliates ("SPANSION") as set out below and in (i) the terms and conditions of the License Agreement and/or the Sale and Purchase Agreement and/or any other agreement under which deliverables have been delivered, (ii) the technical descriptions and (iii) all accompanying written materials.
- 1. Please note that the deliverables are intended for and must only be used for test applications in an evaluation laboratory environment.
- 2. The software deliverables are provided on an as-is basis without charge and are subject to alterations. It is the user's obligation to fully test the software in its environment and to ensure proper functionality, qualification and compliance with component specifications.
- 3. Regarding hardware deliverables, the following limited warranty shall apply:
 - Except as otherwise provided in the following paragraphs, for a period of one (1) year from date of shipment to customer ("Warranty Period"), SPANSION warrants the hardware deliverables (i) are free of defects in material and workmanship, and (ii) conform to SPANSION applicable data sheet specifications (available at www.spansion.com or upon request).
 - This warranty does not extend beyond the first purchaser of the deliverables. The liability of SPANSION under this warranty is limited, at SPANSION's option, solely to repair the deliverable, to send replacement deliverable, or to make an appropriate credit adjustment or refund in an amount not to exceed the original purchase price actually paid for the deliverable returned to SPANSION. SPANSION'S warranty obligations are conditioned upon the following: (a) SPANSION is promptly notified in writing by customer during the applicable warranty period of any defect or nonconformance in the deliverable, (b) customer obtains authorization from SPANSION to return the defective deliverable, (c) the defective deliverable is returned to SPANSION in accordance with SPANSION'S shipping instructions set forth below, and (d) SPANSION'S examination of such deliverable discloses to its satisfaction that any defect or nonconformance actually existed and was not caused by improper use or operation outside of the data sheet specifications for the deliverable, abuse, negligence, improper installation, accident, loss or damage in transit, or unauthorized repair or alteration by a person other than SPANSION. Customer shall ship such defective deliverable to SPANSION via SPANSION'S carrier, collect. Risk of loss will transfer to SPANSION when the defective deliverable is provided to SPANSION'S carrier. If customer fails to adhere to these warranty returns guidelines, customer shall assume all risk of loss and shall pay for all freight to SPANSION'S specified location. This warranty shall not apply to any deliverables that have been repaired or altered, except those which have been repaired or altered by SPANSION. The aforementioned provisions do not extend the original warranty period of any deliverable that has either been repaired or replaced by Seller.
 - THESE WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT, AND ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION OR SAMPLE. SPANSION NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITIES. THE FOREGOING CONSTITUTES CUSTOMER'S SOLE AND EXCLUSIVE REMEDY FOR THE FURNISHING OF DEFECTIVE OR NONCONFORMING DELIVERABLES.
- 4. The following limitation of liability shall apply for all deliverables
 - EXCEPT FOR DAMAGES FOR BODILY INJURY OR DEATH, SPANSION SHALL NOT BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL, RELIANCE, OR CONSEQUENTIAL DAMAGES, RELIANCE DAMAGES, AND/OR PUNITIVE, OR EXEMPLARY DAMAGES, WHETHER ANY SUCH DAMAGES ARE BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY, AND WHETHER OR NOT SPANSION HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES, AND NOTWITHSTANDING ANY FAILURE OF ESSENTIAL PURPOSE OF ANY LIMITED REMEDY.
 - REGARDLESS OF THE BASIS ON WHICH CUSTOMER IS ENTITLED TO CLAIM DAMAGES FROM SPANSION (INCLUDING FUNDAMENTAL BREACH, NEGLIGENCE, MISREPRESENTATION, OR OTHER CONTRACT OR TORT CLAIM), SPANSION ENTIRE LIABILITY IN ANY CALENDAR YEAR, REGARDLESS OF THE NUMBER OF CLAIMS, SHALL NOT EXCEED FIFTY PERCENT (50%) OF THE TOTAL AMOUNT PAID BY CUSTOMER TO SPANSION FOR THE DELIVERABLES SOLD IN SUCH CALENDAR YEAR.
- 5. Should one of the above stipulations be or become invalid and/or unenforceable, the remaining stipulations shall stay in full effect.
- 6. The contents of this document are subject to change by SPANSION without a prior notice, thus contact SPANSION about the latest one.
- This board and its deliverables must only be used for test applications in an evaluation laboratory environment.

- For your convenience this user guide includes external links that simplify installing of drivers, software utilities, and quick jumps to documentation.
- Some PDF viewer do not allow access to external content by links because of security reasons.
- A viewer called “PDF XChange” is provided in the software package of this starter kit. It’s use is free of charge and no additional installation is required.
- Launching “start.bat” opens this user guide in the PDF XChange viewer.
- Please ensure you have copied the complete software package related to this starter kit in order to use and run the links and examples given on the next pages.
- Please contact the [SpanSION Support](#) in case of any question.


■ Introduction

- [About the SK-FM3-48PMC-MB9BF524K](#)
- [SK-FM3-48PMC-MB9BF524K content](#)
- [SK-FM3-48PMC-9BF524K-JL content](#)
- [Test it](#)
- [The Hardware](#)
- [The Software](#)

■ Try yourself

- [Software examples](#)
- [Program download](#)
- [IAR-Embedded Workbench](#)
- [KEIL \$\mu\$ Vision](#)
- [Solutions](#)

■ [Workshops](#), [Contacts](#) & [More](#)



■ [Additional documents](#)

- [Schematic](#)
- [Factsheet](#)
- [Data sheet MB9B520M Series](#)
- [Peripheral Manual](#) and [Errata](#)
- [Peripheral Manual \(Timer Part\)](#) and [Errata](#)
- [Peripheral Manual \(Analog Part\)](#) and [Errata](#)
- [Peripheral Manual \(Communication Part\)](#) and [Errata](#)
- [Cortex M3 Technical Reference Manual](#)
- [Flash Programming Manual](#)


Please visit www.spansion.com to find latest releases of the above mentioned documents.

The SK-FM3-48PMC-MB9BF524K is available in two versions:

- The SK-FM3-48PMC-MB9BF524K includes a low-cost evaluation board based on the Spansion FM3 microcontroller MB9B520M Series
- SK-FM3-48PMC-9BF524K-JL includes a low-cost evaluation board based on the Spansion FM3 microcontroller MB9B520M Series and the JTAG adapter J-Link
- The MB9B520M Series includes the following features:
 - Up to 288 KByte Dual Operation Flash Memory
 - Up to 64 KByte RAM
 - Up to 2 CAN controller 2.0A/B
 - Up to 8 LIN-USART-I²C interfaces
 - USB-Host/-Device interface
 - Timers (ICUs, OCUs, PPGs, others)
 - Two 12 Bit ADCs, up to 26 channels
 - External interrupts


- Features of the SK-FM3-48PMC-MB9BF524K board:
 - Microcontroller MB9BF524K
 - 1x UART-Transceiver (SUB-D9 connector)
 - 1x USB to serial converter (Type-B connector)
 - 1x High-speed CAN-Transceiver (SUB-D9 connector)
 - 1x USB-Host (Type-A connector)
 - 1x USB-Device (Type-B connector)
 - 1x LED-Display (7-Segment)
 - 2x 'User'-button
 - 1x 'Reset'-button, 'Reset'-LED
 - JTAG-Interface on a 20 pin-header
 - FMTouch connector interface for [software touch solutions](#)
 - TSC-Interface to connect for example the Spansion SK-TSC-1127S-SB
 - All 48 pins routed to pin-header
 - On-board 5V and 3V voltage regulators, 'Power'-LED
 - Power supply via USB (UART'B'), USB-Device, JTAG or external with a 8V to 12V power connector

- The SK-FM3-48PMC-MB9BF524K contains
 - SK-FM3-48PMC-MB9BF524K evaluation board with MB9BF524K
 - USB cable
 - DVD: Documentation, USB driver, Software examples, Programmer




SK-FM3-48PMC-9BF524K-JL content

- The SK-FM3-48PMC-9BF524K-JL contains
 - SK-FM3-48PMC-MB9BF524K evaluation board with MB9BF524K
 - USB cable
 - DVD: Documentation, USB driver, Software examples, Programmer
 - Segger J-Link JTAG adapter incl. USB cable



- The microcontroller on the SK-FM3-48PMC-MB9BF524K is already preprogrammed with a simple application.
 - Connect the SK-FM3-48PMC-MB9BF524K via USB (X5) with the PC
 - [Install the USB driver from the DVD](#)
 - Press the ‚Reset‘- Button
 - The SK-FM3-48PMC-MB9BF524K will automatically start counting
 - The count direction can be changed by pressing the key buttons




Congratulations!

- You finished successfully the first test
- Now you will get more details about the SK-FM3-48PMC-MB9BF524K board
- You will learn more about
 - The on-board features
 - How to program the Flash
 - How to start with IAR-Embedded-Workbench and KEIL μ Vision

The Hardware

- Main features



■ The jumpers

JP1: UART-Reset

1-2: DTR-Signal of the UART connector is connected to the MCU reset-pin.

2-3: DTR-Signal of the USB connector is connected to the MCU reset-pin.

Some terminal-programs, e.g. Spansion's Skwizard, allow to reset the evaluation board by using the DTR-Signal.

JP6: MD0 selection

Close this jumper to control the MD0 level by the RTS signal of the USB interface

S1: Mode selection

PROG: Program-mode

RUN: Run-mode

JP10: 5V / 3.3V

1-2: 5V supply is used


2-3: 3.3V supply is used

JP4: UART RX select

R-0: UART0=UART'A' / U-4: UART4=UART'B' (USB) R-0: UART0=UART'A' / U-4: UART4=UART'B' (USB)

R-3: UART3=UART'A' / U-0: UART0=UART'B' (USB) R-3: UART3=UART'A' / U-0: UART0=UART'B' (USB)

JP5: UART TX select



JP9: MCU Vcc

This jumper can be used to measure the current consumption of the MCU

J5: Power Supply

1-2: USB (UART ,B') supply


3-4: USB Device supply

5-6: JLINK supply

7-8: External supply

The Hardware


■ The jumpers



- The jumpers(back)


JP20-JP23, JP27-JP30: SEG1
Closed: SEG1a- SEG1DP active

JP31-JP38: SEG2
Closed: SEG2a- SEG2DP active




- JP4, JP5 : UART selection

- UART0 and UART3 of the microcontroller can be used together with a typical RS232 SUB-D9 connector and a serial/USB converter
- The jumpers JP4 and JP5 routes the channel to the connector
- UART0 = USB-connector (X5), UART3 = Sub-D9 (X4) (default)
 - ◆ Setting of Jumper JP4 and JP5: U-0 / R-3




- UART0 = Sub-D9 (X4), UART3 = USB-connector (X5)
 - ◆ Setting of Jumper JP4 and JP5: U-3 / R-0



■ Extension headers X20-X23

- Standard 0.1" / 2.54mm grid for use with prototype boards



- The microcontroller pins

Board Function	Pin Function	MB9BF524K
MCUVCC	VCC	1
(SW-Touch_4 , Connector X15)/(TSC_7, Connector X10)/ UART3_1	P50/INT00_0 /AIN0_2/SIN3_1/AN22	2
(SW-Touch_3, Connector X15)/(TSC_2, Connector X10)/ UART3_1	INT01_0/BIN0_2/SOT3_1/AN23	3
(SW-Touch_2, Connector X15)/ (TSC_4, Connector X10)	P52/INT02_0/ZIN0_2/SCK3_1/AN24	4
SEG1b	P39/DTTI0X_0/INT06_0/ADTG_2	5
SEG1a	P3A/RTO00_0/TIOA0_1/INT07_0/SUBOUT_2/RTCCO_2	6
SEG1c	P3B/RTO01_0/TIOA1_1	7
SEG1d	P3C/RTO02_0 /TIOA2_1/INT18_2	8
SEG1g	P3D/RTO03_0/TIOA3_1	9
SEG1f	P3E/RTO04_0/TIOA4_1/INT19_2	10

- The microcontroller pins

Board Function	Pin Function	MB9BF524K
SEG1e	P3F/RTO05_0/TIOA5_1	11
GND	VSS	12
C-Pin	C	13
MCUVCC	VCC	14
(32.768KHz Crystal)	P46/X0A	15
(32.768KHz Crystal)	P47/X1A	16
Key button- ,Reset'	INITX	17
	P49/TIOB0_0/INT20_1/DA0_0/SOT3_2/AIN0_1	18
Key button ,INT'	P4A/TIOB1_0/INT21_1/DA1_0/SCK3_2/BIN0_1	19
GND	MD1/PE0	20

- The microcontroller pins

Board Function	Pin Function	MB9BF524K
Mode-Switch ,S1'	MD0	21
4MHz Crystal	X0/PE2	22
4MHz Crystal	X1/PE3	23
GND	VSS	24
USB Switch Device/Host	P10/AN00	25
CAN RX	P11/AN01/SIN1_1/INT02_1/RX1_2/FRCK0_2/WKUP1	26
CAN TX	P12/AN02/SOT1_1/TX1_2/IC00_2	27
GND	AVSS	28
USB Current limitation	AN04/INT03_1/IC02_2/SIN0_1	29
USB Host Power enable	P15/AN05/IC03_2/SOT0_1/INT14_0	30

- The microcontroller pins

Board Function	Pin Function	MB9BF524K
AVCC	AVCC	31
AVRH	AVRH	32
GND	AVRL	33
(SW-Touch _13, Connector X15)	SCK0_0/TIOA7_1/AN12	34
UART0 TX	P22/SOT0_0/TIOB7_1/ZIN1_1/AN13	35
UART0 RX	P21/SIN0_0/INT06_1/WKUP2/BIN1_1/AN14	36
(JTAG TRSTX, Connector X13)	P00/TRSTX	37
(JTAG TCK, Connector X13)	P01/TCK/SWCLK	38
(JTAG TDI, Connector X13)	P02/TDI	39
(JTAG TMS, Connector X13)	P03/TMS/SWDIO	40

- The microcontroller pins

Board Function	Pin Function	MB9BF524K
(JTAG TDO, Connector X13)	P04/TDO/SWO	41
NMIX/ WKUP	P0F/NMIX/SUBOUT_0/CROUT_1/RTCCO_0/WKUP0/AN18	42
USB UHCONX	P61/SOT5_0/TIOB2_2/UHCONX/DTTI0X_2/AN20	43
Mode Switch ,S1'	P60/SIN5_0/TIOA2_2/INT15_1/WKUP3/IGTRG_1/AN21	44
USB-power supply	USBVCC	45
USB Data -	P80/UDM0/INT16_1	46
USB Data +	P81/UDP0/INT17_1	47
GND	VSS	48


- The SK-FM3-48PMC-MB9BF524K DVD includes the following software:
 - MCU Flash programming tools
 - FLASH MCU Programmer for FM3
 - FLASH USB DIRECT Programmer
 - USB driver for on-board USB-to-RS232 converter
 - The terminal program ,Serial Port Viewer‘
 - The USB configuration tool ,USB Wizard‘
 - Software examples for the SK-FM3-48PMC-MB9BF524K
- Please check our dedicated microcontroller website:

www.spansion.com

- for updates of the Flash programmer tool, utilities and examples
- for data sheets, hardware manuals, application notes, etc.

Installation of the USB-driver

- Install the USB driver from the [DVD](#) with administrator privileges
- Start the Device Manager of the Windows Control Panel
 - START -> Settings -> Control Panel
 - Control Panel -> System -> Hardware -> Device Manager
- Check 'Ports' for the assigned virtual COM-port number
 - USB Serial Port (e.g.: COM7)



- Ready!

- Serial Port Viewer
 - Free of charge terminal program, [Start installation](#)
- USB Wizard
 - Free of charge USB configuration tool, [Start installation](#)
- Following examples are provided with SK-FM3-48PMC-MB9BF524K for IAR Embedded Workbench V6 and KEIL μ Vision4:
 - [mb9bf52xk template](#) ,Empty' project as base for user applications
 - [mb9bf52xk adc dvm](#) Digital Voltage Meter based on the A/D-converter
 - [mb9bf52xk can uart terminal](#) Simple CAN example (CAN0)
 - [mb9bf52xk ioport counter](#) Counts from 0 to 99 on the 7-segment Display
 - Further examples on [DVD](#) and on our website

Note: **Please copy the examples to your local drive!**



- There are three options to program the flash:
 - UART Programming (X4, X5)
 - ◆ Check jumper JP16 is opened
 - ◆ Connect UART0 of the board to the USB-Port of the PC
 - via USB (JP4,JP5: U-0, R-4)
 - via RS232 (JP4,JP5: U-4, R-0)
 - ◆ Use the [FLASH MCU Programmer](#)
 - USB Programming (X3)
 - ◆ Check jumper JP16 is closed
 - ◆ Connect the board via USB-Device (X3) to the USB-Port of the PC
 - ◆ Use the [FLASH USB DIRECT Programmer](#)
 - JTAG
 - ◆ Use the JTAG-adapter supported by the development toolchain.