



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





Quick Start Guide

TWR-IND-IO
Industrial I/O Module



TOWER SYSTEM

Get to Know the TWR-IND-IO



TWR-IND-IO Freescale Tower System

The TWR-IND-IO module is part of the Freescale Tower System, a modular development platform that enables rapid prototyping and tool re-use through reconfigurable hardware. Take your design to the next level and begin prototyping with your Tower System today.

TWR-IND-IO Features

- USB to Serial Ready Play solution, providing serial connectivity via USB
- RS-232 transceiver with available flow control signaling
- RS-485 transceiver with optional isolation and PROFIBUS capability
- Dual CAN transceivers
- Analog signals accessible via screw terminals: 3x ADC, 1x DAC, VDDA, VSSA
- Digital signals accessible via LEDs and thru-hole points: 6x PWM, 3x timer
- Signal jumpers to allow isolation, probing and remapping of interfaces
- Compatible with the TWR-SER to provide access to additional industrial I/O interfaces

Step-by-Step Installation Instructions

1 Configure Jumpers

Configure the TWR-IND-IO jumpers to align with the intended Tower System controller module. Be aware that not all controller modules will provide access to all features available on the TWR-IND-IO. Refer to the Jumper Table in this document for reference and the user manual for additional details regarding the flexibility of this module.

2 Ensure Compatibility

Each interface featured on the TWR-IND-IO is capable of being isolated from the Tower System. To maintain the best compatibility with additional Tower peripheral modules it is recommended that any unused interfaces be isolated.

3 Assemble Your Tower System

Assemble your Tower System, including a Tower System controller module, the TWR-IND-IO peripheral module, and the TWR-ELEV elevator modules. Refer to the assembly instructions provided with the TWR-ELEV modules for correct orientation and assembly of boards. NOTE: The TWR-IND-IO module is intended to be compatible with the TWR-SER serial module, thus expanding the number of available interfaces.



4 Refer to Additional Materials

Many existing MQX™ example projects can be adapted to utilize the respective I/O interfaces on the TWR-IND-IO by modifying the “user_config.h” file and recompiling the MQX BSP. Refer to the TWR-IND-IO user manual and the latest MQX release notes for details. Refer to the TWR-IND-IO page on freescale.com/Tower for additional information and example application projects for select Tower System controller modules.

TWR-IND-IO Jumper Options

The following is a list of all jumper options. The default installed jumper settings are shown in white text within the black boxes.

Jumper	Option	Setting	Description
J3	LED Enable for Digital Signal Block A (3x PWM)	1-2	Provides power to the associated LEDs, remove to isolate PWM signals or to use JP1 - JP3
J4	LED Enable for Digital Signal Block B (3x PWM)	1-2	Provides power to the associated LEDs, remove to isolate PWM signals or to use JP4 - JP6
J5	LED Enable for Digital Signal Block C (3x Timer)	1-2	Provides power to the associated LEDs, remove to isolate timer signals or to use JP7 - JP9
J6	Voltage I/O selection	1-2	5V interface between MCU and transceivers
		2-3	3.3V interface between MCU and transceivers
J7	USB2SER RTS/CTS	1-2	Provides a loopback of RTS/CTS, remove to allow access to RTS and CTS
J9	USB2SER TX/RX	1-2	Connects UART0 TX to USB2SER RX. Pin 1 - UART0 TX, Pin 2 - USB2SER RX
		3-4	Connects UART0 RX to USB2SER TX. Pin 3 - UART0 RX, Pin 4 - USB2SER TX
J13	CAN1 Termination Enable	1-2	Enables 121 Ohm termination between CANH and CANL
J14	CAN2 Termination Enable	1-2	Enables 121 Ohm termination between CANH and CANL
J15	CAN Isolation Jumpers	1-2	Connects CAN1_TX to TXD on CAN transceiver associated with J11
		3-4	Connects CAN1_RX to RXD on CAN transceiver associated with J11
		5-6	Connects CAN1_TX to TXD on CAN transceiver associated with J12
		7-8	Connects CAN1_RX to RXD on CAN transceiver associated with J12

TWR-IND-IO Jumper Options continued

The following is a list of all jumper options. The default installed jumper settings are shown in white text within the black boxes.

Jumper	Option	Setting	Description
J16	UART3 Isolation/Access Jumpers	1-2	Connects UART3_TX to T1IN on RS-232 transceiver associated with J17
		3-4	Connects UART3_RX to R1OUT on RS-232 transceiver associated with J17
		5-6	Connects UART3_RTS to T2IN on RS-232 transceiver associated with J17
		7-8	Connects UART3_CTS to R2OUT on RS-232 transceiver associated with J17
J18	UART3 RTS/DCD Loopback	1-2	Provides a loopback of RTS to DCD on UART3
		2-3	Provides a pulldown on UART3 DCD
J19	UART2 RTS/DCD Loopback	1-2	Provides a loopback of RTS to DCD on UART3
		2-3	Provides a pulldown on UART3 DCD
J20	UART2 Isolation/Access Jumpers	1-2	Connects UART2_RX to R on RS-485 transceiver associated with J22/J23
		3-4	Connects UART2_TX to D on RS-485 transceiver associated with J22/J23
		5-6	Connects UART2_RTS to DE on RS-485 transceiver associated with J22/J23
		7-8	Connects UART2_CTS to a pull-down resistor
J21	RS-485 Termination Enable	1-2	Enables 121 Ohm termination between RS-485 A and B

TWR-IND-IO Header Descriptions

The following is a list of all available headers and their descriptions

Header	Description	Pin Details
J2 (J24, J25)	Analog Screw Terminal	1-VDDA, 2-VSSA, 3-DAC0, 4-VSSA, 5-AN1, 6-AN2 7-AN3, 8-VSSA, 9-VDDA
J7	USB2SER RTS/CTS	1-CTS, 2-RTS
J8	UART1	1-TXD1, 2-RXD1, 3-RTS1, 4-CTS1
J11	CAN1 Header	1-CANH, 2-GND, 3-CANL
J12	CAN2 Header	1-CANH, 2-GND, 3-CANL
J17	RS-232 Header	3-TXD, 4-CTS, 5-RXD, 6-RTS, 9-GND (others signals are NC)
J22	RS-485 Screw Terminal (Power)	1-Isolated GND, 2-Isolated VCC, 3-Isolated GND
J23	RS-485 Screw Terminal (Signal)	1-Isolated DE, 2-RS-485 B, 3-RS-485 A

Visit **freescale.com/Tower** for information on the TWR-IND-IO module, including:

- TWR-IND-IO user guide
- TWR-IND-IO schematics
- Tower System fact sheet

Support

Visit **freescale.com/support** for a list of phone numbers within your region.

Warranty

Visit **freescale.com/warranty** for complete warranty information.

For more information, please visit **freescale.com/Tower**
Join the online Tower community at **towergeeks.org**

Freescale and the Freescale logo are trademarks of Freescale semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners. Apple, iPad, iPhone and iPod are trademarks of Apple Inc., registered in the U.S. and other countries.

© 2012 Freescale Semiconductor, Inc.

