



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



XBIB-U-SP

Reference Guide

20 Pin Header
Maps to standard through hole XBEE pins and corresponding SMT pads

SMT XBee Pads

RPSMA Connector
For use with SMT modules with RF pad out

Indicator LEDs
DS5: ON/ SLEEP
DS2: DIO12
DS3: DIO11
DS4: DIO4

Programming Header
Header used to program XBee Programmable modules

Self Power Module
Advanced users only – will void warranty. R31 must be depopulated to power module using V+ and GND from J2 and J5. Sense lines can be connected to S+ and S- for sensing power supplies. **CAUTION:** Voltage not regulated. Applying incorrect voltage can cause fire and serious injury. See Note 1.

SPI
Only used for SMT modules

SPI Power
Connect to power board from 3.3V

Current Testing
Depopulating R31 allows a current probe to be inserted across P6 terminals. The current though P6/R31 powers the module only. Other supporting circuitry is powered by a different trace.

Reset button

Loopback Jumper
Populating P8 with a loopback jumper causes transmissions both from the module and from the USB to loopback.

User Buttons
Connected to DIO lines for user implementation

DC barrel plug: 6-20V
Module can be powered by the USB or DC supply. When plugged in simultaneously the DC supply powers the board.

LED Indicator
Yellow: UART Tx, RF Rx
Green: UART Rx, RF Tx
Red: Associate

USB

RSSI Indicator

NOTE 1: Powering board with J2 and J5 without R31 removed can cause shorts if USB or barrel plug power is connected. Applying too high of a voltage will destroy electronic circuitry in the module and other board components and/or cause injury.

