



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



1.0 INTRODUCTION

This user's manual is for the XR17V358/354 evaluation board revision 3.x. The XR17V358 and XR17V354 are available in the same package and are pin compatible, therefore they share the same evaluation board. This user's manual gives an overview of the evaluation board and the jumper settings for testing various modes using the evaluation board. The ordering information for the XR17V358/354 evaluation board is as following:


ORDERING INFORMATION

| PART NUMBER | DESCRIPTION |
|-------------------|---|
| XR17V354IB-0A-EVB | Single device XR17V354 is installed on the board. |
| XR17V354IB-E4-EVB | Two devices are installed on the board. The master device is XR17V354. The slave device on expansion interface is a XR17V354. |
| XR17V354IB-E8-EVB | Two devices are installed on the board. The master device is XR17V354. The slave device on expansion interface is a XR17V358. |
| XR17V358IB-0A-EVB | Single device XR17V358 is installed on the board. |
| XR17V358IB-E4-EVB | Two devices are installed on the board. The master device is XR17V358. The slave device on expansion interface is a XR17V354. |
| XR17V358IB-E8-EVB | Two devices are installed on the board. The master device is XR17V358. The slave device on expansion interface is a XR17V358. |

2.0 OVERVIEW

This evaluation board has a x1 PCIe connector and will work in any x1, x4 or x16 PCIe slot. Up to 16 UART ports can be tested on this evaluation board when 2 XR17V358 are installed. The PCIe interface of the master device is connected directly to the PCIe connector. The master device communicates with the slave device via Exar's proprietary expansion interface. The PCIe interface on the slave device is not used.

FIGURE 1. PCIe AND EXPANSION INTERFACE



XR17V358/354 EVALUATION BOARD USER'S MANUAL
2.1 Evaluation Board Components for Master Device

The table below shows all of the components that are on the evaluation board for the master device.

TABLE 1: COMPONENTS OF THE XR17V358 EVALUATION BOARD FOR MASTER DEVICE

| UNIT | PART | FUNCTION |
|------|------------------------------------|--|
| U2 | XR17V358IB176-F XR17V354IB176-F | XR17V358 or XR17V354 PCIe UART master device. |
| U16 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 0. |
| U11 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 1. |
| U25 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 2. |
| U24 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 3. |
| U28 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 4. |
| U27 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 5. |
| U17 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 6. |
| U22 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 7. |
| U6 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART RI# signals channels 0-3. |
| U13 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART RI# signals channels 4-7. |
| U9 | SP3497EEN-L | Exar RS-485 Transceiver for master device UART channel 4. Not installed. |
| U10 | SP3497EEN-L | Exar RS-485 Transceiver for master device UART channel 5. Not installed. |
| U21 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for master device UART channel 3 and 4 for RS-485 full-duplex testing. Not installed. |
| U3 | HSDL2300 | IR Transceiver. Not installed. |
| U26 | 93C46 (PDIP) | External EEPROM for storing Vendor ID and Device ID. Not installed. |
| U30 | 93C46 (TSSOP) | External EEPROM for storing Vendor ID and Device ID. Installed, not programmed. |

2.2 Evaluation Board Components for Slave Device

The table below shows all of the components that are on the evaluation board for the slave device. If the slave device is not installed, then these components will also not be installed.

TABLE 2: COMPONENTS OF THE XR17V358 EVALUATION BOARD FOR SLAVE DEVICE

| UNIT | PART | FUNCTION |
|------|------------------------------------|--|
| U1 | XR17V358IB176-F XR17V354IB176-F | XR17V358 or XR17V354 PCIe UART slave device. |
| U5 | SP3245EEA-L | Exar RS-232 Transceiver for slave device UART channel 0. |
| U4 | SP3245EEA-L | Exar RS-232 Transceiver for slave device UART channel 1. |
| U8 | SP3245EEA-L | Exar RS-232 Transceiver for slave device UART channel 2. |

TABLE 2: COMPONENTS OF THE XR17V358 EVALUATION BOARD FOR SLAVE DEVICE

| UNIT | PART | FUNCTION |
|------|-------------|---|
| U7 | SP3245EEA-L | Exar RS-232 Transceiver for slave device UART channel 3. |
| U15 | SP3245EEA-L | Exar RS-232 Transceiver for slave device UART channel 4. |
| U14 | SP3245EEA-L | Exar RS-232 Transceiver for slave device UART channel 5. |
| U19 | SP3245EEA-L | Exar RS-232 Transceiver for slave device UART channel 6. |
| U20 | SP3245EEA-L | Exar RS-232 Transceiver for slave device UART channel 7. |
| U12 | SP3497EEN-L | Exar RS-485 Transceiver for slave device UART channel 4. |
| U18 | SP3497EEN-L | Exar RS-485 Transceiver for slave device UART channel 5. |
| U23 | SP336EEY-L | Exar RS-232/RS-485 Transceiver for slave device UART channel 3 and 4 for RS-485 full-duplex testing. Not installed. |

2.3 Jumper Settings for Power Sources for Master Device

The following table shows the jumper settings for selecting/enabling the power source for the Master Device.

TABLE 3: JUMPER SETTINGS FOR POWER SOURCES FOR MASTER DEVICE

| JUMPER | FUNCTIONS | COMMENTS |
|--------|--|--|
| J45 | 3.3V supply voltage for the 3.3V Core | Not installed. Trace between 1&2. |
| J42 | Enables/Disables Internal Buck Regulator | Jumper is not in - Internal buck regulator is enabled (default). |
| J66 | 3.3V supply voltage for the output stage of buck regulator | Not installed. Trace between 1&2. |
| J63 | 3.3V supply voltage for analog blocks of buck regulator | Not installed. Trace between 1&2. |
| J62 | 1.2V regulated voltage from internal buck | Not installed. Trace between 1&2. |
| J67 | 1.2V supply voltage for 1.2V PHY | Not installed. Trace between 1&2. |
| J56 | 1.2V supply voltage for 1.2V Core | Not installed. Trace between 1&2. |

2.4 Jumper Settings for Power Sources for Slave Device

The following table shows the jumper settings for selecting/enabling the power source for the Slave Device.

TABLE 4: JUMPER SETTINGS FOR POWER SOURCES FOR SLAVE DEVICE

| JUMPER | FUNCTIONS | COMMENTS |
|--------|--|--|
| J32 | 3.3V supply voltage for the 3.3V Core | Not installed. Trace between 1&2. |
| J31 | Enables/Disables Internal Buck Regulator | Jumper is not in - Internal buck regulator is enabled (default). |
| J68 | 3.3V supply voltage for the output stage of buck regulator | Not installed. Trace between 1&2. |
| J65 | 3.3V supply voltage for analog blocks of buck regulator | Not installed. Trace between 1&2. |
| J64 | 1.2V regulated voltage from internal buck | Not installed. Trace between 1&2. |
| J70 | 1.2V supply voltage for 1.2V PHY | Not installed. Trace between 1&2. |
| J34 | 1.2V supply voltage for 1.2V Core | Not installed. Trace between 1&2. |

XR17V358/354 EVALUATION BOARD USER'S MANUAL

2.5 Jumper/Switch Settings for RS-232 or RS-485 for Master Device

The following table (**Table 5**) shows the setting for selecting between the RS-232 or RS-485 modes for the master device. The Half-duplex RS-485 mode can be enabled by either setting the FCTR bit-5 to 1 or connecting the EN485# pin to GND.

TABLE 5: SETTINGS FOR RS-232 OR RS-485 MODE FOR MASTER DEVICE


| JUMPERS/ SWITCH | FUNCTIONS | COMMENTS |
|--------------------|---|--|
| J13 | 3.3V Supply voltage pin for transceivers | Not installed. Trace between 1&2. |
| J41 | Enable Auto RS-485 Half-Duplex Direction Control upon power-up | Jumper between 1&2 enables this feature for all 8 channels. This feature can be disabled in the software after power-up. |
| J54 | Enable IR mode upon power-up | Jumper between 1&2 enables this feature for all 8 channels. This feature can be disabled in the software after power-up. |
| SW5 | Indicate whether slave device is presented or not. <div style="text-align: center;">  <p>SW5</p> <p>OFF ON</p> <p>1 2 3 4 5 6 7 8</p> <p>Default for "0A-EVB"</p> </div> | Slave is not present (default for "0A-EVB" board). <ul style="list-style-type: none"> ■ Position 1 = OFF Slave is present (default for "Ex-EVB" board). <ul style="list-style-type: none"> ■ Position 1 = ON Position 2, Position 3, Position 4, Position 5, Position 6, Position 7, and Position 8 are for internal use only. They should be set as OFF status (default). |

TABLE 5: SETTINGS FOR RS-232 OR RS-485 MODE FOR MASTER DEVICE



| JUMPERS/ SWITCH | FUNCTIONS | COMMENTS |
|--------------------|---|---|
| SW1 | <p>Selects between RS-232 and half-duplex RS-485 mode for UART channels 0 and 1</p> <div style="text-align: center;">  <p>SW 1</p> <p>OFF ON</p> <p>1 2 3 4 5 6 7 8</p> <p>RS-232 Mode (Default)</p> </div> | <p>UART channel 0 RS-232 Mode (default)</p> <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = OFF ■ Position 3 = ON ■ Position 4 = ON <p>UART channel 0 half-duplex RS-485 Mode</p> <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = ON ■ Position 3 = OFF ■ Position 4 = ON <p>UART channel 1 RS-232 Mode (default)</p> <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = ON ■ Position 7 = OFF ■ Position 8 = OFF <p>UART channel 1 half-duplex RS-485 Mode</p> <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = OFF ■ Position 7 = ON ■ Position 8 = OFF |
| SW4 | <p>Selects between RS-232 and half-duplex RS-485 mode for UART channels 2 and 3</p> <div style="text-align: center;">  <p>SW4</p> <p>OFF ON</p> <p>1 2 3 4 5 6 7 8</p> <p>RS-232 Mode (Default)</p> </div> | <p>UART channel 2 RS-232 Mode (default)</p> <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = OFF ■ Position 3 = ON ■ Position 4 = ON <p>UART channel 2 half-duplex RS-485 Mode</p> <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = ON ■ Position 3 = OFF ■ Position 4 = ON <p>UART channel 3 RS-232 Mode (default)</p> <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = ON ■ Position 7 = OFF ■ Position 8 = OFF <p>UART channel 3 half-duplex RS-485 Mode</p> <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = OFF ■ Position 7 = ON ■ Position 8 = OFF |

TABLE 5: SETTINGS FOR RS-232 OR RS-485 MODE FOR MASTER DEVICE




| JUMPERS/ SWITCH | FUNCTIONS | COMMENTS |
|--------------------|---|---|
| SW6 | Selects between RS-232 and half-duplex RS-485 mode for UART channels 4 and 5  | UART channel 4 RS-232 Mode (default) <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = OFF ■ Position 3 = ON ■ Position 4 = ON UART channel 4 half-duplex RS-485 Mode <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = ON ■ Position 3 = OFF ■ Position 4 = ON UART channel 5 RS-232 Mode (default) <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = ON ■ Position 7 = OFF ■ Position 8 = OFF UART channel 5 half-duplex RS-485 Mode <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = OFF ■ Position 7 = ON ■ Position 8 = OFF |
| SW3 | Selects between RS-232 and half-duplex RS-485 mode for UART channels 6 and 7  | UART channel 6 RS-232 Mode (default) <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = OFF ■ Position 3 = ON ■ Position 4 = ON UART channel 6 half-duplex RS-485 Mode <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = ON ■ Position 3 = OFF ■ Position 4 = ON UART channel 7 RS-232 Mode (default) <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = ON ■ Position 7 = OFF ■ Position 8 = OFF UART channel 7 half-duplex RS-485 Mode <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = OFF ■ Position 7 = ON ■ Position 8 = OFF |

TABLE 5: SETTINGS FOR RS-232 OR RS-485 MODE FOR MASTER DEVICE

| JUMPERS/ SWITCH | FUNCTIONS | COMMENTS |
|--------------------|---|---|
| SW2 | <p>Enables the RI# signals in RS-232 mode for UART channels 0-7</p> <div style="text-align: center;">  <p>SW2</p> <p>OFF ON</p> <p>1 2 3 4 5 6 7 8</p> <p>RS-232 Mode (Default)</p> </div> | <p>UART channel 0 RS-232 Mode (default)</p> <ul style="list-style-type: none"> ■ Position 1 = OFF ■ Position 2 = OFF ■ Position 3 = ON ■ Position 4 = ON <p>UART channel 1 RS-232 Mode (default)</p> <ul style="list-style-type: none"> ■ Position 5 = ON ■ Position 6 = ON ■ Position 7 = OFF ■ Position 8 = OFF |
| J14 | <p>Half-Duplex RS-485 control select for DE for UART channel 3</p> <p>Note: SP3497E is not installed.</p> | <ul style="list-style-type: none"> ■ No jumper installed enables RS-485 driver ■ Jumper between 2&3 selects RTS# as the half-duplex control output ■ Jumper between 1&2 disables the RS-485 driver |
| J17 | <p>Half-Duplex RS-485 control select for RE# for UART channel 3</p> <p>Note: SP3497E is not installed.</p> | <ul style="list-style-type: none"> ■ No jumper installed disables RS-485 receiver ■ Jumper between 1&2 enables the RS-485 receiver ■ Jumper between 2&3 selects RTS# as the half-duplex control output |
| J10 | <p>Half-Duplex RS-485 control for transmitter and receiver for UART channel 3</p> <p>Note: SP3497E is not installed.</p> | <ul style="list-style-type: none"> ■ Not installed |
| J16 | <p>Half-Duplex RS-485 control select for DE for UART channel 4</p> <p>Note: SP3497E is not installed.</p> | <ul style="list-style-type: none"> ■ No jumper installed enables RS-485 driver ■ Jumper between 2&3 selects RTS# as the half-duplex control output ■ Jumper between 1&2 disables the RS-485 driver |
| J19 | <p>Half-Duplex RS-485 control select for RE# for UART channel 4</p> <p>Note: SP3497E is not installed.</p> | <ul style="list-style-type: none"> ■ No jumper installed disables RS-485 receiver ■ Jumper between 1&2 enables the RS-485 receiver ■ Jumper between 2&3 selects RTS# as the half-duplex control output |
| J8 | <p>Half-Duplex RS-485 control for transmitter and receiver for UART channel 4</p> <p>Note: SP3497E is not installed.</p> | <ul style="list-style-type: none"> ■ Not installed |

XR17V358/354 EVALUATION BOARD USER'S MANUAL
2.6 Jumper Settings for RS-232 or RS-485 for Slave Device

The following table shows the setting for selecting between the RS-232 or RS-485 modes for the slave device:

TABLE 6: SETTINGS FOR RS-232 OR RS-485 MODE FOR SLAVE DEVICE

| JUMPERS/ SWITCH | FUNCTIONS | COMMENTS |
|--------------------|---|---|
| J23 | 3.3V supply voltage for RS-232 and RS-485 Transceivers for the slave device | Jumper between 1&2 |
| J29 | Enable Auto RS-485 Half-Duplex Direction Control upon power-up | Jumper between 1&2 enables this feature for all 8 channels. This feature can be disabled in the software after power-up. |
| J37 | Enable IR mode upon power-up | Jumper between 1&2 enables this feature for all 8 channels. This feature can be disabled in the software after power-up. |
| J15 | Half-Duplex RS-485 control select for DE for UART channel 3 Note: SP3497E is not installed. | <ul style="list-style-type: none"> ■ No jumper installed enables RS-485 driver ■ Jumper between 2&3 selects RTS# as the half-duplex control output ■ Jumper between 1&2 disables the RS-485 driver |
| J18 | Half-Duplex RS-485 control select for RE# for UART channel 3 Note: SP3497E is not installed. | <ul style="list-style-type: none"> ■ No jumper installed disables RS-485 receiver ■ Jumper between 1&2 enables the RS-485 receiver ■ Jumper between 2&3 selects RTS# as the half-duplex control output |
| J12 | Half-Duplex RS-485 control for transmitter and receiver for UART channel 3 Note: SP3497E is not installed. | <ul style="list-style-type: none"> ■ Not installed |
| J24 | Half-Duplex RS-485 control select for DE for UART channel 4 Note: SP3497E is not installed. | <ul style="list-style-type: none"> ■ No jumper installed enables RS-485 driver ■ Jumper between 2&3 selects RTS# as the half-duplex control output ■ Jumper between 1&2 disables the RS-485 driver |
| J28 | Half-Duplex RS-485 control select for RE# for UART channel 4 Note: SP3497E is not installed. | <ul style="list-style-type: none"> ■ No jumper installed disables RS-485 receiver ■ Jumper between 1&2 enables the RS-485 receiver ■ Jumper between 2&3 selects RTS# as the half-duplex control output |
| J25 | Half-Duplex RS-485 control for transmitter and receiver for UART channel 4 Note: SP3497E is not installed. | <ul style="list-style-type: none"> ■ Not installed |

2.7 Pinout for connectors

The RS232 signals on the evaluation board goes to the SCSI type ultra micro DB68 connector. Figure 2 shows the DB68 connector on the board. Table 7 shows the pinout.

FIGURE 2. DB68 CONNECTOR




TABLE 7: PINOUT FOR THE DB68

| PIN NUMBER | SIGNAL NAME | PIN NUMBER | SIGNAL NAME | PIN NUMBER | SIGNAL NAME | PIN NUMBER | SIGNAL NAME |
|------------|-------------|------------|-------------|------------|-------------|------------|-------------|
| 1 | RXD7 | 18 | RXD3 | 35 | RXD8 | 52 | RXD4 |
| 2 | CT7 | 19 | CT3 | 36 | CT8 | 53 | CT4 |
| 3 | RIN7 | 20 | RIN3 | 37 | RIN8 | 54 | RIN4 |
| 4 | RT7 | 21 | RT3 | 38 | RT8 | 55 | RT4 |
| 5 | DCD7 | 22 | DCD3 | 39 | DCD8 | 56 | DCD4 |
| 6 | DT7 | 23 | DT3 | 40 | DT8 | 57 | DT4 |
| 7 | DS7 | 24 | DS3 | 41 | DS8 | 58 | DS4 |
| 8 | TXD7 | 25 | TXD3 | 42 | TXD8 | 59 | TXD4 |
| 9 | GND | 26 | GND | 43 | GND | 60 | GND |
| 10 | TXD5 | 27 | TXD1 | 44 | TXD6 | 61 | TXD2 |
| 11 | DS5 | 28 | DS1 | 45 | DS6 | 62 | DS2 |
| 12 | DT5 | 29 | DT1 | 46 | DT6 | 63 | DT2 |
| 13 | DCD5 | 30 | DCD1 | 47 | DCD6 | 64 | DCD2 |
| 14 | RT5 | 31 | RT1 | 48 | RT6 | 65 | RT2 |
| 15 | RIN5 | 32 | RIN1 | 49 | RIN6 | 66 | RIN2 |
| 16 | CT5 | 33 | CT1 | 50 | CT6 | 67 | CT2 |
| 17 | RXD5 | 34 | RXD1 | 51 | RXD6 | 68 | RXD2 |

XR17V358/354 EVALUATION BOARD USER'S MANUAL

Figure 3 shows the DB9 connector. Table 8 shows the DB9 connector pinout.

FIGURE 3. DB9 CONNECTOR




TABLE 8: DB9 CONNECTOR PINOUT

| PIN NUMBER | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|------------|------|------|------|-----|-----|-----|-----|-----|------|
| SIGNAL | DCDx | RXDx | TXDx | DTx | GND | DSx | RTx | CTx | RINx |

2.8 MPIO pins

The MPIO pins of the both the master and slave devices are connected to LEDs or test points on the evaluation board. Refer to page 6 of the evaluation board schematic for details.

3.0 DRIVERS

Software drivers for Windows and Linux are available from Exar. Send an e-mail with your driver request to uarttechsupport@exar.com.

NOTICE

EXAR Corporation reserves the right to make changes to the products contained in this publication in order to improve design, performance or reliability. EXAR Corporation assumes no responsibility for the use of any circuits described herein, conveys no license under any patent or other right, and makes no representation that the circuits are free of patent infringement. Charts and schedules contained here in are only for illustration purposes and may vary depending upon a user's specific application. While the information in this publication has been carefully checked; no responsibility, however, is assumed for inaccuracies.

EXAR Corporation does not recommend the use of any of its products in life support applications where the failure or malfunction of the product can reasonably be expected to cause failure of the life support system or to significantly affect its safety or effectiveness. Products are not authorized for use in such applications unless EXAR Corporation receives, in writing, assurances to its satisfaction that: (a) the risk of injury or damage has been minimized; (b) the user assumes all such risks; (c) potential liability of EXAR Corporation is adequately protected under the circumstances.

Copyright 2011 EXAR Corporation

Datasheet June 2011.

Send your UART technical inquiry with technical details to hotline: uarttechsupport@exar.com.

Reproduction, in part or whole, without the prior written consent of EXAR Corporation is prohibited.