



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



Displacement Sensor

ZW series

## Confocal Fiber Type Displacement Sensor

User's Manual

ZW-C1□ T



# Introduction

---

Thank you for purchasing the ZW.

This manual provides information regarding functions, performance and operating methods that are required for using the ZW.

When using the ZW, be sure to observe the following:

- The ZW must be operated by personnel knowledgeable in electrical engineering.
- To ensure correct use, please read this manual thoroughly to deepen your understanding of the product.
- Please keep this manual in a safe place so that it can be referred to whenever necessary.

# User's Manual

APPLICATION CONSIDERATIONS  
(Please Read)

Basic configuration

1

Installation and Connections

2

Basic Operation

3

Settings for Function

4

Convenient Functions

5

Communications with External Devices

6

Offline Settings

7

Troubleshooting

8

Sensor controller operations

9

APPENDICES

10

Confocal Fiber Type  
Displacement Sensor

ZW

## **READ AND UNDERSTAND THIS DOCUMENT**

Please read and understand this document before using the products. Please consult your OMRON representative if you have any questions or comments.

## **WARRANTY**

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

## **LIMITATIONS OF LIABILITY**

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

## **SUITABILITY FOR USE**

THE PRODUCTS CONTAINED IN THIS DOCUMENT ARE NOT SAFETY RATED. THEY ARE NOT DESIGNED OR RATED FOR ENSURING SAFETY OF PERSONS, AND SHOULD NOT BE RELIED UPON AS A SAFETY COMPONENT OR PROTECTIVE DEVICE FOR SUCH PURPOSES.

Please refer to separate catalogs for OMRON's safety rated products.

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the product.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.

- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

## **PERFORMANCE DATA**

Performance data given in this document is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

## **CHANGE IN SPECIFICATIONS**

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the product may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

## **DIMENSIONS AND WEIGHTS**

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

## **ERRORS AND OMISSIONS**

The information in this document has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

## **PROGRAMMABLE PRODUCTS**

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

## **COPYRIGHT AND COPY PERMISSION**

This document shall not be copied for sales or promotions without permission.

This document is protected by copyright and is intended solely for use in conjunction with the product. Please notify us before copying or reproducing this document in any manner, for any other purpose. If copying or transmitting this document to another, please copy or transmit it in its entirety.

# Precautions for Safe Use

Please observe the following precautions for safe use of the products.

## 1. Installation Environment

- Do not use the product in environments where it can be exposed to inflammable/explosive gas.
- To secure the safety of operation and maintenance, do not install the product close to high-voltage devices and power devices.

## 2. Power Supply and Wiring

- Take care when using a power supply with an overcurrent detector, because this sensor uses DC-DC converter for its power supply circuit and inrush current may activate the protective circuit for a power supply with an overcurrent detector.

Recommended power supply: S8VS-06024 (Omron, DC24 V 2.5 A 60 W)

- The supply voltage must be within the rated range (DC24 V  $\pm$  10 %).
- Reverse connection of the power supply is not allowed.
- Open-collector outputs should not be short-circuited.
- Use the power supply within the rated load.
- High-voltage lines and power lines must be wired separately from this product. Wiring them together or placing them in the same duct may cause induction, resulting in malfunction or damage.
- Use adequate safety measures, for example fail-safe circuits.
- Use a specified-sized wire when wiring. Do not connect wires other than those of the specification to the terminal block.
- For a power supply, use a DC power supply unit provided with a remedy, for example, safety ultralow voltage circuit, to prevent a high voltage from being generated.
- Route so that power supply wires are as short as possible.
- Use a power supply dedicated for this product, without sharing it with other products.
- Tighten fixing screws securely at a torque specified in this manual.
- Before performing any of the following activities, be sure to turn off the product, or breakdown may result.
  - Connecting or wiring cables
  - Connecting or disconnecting connectors
  - Installing or removing Calibration ROM


## 3. Grounding

- Use a frame ground terminal of the specified size to be grounded. Do not connect a wire with an only twisted end directly to a terminal block.
  - Terminal screw: M4
  - Crimp-type terminal:



- Use D-type grounding (ground resistance of 100  $\Omega$  or less). Make the ground point as close as possible and make the ground wire used as short as possible.
- Never a ground wire with other equipment and never ground to building beams. Doing so could cause negative impacts.
- The power supply circuit of the Sensor Controller is not insulated from the internal circuits.
- When grounding the positive (+) terminal of the 24 VDC power supply, do not connect the Sensor Controller's frame ground terminal or PLC's frame ground terminal to ground. [(1), (2)]  
The PC housing may be internally connected to the SG (0 V), in which case current will flow through the path shown below and may cause seizure.

- If there is no PC, or specifically there is no SG (0 V)/FG short-circuiting path, grounding the Sensor Controller's frame ground terminal will not cause seizure. Wire the PLC after checking the specification of your PLC.
- The dedicated RS-232C cable (ZW-XRS2/XPT2) has its cable shield isolated from the connector housing. [(3)]



#### 4. Regulations and Standards

- EN61326-1
- Electromagnetic environment : Industrial electromagnetic environment (EN/IEC 61326-1 Table 2)
- The following condition is applied to the immunity test of this product:  
There may be cases that current or voltage output fluctuate within  $\pm 3\%F.S.$  when a sensor is experienced electromagnetic interference.

#### • Notice for Korea Radio Law

A 급 기기 (업무용 방송통신기자재)  
이 기기는 업무용 ( A 급 ) 전자파적합기기로서 판매자  
또는 사용자는 이 점을 주의하시기 바라며 , 가정외의  
지역에서 사용하는 것을 목적으로 합니다.

#### 5. Others

- Do not use this product for nuclear facilities, or safety circuits involving human lives.
- Do not attempt to disassemble, repair, modify, apply pressure to deform or burn up the body.
- Dispose of this product as industrial waste.
- Use exclusive devices, including a sensor head, Calibration ROM, fiber cable or RS-232C cable, to connect, or ignition, burst, false operation or breakdown may be caused.
- Do not cut fiber cable. Glass at the cut section may cause injury. Also, if cut, it will not work normally anymore.
- Whenever any trouble, including, strange odor smelled, the body overheated or smoke escaped, was found, immediately stop the operation, and consult an OMRON branch or sales office with the system shut down.
- Do not drop or make a strong impact on the unit.
- Before using any equipment provided with a lock mechanism, make sure that it has been locked.



## Precautions for Correct Use

Please observe the following precautions to prevent failure to operate, malfunctions, or undesirable effects on product performance.

### 1. Installation Site

Do not install the product in locations subjected to the following conditions:

- Ambient temperature outside the rating
- Rapid temperature fluctuations (causing condensation)
- Relative humidity outside the range of 35 to 85 %
- Presence of corrosive or flammable gases
- Presence of dust, salt, or iron particles
- Direct vibration or shock
- Reflection of intense light (such as other laser beams, electric arc-welding machines or ultraviolet shine)
- Direct sunlight or near heaters
- Water, oil, or chemical fumes, spray or mist atmospherics
- Strong magnetic or electric field

### 2. Power Supply and Wiring

- When using a commercially available switching regulator, make sure that the FG terminal is grounded.
- If surge currents are present in the power lines, connect surge absorbers that suit the operating environment.
- Before turning ON the power after the product is connected, make sure that the power supply voltage is correct, there are no incorrect connections (e.g. load short-circuit) and the load current is appropriate. Incorrect wiring may result in breakdown of the product.
- Use the specified voltage. If voltage exceeding the rating or AC voltage is applied, circuit parts may be burnt or rupture.
- Use the Extension Fiber Cable (ZW-XF□□R) for extending the fiber cable between the Sensor extension fiber cable, five total lengths, 2, 5, 10, 20 or 30 m, are available.
- Handling fiber cables  
Use them in compliance with the following. This may result in damage to the fiber cable.
  - Fiber cable bend radiuses must be at least 20 mm.
  - Do not let bending cause stress at the root section of a fiber connector.
  - Do not yank hard on a fiber cable.
  - Do not step on a fiber cable or place anything heavy on it.
  - Do not apply any twisting stress to the fiber cable.
- Be sure to use a Sensor Head and Calibration ROM with the same serial number. A pair with different serial numbers cannot operate normally.
- Use the configuration software with the combination specified in this manual, or the system may operate faultily.
- Do not shut down the power supply when saving any data into the memory built in the Sensor Controller, or the data may be corrupted.
- While a fiber cable is disconnected, be sure to attach the included protective cap on both the Sensor Controller side and the fiber cable side. Leaving the fiber cable with the protective cap not attached, the optical fiber may fail due to any adhered foreign matter.

### 3. Warming Up

After turning ON the power supply, allow the product to stand for at least 30 minutes before use. The circuits are still unstable immediately after the power supply is turned ON, so measured values may fluctuate gradually.

#### 4. Maintenance and Inspection

Do not use thinner, benzene, acetone or kerosene to clean the Sensor Head, fiber cable and Sensor Controller. If large dust particles adhere to the emitter/receiver of the Sensor Head or Sensor Controller, use a blower brush (used to clean camera lenses) to blow them off. Do not blow the dust particles with your mouth.

To remove smaller dust particles, dirt, oil, and fat, wipe gently with a soft cloth (for cleaning lenses). Do not use excessive force to wipe off dust particles. Scratches on the emitter/receiver may cause false operations or measuring errors.

For details on the method for cleaning the ends of fiber cables, refer to "Connecting Fiber Cable" (p.34).


Clean the ventilation port periodically to prevent any build up of dirt and dust. If the ventilation port is blocked, heat builds up inside and can cause breakdown.

#### 5. Sensing Objects

The product sometimes cannot accurately measure the following types of objects: Transparent objects, objects with an extremely low reflection factor, objects smaller than the spot diameter, objects with a large curvature, excessively inclined objects, target objects with a thin film on the surface etc.

#### 6. Effect caused by peripheral lights

Do not install the Sensor Head in a place where strong light hits the laser emitter/receiver section of the Sensor Head. Also, if an object has a shiny surface, the light from the lighting will be reflected and a malfunction may occur. In such a case, prevent reflection by, for example, covering the light to stop reflection.

 Basic precautions for installation p.26

#### 7. Influence by Air Turbulences

Slow air turbulences around the Sensor Head may disperse measured values.

To avoid these possible air turbulences, wrap the Sensor Head with an appropriate cover.

#### 8. Operations Outside Measurement Range

This sensor is highly sensitive, it may operate incorrectly outside the measurement range (too close in). In such a case, the problem can be solved by reducing the exposure time.

### Editor's Note

#### ■ Meaning of Symbols

Menu items that are displayed on the main or sub-display, and windows, dialog boxes and other GUI elements displayed on the personal computer are indicated enclosed by brackets [ ].

#### ■ Visual Aids

##### Important

Indicates points that are important to achieve the full product performance, such as operational precautions.

##### Note

Indicates application procedures.



Indicates pages where related information can be found.

##### Optional

Indicates that the setting is optional in a configuration procedure.

## Copyrights and Trademarks

- Windows, Windows XP, Windows Vista, Windows 7, and Windows 8 are registered trademarks of Microsoft Corporation in the USA and other countries.
- Other system names and product names that appear in this manual are the trademarks or registered trademarks of the respective companies.

## Notice

- Photocopying, duplication, or copying of all or part of this manual without permission is prohibited.
- Please understand that the specifications and other contents of this manual are subject to change for improvement without notice.
- Every effort has been made to ensure the accuracy of the contents of this manual, but if you should notice any mistake, questionable section, or the like in this manual, please contact an OMRON branch or sales office.
- If you do so, please also tell us the manual number, which is found at the end of the manual.

# Table of Contents

Editor's Note .....	7
Copyrights and Trademarks .....	8
Notice .....	8
<b>Search from Settings .....</b>	<b>14</b>

## 1. Basic configuration

<b>1-1 ZW-series Displacement Sensors .....</b>	<b>16</b>
Types of Sensor Controllers .....	16
<b>1-2 Basic Operation Flow .....</b>	<b>17</b>

## 2. Installation and Connections

<b>2-1 System Configuration .....</b>	<b>20</b>
System Configuration .....	20
Connection Compatibility .....	21
<b>2-2 Part Names and Functions .....</b>	<b>22</b>
Sensor Head .....	22
Calibration ROM .....	22
Sensor Controller .....	23
<b>2-3 Installation .....</b>	<b>26</b>
Installation of Sensor Head .....	26
Installation of Sensor Controller .....	31
Connecting Calibration ROM .....	33
Connecting Fiber Cable .....	34
Calibrating Sensor Head .....	38
<b>2-4 Wiring .....</b>	<b>40</b>
20-pole terminal block .....	40
52-pole extension connector .....	43
Electrical Specifications .....	46
<b>2-5 Installing the Sysmac Studio .....</b>	<b>48</b>

## 3. Basic Operation

<b>3-1 Launching a project .....</b>	<b>50</b>
Connecting to the sensor with PC tool .....	50
Entering project information .....	51
<b>3-2 Explanation of Screen Sections .....</b>	<b>52</b>

PC tool .....	52
<b>3-3 Switching operation modes .....</b>	<b>57</b>
<b>3-4 Bank switching .....</b>	<b>58</b>
Multi-task and Bank Data .....	58
Switching Banks .....	60
<b>3-5 Perform the Zero Reset .....</b>	<b>61</b>
Zero reset .....	61
<b>3-6 Setting Threshold Value .....</b>	<b>64</b>
Threshold Value Settings .....	64
<b>3-7 Saving a project .....</b>	<b>66</b>
Saving a project .....	66
Exporting a project .....	66
Importing a project .....	66
<b>3-8 Operating with Sensor Controller .....</b>	<b>67</b>

## 4.Settings for Function

<b>4-1 Setting Sensing .....</b>	<b>70</b>
Selecting the Area Mode .....	70
Setting the Material of the Target to Measure .....	71
Setting the Noise Cut Level .....	72
Setting Smoothing Size .....	73
Setting Start Direction of Count Measurement Surfaces .....	74
Setting Exposure Time Control Mode .....	75
Setting the Measurement Area .....	76
<b>4-2 Setting Measurement Items .....</b>	<b>79</b>
What is a Measurement Item? .....	79
Measuring the Height .....	79
Measuring the Thickness .....	81
Performing Calculations .....	82
<b>4-3 Setting the Output Conditions .....</b>	<b>83</b>
Setting Scaling .....	83
Setting Filters .....	89
Setting Hold .....	94
Setting the Zero Reset .....	101
<b>4-4 Setting the Banks .....</b>	<b>106</b>
Changing the Bank Mode .....	106
Copying the Bank/System Settings .....	107
Saving the Bank/System Settings .....	108
Clearing the Bank Settings .....	109
<b>4-5 Setting the System .....</b>	<b>110</b>
Checking Information .....	110
Making Sensor Settings .....	111

Initializing Settings . . . . . 112

## 5. Convenient Functions

**5-1 Displaying measured values in graphs. . . . . 116**  
    Specifying the sampling start and end conditions . . . . . 118  
    Starting and ending sampling before and after the trigger condition is met . . 120

**5-2 Saving measured values in a file. . . . . 121**  
    Outputting the results of sampling as a file . . . . . 121  
    Exporting the results of sampling . . . . . 121

**5-3 Displaying saved measured values. . . . . 124**

**5-4 Performing internal logging. . . . . 125**

**5-5 Storing the light reception wave form in a file . . . . . 127**

**5-6 Recovering calibration ROM data . . . . . 129**

**5-7 Printing the contents of settings . . . . . 130**

**5-8 Controll input signal with PC tool . . . . . 131**

## 6. Communications with External Devices

**6-1 Parallel I/O connection . . . . . 134**  
    I/O Signal Functions . . . . . 134  
    Settings for Analog Output . . . . . 138  
    Settings for Judgment Output . . . . . 143  
    Settings for Binary Output . . . . . 146  
    Settings for Processing When Measurement Is Not Possible . . . . . 150  
    Settings for Bank Control . . . . . 153  
    Settings for Internal Logging . . . . . 154  
    Timing Chart . . . . . 155

**6-2 No-protocol Connection. . . . . 169**  
    Outline of No-protocol Communications . . . . . 169  
    Setting Up No-protocol Communications . . . . . 170  
    Setting Communications Specifications (RS-232C Communications) . . . . . 173  
    Setting for serial data output after application of measured value . . . . . 174  
    Command List . . . . . 178  
    Command Format . . . . . 180

## 7. Offline Settings

**7-1 Performing Settings Offline . . . . . 204**

**7-2 Starting a Project in Offline Mode . . . . . 205**

**7-3 Changing between Online and Offline . . . . . 206**

## 8. Troubleshooting

**8-1 Error Messages. . . . . 208**

Errors for Ethernet Connection .....	208
Errors Common to All Communication States .....	209
<b>8-2 Troubleshooting .....</b>	<b>210</b>

## 9.Sensor controller operations

<b>9-1 Search from Menu Tree .....</b>	<b>214</b>
FUN Mode Menu .....	214
RUN (run) Mode Menu .....	219
<b>9-2 Functions of Operating Keys .....</b>	<b>220</b>
<b>9-3 Digital Displays .....</b>	<b>221</b>
<b>9-4 Switching operation modes .....</b>	<b>222</b>
<b>9-5 Functions and Operations during Measurement .....</b>	<b>224</b>
Switching the RUN (Run) Mode Display .....	224
<b>9-6 Setting Sensing .....</b>	<b>228</b>
Setting the Material of the Target to Measure .....	228
Setting Start Direction of Count Measurement Surfaces .....	229
Setting Exposure Time Control Mode .....	230
<b>9-7 Setting Measurement Items .....</b>	<b>231</b>
Measuring the Height .....	231
Measuring the Thickness .....	232
Calculating .....	233
<b>9-8 Setting the Output Conditions .....</b>	<b>236</b>
Setting the Filter .....	236
Setting Scaling .....	240
Setting Hold .....	244
Setting the Zero Reset .....	248
<b>9-9 Setting the Banks .....</b>	<b>252</b>
Switching Banks .....	252
Changing the Bank Mode .....	253
Copying the Bank Settings .....	254
Saving the Bank/System Settings .....	255
Clearing the Bank Settings .....	256
<b>9-10 Setting Threshold Value .....</b>	<b>257</b>
Teaching .....	257
Direct .....	259
<b>9-11 Setting the System .....</b>	<b>260</b>
Checking Information .....	260
Setting the Key Lock .....	261
Calibrating Sensor Head .....	262
Initializing Settings .....	263
<b>9-12 Connecting Parallel I/O .....</b>	<b>264</b>
Settings for Analog Output .....	264

Settings for Binary Output .....	268
Settings for Judgment Output .....	271
Settings for Processing When Measurement Is Not Possible .....	273
Setting for Internal Logging .....	275
<b>9-13 Connecting by No-protocol Communications .....</b>	<b>277</b>
Initial Settings for No-protocol Communications .....	277
Setting Communications Specifications (RS-232C Communications) .....	278
Setting Serial Data Output .....	279
Set the delimiter .....	280

## 10.APPENDICES

<b>10-1 Specifications and External Dimensions .....</b>	<b>282</b>
Sensor Head .....	282
Sensor controller .....	294
PC tools (Sysmac Studio) .....	298
Accessories .....	299
EMC Directive Conformity .....	303
<b>10-2 Firmware update .....</b>	<b>304</b>
Use PC tools (Sysmac Studio) to update. ....	304
Performing the Update on Warp Engine ZW .....	305
<b>10-3 Processing Item Data List .....</b>	<b>308</b>
<b>10-4 System data list.....</b>	<b>313</b>
<b>Index .....</b>	<b>315</b>
<b>Revision History.....</b>	<b>318</b>



# Search from Settings

Settings	Set by Sysmac Studio	Set by Sensor Controller
Setting the Material for the Target to Measure	p.71	p.228
Setting Exposure Time Control Mode	p.75	p.230
Measuring the Height	p.79	p.231
Measuring the Thickness	p.81	p.232
Calculating	p.82	p.233
Setting the Filter	p.89	p.236
Setting the Scaling	p.83	p.240
Setting the Hold	p.94	p.244
Setting the Zero Reset	p.101	p.248
Changing the Bank Mode	p.106	p.253
Copying the Bank/System Settings	p.107	p.254 (Bank Settings only)
Saving the Bank/System Settings	p.108	p.255
Clearing the Bank Settings	p.109	p.256
Checking Information	p.110	p.260
Setting the Key Lock	p.111	p.261
Initializing Settings	p.112	p.263

# Basic configuration


---

<b>1-1 ZW-series Displacement Sensors .....</b>	<b>16</b>
<b>1-2 Basic Operation Flow .....</b>	<b>17</b>

# 1-1 ZW-series Displacement Sensors

The ZW-series is a line of fiber coaxial displacement sensors.

They consist of Sensor Head and Sensor Controller, calibration ROM, and exclusive setting PC tool which runs on personal computers for system settings and monitoring.




## Types of Sensor Controllers

The ZW Series has two types of Controllers (hereinafter be referred to as "Sensor Controller" in this document.). Differences are described below.


Model	ZW-C1□T/ZW-C1□AT	ZW-CE1□T
I/O Specifications	EtherCAT and EtherNet/IP not mounted, Binary output device mounted	EtherCAT and EtherNet/IP mounted, Binary output device not mounted
PC tool	Sysmac Studio (Measurement Sensor Edition)/ Smart MonitorZW version 1.10 or later	Sysmac Studio (Standard Edition)/ Sysmac Studio (Measurement Sensor Edition)/ Smart MonitorZW version 1.10 or later

# 1-2 Basic Operation Flow

The following is the basic operation flow for ZW Series.



(\*1) After you have made or changed settings, be sure to save the setup data. All set data will be cleared if you turn the power OFF without saving the data.




# Installation and Connections

---

<b>2-1 System Configuration</b> .....	<b>20</b>
<b>2-2 Part Names and Functions</b> .....	<b>22</b>
<b>2-3 Installation</b> .....	<b>26</b>
<b>2-4 Wiring</b> .....	<b>40</b>
<b>2-5 Installing the Sysmac Studio.</b> .....	<b>48</b>

# 2-1 System Configuration

## System Configuration



• (Note1) Ethernet cable (sold separately)  
 Prepare commercially available Ethernet cable satisfying the following requirements:  
 - Category 5e or more, 30 m or less  
 - RJ45 connector (8-pin modular jack)  
 - For direct connection: Select cross cable.  
 - For connection through an industrial switching hub (note 4): Select straight cable.

• Extension fiber cable (optional)  
 A exclusive extension fiber cable is available to place the Sensor Head and Sensor Controller far apart than the normal distance to each other. Use the exclusive product for correct measurements.

Connecting adapter (included with the fiber cable for extension) ZW-XFC  
 Extension fiber cable ZW-XF\_R (2 m/5 m/10 m/20 m/30 m)

• (Note2) RS-232C cable (optional)  
 Depending on connecting devices, exclusive cables may be supplied.

For PLC/programmable terminal: ZW-XPT2  
 For personal computer: ZW-XRS2

• (Note3) Parallel cable (optional)  
 A parallel cable for 52-pole extension connector (ZW-XCP2) with 2 m cable is available.

• (Note 4) Industrial network hub (sold separately)  
 Use the recommended products below:  
 W4S1-0\_ (Omron)

3-port type 5-port type

## Connection Compatibility

Connected to ZW-C1□T	Other connection		
	Ethernet (no-protocol)	RS-232C (no-protocol)	I/O Cable
Ethernet (no-protocol)	---	Compatible	Compatible
Ethernet (programmable no- protocol)	Compatible	---	Compatible

### Important

Can be connected simultaneously via Ethernet with PC tools (Sysmac Studio, SmartMonitorZW) and another device (PLC etc). Can be connected simultaneously via Ethernet with PC tools (Sysmac Studio, SmartMonitorZW) and another device (PLC etc). The port number for the PC tool is fixed to 9600. When connecting different devices, set the port number to other than 9600 (default value is 9601).


Product	Model	Application
ZW	ZW-C1□T	This Displacement Sensor performs measurements.
PC Tool	Sysmac Studio Measurement Sensor Edition • SYSMAC-ME2□□L (1 or 3 licences)	This is the setup application. It is part of the Sysmac Studio Package and it runs on Windows. This license provides the functions that are required to set up ZW Vision Sensors from the Sysmac Studio. This model number is for the license only. You must also purchase the DVD for the Sysmac Studio Standard Edition Ver.1.05 or higher.
General-purpose Ethernet cable	---	Prepare commercially available Ethernet cable satisfying the following requirements: <ul style="list-style-type: none"> <li>• Category 5e or more, 30 m or less</li> <li>• RJ45 connector (8-pin modular jack)</li> <li>• For direct connection: Select cross cable.</li> <li>• For connection through an industrial switching hub: Select straight cable.</li> </ul>
Special I/O Cable	For connecting to a PLC or programmable terminal • ZW-XPT2 For connecting to a PC • ZW-XRS2	Connect the sensor with a PLC, programmable terminal, or personal computer etc..
Industrial Ethernet Switching Hub	• W4S1-03B (3 ports type) • W4S1-05B • W4S1-05C (5 ports type)	Used to connect multiple sensors or PLCs using Ethernet.



## 2-2 Part Names and Functions

The following describes the names and functions of parts of the Sensor Head, Calibration ROM and Sensor Controller.


### Sensor Head



No.	Names	Functions
1	Projector/receiver	Projects and receives light.
2	Serial number.	Serial number. Only a calibration ROM with the same serial number is available.
3	Fiber interface	Interfaces the Sensor Head and optical fiber (unremovable).
4	Fiber Cable	Sends or receives light signals to/from the Sensor Controller.
5	Fiber Connector	Couples the Sensor Controller and fiber cable.

### Calibration ROM

This ROM is associated with the sensor on a one-to-one basis, and operates connected to the Sensor Controller.



No.	Names	Functions
1	Serial number	Serial number. Only a Sensor Head with the same serial number is available.

#### Important

Use with the Calibration ROM always connected. If the Calibration ROM is not connected, an error is displayed.

# Sensor Controller

