mail

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





CAUTION:

- 1. Be sure that all parts of the tool will clear any components on the printed circuit board during use. The force this tool can generate will damage any components placed under it.
- 2. Tape may be placed over circuit traces or on the bottom of the tool standoffs for added protection of the printed circuit board.

OPERATION:

- Turn the lifting knob counter-clockwise (CCW) until half the extraction jaws are exposed below the standoffs. NOTE: The power dock modules are keyed together so that all overlapping modules have to be removed, starting from the end and working back to the defective module.
- Slide the extraction jaws down over the power dock module until the jaws lock into the slots at the base of the module. The jaws must snap into these slots for the tool to work. Center or reposition the jaws on wider modules to pull straight up.
- 3. Turn the lifting knob clockwise until the tool standoffs touch the printed circuit board.
- 4. Continue turning the lifting knob clockwise (CW) until the insulator is removed from the contacts.
- 5. Move the tool away from the board, then turn the tool on its side and remove the insulator.



Molex Application Tooling Group

1150 E. Diehl Road Naperville, IL 60563 Tel: (630) 969-4550 Fax: (630) 505-0049

UNCONTROLLED COPY