

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







IIIIA S H PANAMSE®

MOUNTING LOCATION:

Cubby Below Radio or Climate Control MJC B

TOOLS REQUIRED:

Phillips Screwdriver

HARDWARE INCLUDED:

(2)I-#8x3/4" Needle Pt. Screw (1)A-#8x9/16"Needle Pt. Screw

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **751051106**MFG: **DODGE**

MODELS & YEARS:

Ram Pickup 1500 2006-08 (w/o Nav) Ram 2500 &3500 2006-2009* Chassis Cab 2500,3500,4500 09-10

*(With Cubby Below Radio or Climate Control)

I-751051106

Page 1 of 1

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 Lift up on the rubber pad of the cubby below the climate control. Place InDash by PanaVise Mount in the Cubby. Make sure the face of the mount is facing to the right of the cubby.

STEP #2 Install the (2) screws at the back of the the cubby. Install (1) smaller screw into the hole closer to the openeing of the Cubby.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.







InDash Installed Showing Screws in Place

