



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



INDASH by PANAVISE®

75107-311

Page 1 of 1

MOUNTING LOCATION:
Right side of radio/display J R

CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS

**** ADVISEMENT ****

TOOLS REQUIRED:

Dash Tool, Hook Tool

Phillips Screwdriver

HARDWARE INCLUDED:

(2)-A-#8x9/16" Needle Pt Screw

(2)-O- 8/32" Acorn Nuts (75001)

PART#: 75107-311

MFG: FORD

MODELS & YEARS:

F-150 2009-2012

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Dash tool release the left side of the bezel to right of the Radio, that has the air vents, power outlet, and cubby. Pry with Dash Tool starting at the edge to the left of the cubby to release (1 or 2) clips. Continue up the edge to release as many left side clips as possible. Do not need to remove the bezel completely from the bottom. Just enough to get InDash Mount in place. See picture.

STEP #2: Place the InDash by PanaVise Mount to the left of the power outlet cavity, and it straddles the clip slot and leaves space for the clip to be inserted all the way. Install the (2) screws into the dash with the Phillips Screwdriver.

STEP #3: Sanp the bezel back in place securely. Install the Top part of the InDash by PanaVise Mount (75001) with the (2) Acorn nuts.



Bottom part of InDash installed. Notice clip location.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDash installed showing location



10-23-12

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2002 PanaVise Products, Inc.