

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







IIIIA S H PANAMSE®

MOUNTING LOCATION: Right&Left of Radio Bezel J RL TOOLS REQUIRED:

Phillips Screwdriver 5/16" Socket Driver

HARDWARE INCLUDED

75001 TOP W/(2)-O- 8/32" Acorn Nuts

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **751372007**MFG: **TOYOTA**MODELS & YEARS: **FJ Cruiser 2007-2013**

STEP #1: With Phillips screwdriver, remove (1) screw located at the bottom of the right side end piece that goes from the bottom of the dash to the top. Tilt out end piece from the bottom, and pulling up and out to release a total of (3) clips, with (2) clips at the top.

STEP #2: Remove the (1) Phillips screw from right or left of the radio bezel. Place bottom part #34A part over the screw hole, while tightening the screw apply pressure to set the mount flush to the radio bezel. If after your installation there is a 1/16" + gap, re-tighten screw slightly more to set screw in place better.

STEP#3: Replace the side bezel and screw. Install the InDash by PanaVise Mount top part with the part number on it with the (2) Acorn Nuts provided with 5/16 socket driver.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.

I-751372007

Page 1 of 1

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Lower screw location.



Part #34A prototype in place, right side.



InDash installed showing Right side location.



InDash installed showing Left side location.



02-20-13

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise InDash Applications List: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2002 PanaVise Products, Inc.