



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



INDASH by PANAVISE®

I-75140-106

Page 1 of 1

MOUNTING LOCATION:

Right side of center air vent V R

TOOLS REQUIRED:

Hook tool

Phillips screwdriver, power

HARDWARE INCLUDED:

(3)F- #8x1/2 Phillips PanHead Tap Screw

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 75140-106

MFG: PETERBILT

MODELS & YEARS:

Conventional 2006-2014

365, 367, 379, 384, 386, 388, 389

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With hook tool assist, remove the thin strip below the center air vents and above switches. Start from the right side, lift up to release (3) clips and tilt it out to release lip from left side of strip.

STEP #2: With Phillips screwdriver remove the (2) screws exposed that hold the dash cover in place. With your hands pull on the dash cover to release (4) peg clips. Do not try to remove the plate completely. Pull out only enough to get a power screwdriver in to install the screws.

STEP #3: Place Mount to right side of center air vent. Carefully install (3) supplied self drilling/tapping screws. It is best to use a power drill.

STEP #4: Snap the dash cover back into place. It may be necessary to pull out the clips slightly (1/8" - 1/4") on the trim strip to help it stay in place when it is replaced. Also straightening of the clip lips could help seat the clip better into the dash.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Dash strip



Clip to pull out slightly



InDash installed showing location



InDash fit into location with screw



Location detail



02-20-13