



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



MOUNTING LOCATION:

Upper right side of dash

TOOLS REQUIRED:

Phillips screwdriver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75144-100**

MFG: **WESTERN STAR**

MODELS & YEARS:

SEMI - ALL 1996-2014

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

NOTE: Mounts taken off of older model trucks may need to enlarge the screw hole in mount to fit newer models.

- STEP #1 Remove (2) Phillips screws located on top of the right instrument panel located above the dashboard rocker switches.
- STEP #2 Pull woodgrain panel back approximately 2 inches on top. Panel is hinged on the bottom. Locate air vent at upper right-hand corner of panel.
- STEP #3 Slide InDash mount into right corner position and align outside hole of woodgrain panel hole and reassemble factory Phillips screw through panel and InDash Mount into threaded nut of dash.
- STEP #4 Attach phone holder to Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Final install showing location



02-20-13