



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



INDASH by PANAVISE®

I-75145-201

Page 1 of 1

MOUNTING LOCATION:

Left side of climate control CR

TOOLS REQUIRED:

Hook tool

#15 Torx driver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 75145-201

MFG: INTERNATIONAL

MODELS & YEARS:

4000 Series 01-14, 7000 Series 02-13,

8000 Series 05-13, DuraStar 07-14,

TerraStar 2012-14

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 With hook tool pull off bezel that outlines the, climate control, radio, etc. Set bezel aside. There are (5) total clips.

STEP #2: Remove the (4) T-15 Torx screws that hold the climate control on. Pull out the climate control just enough to get the InDash by PanaVise over the (2) screw holes on the left side of the climate control. The PanaVise logo should be right side up. Reinstall the (2) screws on the left side of the climate control, then the right side screws.

STEP #3: Replace the bezel, securing all (5) clips.



Install InDash on these (2) holes under climate control flange

INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Prototype installed showing location
Finished Install Picture



02-19-13