

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China










## Ultralow power energy harvester and battery charger

Datasheet - production data



#### **Features**

- Transformerless thermoelectric generators and PV modules energy harvester
- High efficiency for any harvesting source
- Up to 70 mA maximum battery charging current
- · Fully integrated buck-boost DC-DC converter
- · Programmable MPPT by external resistors
- 2.6 V to 5.3 V trimmable battery charge voltage level (± 1% accuracy)
- 2.2 V to 3.6 V trimmable battery discharge voltage level (± 1% accuracy)
- Two fully independent LDOs (1.8 V and 3.3 V output)
- · Enable/disable LDO control pins
- Battery disconnect function for battery protection
- Battery connected and ongoing charge logic open drain indication pins

### **Applications**

- Charge any battery type, including lithium based, solid state thin film and super-capacitor.
- WSN, HVAC, building and home automation, industrial control, remote metering, lighting, security, surveillance.
- Wearable and biomedical sensors, fitness.

### **Description**

The SPV1050 is an ultralow power and highefficiency energy harvester and battery charger, which implements the MPPT function and integrates the switching elements of a buck-boost converter.

The SPV1050 device allows the charge of any battery, including the thin film batteries, by tightly monitoring the end-of-charge and the minimum battery voltage in order to avoid the overdischarge and to preserve the battery life.

The power manager is suitable for both PV cells and TEG harvesting sources, as it covers the input voltage range from 75 mV up to 18 V and guarantees high efficiency in both buck-boost and boost configuration.

Furthermore the SPV1050 device shows very high flexibility thanks also to the trimming capability of the end-of-charge and undervoltage protection voltages. In such way any source and battery is matched.

The MPPT is programmable by a resistor input divider and allows maximizing the source power under any temperature and irradiance condition.

An unregulated voltage output is available (e.g. to supply a microcontroller), while two fully independent LDOs are embedded for powering sensors and RF transceivers. Both LDOs (1.8 V and 3.3 V) can be independently enabled through two dedicated pins.

**SPV1050** 

## **Contents**

1	Block	diagram 5
2	Pin c	onfiguration
3	Pin d	escription7
4	Maxii	num ratings
5	Elect	rical characteristics10
6	Func	tional description13
	6.1	Battery charger
	6.2	Boost configuration
	6.3	Buck-boost configuration
	6.4	MPPT setting
	6.5	Power manager
7	Pack	age information
8	Orde	ring information
Appendix	A A	pplication tips
9	Revis	sion history

SPV1050 List of tables

## List of tables

Table 1.	Pin description	7
Table 2.	Thermal data	9
Table 3.	Absolute maximum ratings	9
Table 4.	Electrical characteristics	. 10
Table 5.	VFQFPN20 3 x 3 x 1 mm - 20-lead pitch 0.4 package mechanical data	. 29
Table 6.	Die pad coordinates and pad size	. 31
Table 7.	Device summary	. 32
Table 8.	Document revision history	. 35



List of figures SPV1050

# **List of figures**

Figure 1.	Block diagram	. 5
Figure 2.	Pin configuration (top through view)	
Figure 3.	Battery management section	
Figure 4.	Boost configuration	
Figure 5.	Boost startup	17
Figure 6.	MPPT tracking	
Figure 7.	Triggering of V <sub>EOC</sub> (BATT pin floating)	18
Figure 8.	Efficiency vs. input current - V <sub>OC</sub> = 1.0 V	19
Figure 9.	Efficiency vs. input current - V <sub>OC</sub> = 1.5 V	
Figure 10.	Efficiency vs. input current - V <sub>OC</sub> = 2.0 V	19
Figure 11.	Efficiency vs. input current - V <sub>OC</sub> = 2.5 V	19
Figure 12.	Buck-boost configuration	
Figure 13.	Buck-boost startup ( $I_{IN} = 5 \mu A$ )	21
Figure 14.	MPPT tracking	
Figure 15.	Efficiency vs. input current - V <sub>OC</sub> = 6 V	
Figure 16.	Efficiency vs. input current - V <sub>OC</sub> = 9 V	
Figure 17.	Efficiency vs. input current - V <sub>OC</sub> = 12 V	
Figure 18.	Efficiency vs. input current - V <sub>OC</sub> = 15 V	
Figure 19.	MPPT setup circuitry	
Figure 20.	Energy harvester equivalent circuit	
Figure 21.	Voltage vs. time at different C values and fixed current	
Figure 22.	LDO1 turn on with 100 mA load	
Figure 23.	LDO2 turn on with 100 mA load	
Figure 24.	VFQFPN20 3 x 3 x 1 mm - 20-lead pitch 0.4 package outline	
Figure 25.	Die form pad position (top view)	
Figure 26.	Inductor current and input voltage waveforms	33



SPV1050 Block diagram

## 1 Block diagram

**BATT** STORE **UVP** IN\_LV CONTROL DRIVERS EOC IN\_HV 1.23 \ L\_HV STORE CONTROL LOGIC LDO1 STORE MPP MPP\_SET **MPPT** LDO2 MPP\_REF LDO1\_EN BATT\_CHG LDO2\_EN BATT\_CONN CONF

Figure 1. Block diagram

GND 🗀

PGND

AM03402

Pin configuration SPV1050

# 2 Pin configuration




Figure 2. Pin configuration (top through view)

4

SPV1050 Pin description

# 3 Pin description

Table 1. Pin description

Pin no.	Name	Туре	Description
1	MPP	I	Max. power point tracking voltage sense pin. To be connected to the voltage source through a ladder resistor.
2	MPP-SET	ı	Max. power point setting voltage pin.  To be connected to the MPP pin through a ladder resistor. Connect to STORE if MPP function is not required.
3	MPP-REF	ı	Max. power point reference voltage pin.  To be connected to a 10 nF capacitor.  Connect to an external voltage reference if MPP function is not required.
4	GND	GND	Signal ground pin.
5	LDO1_EN	I	If high, enables LDO1.
6	LDO2_EN	I	If high, enables LDO2.
7	BATT_CHG	0	Ongoing battery charge output flag pin (open drain). If low, it indicates that the battery is on charge. If high, it indicates that the battery is not on charge.
8	BATT_CONN	0	Battery status output flag pin (open drain). If high, it indicates that the pass transistor between the STORE and BATT pins is open (battery disconnected). If low, it indicates that the pass transistor between the STORE and BATT pins is closed (battery connected).
9	EOC	ı	Battery end-of-charge pin.  To be connected to the STORE pin through a resistor divider between EOC and GND.
10	UVP	I	Battery undervoltage protection pin. To be connected to the STORE pin through a resistor.
11	LDO1	0	1.8 V regulated output voltage pin.
12	LDO2	0	3.3 V regulated output voltage pin.
13	CONF	ı	Configuration pin. Boost configuration: to be connected to the voltage supply source. Buck-boost configuration: to be connected to ground.
14	BATT	I/O	Battery connection pin.
15	STORE	I/O	Tank capacitor connection pin.
16	IN_LV	I	Low voltage input source. It has to be connected to the inductor for both boost and buck-boost configuration.
17	NC	-	Not connected.
18	PGND	PGND	Power ground pin.

Pin description SPV1050

Table 1. Pin description (continued)

Pin no.	Name	Туре	Description
19	L_HV	I	Input pin for buck-boost configuration.  Boost configuration: to be connected to ground.  Buck-boost configuration: to be connected to the inductor.
20	IN_HV	I	High voltage input source.  Boost configuration: to be connected to ground.  Buck-boost configuration: to be connected to the voltage supply source.

SPV1050 Maximum ratings

# 4 Maximum ratings

Table 2. Thermal data

Symbol	Parameter		Value		
Symbol			Max.	Unit	
R <sub>th j-c</sub>	Max. thermal resistance, junction to case		7.5	°C/W	
R <sub>th j-a</sub> <sup>(1)</sup>	Max. thermal resistance, junction to ambient		49	°C/W	
P <sub>TOT</sub>	Maximum power dissipation at T <sub>amb</sub> = 85 °C		1	W	
Tj	Junction temperature range	-40 ÷ 125		°C	
T <sub>storage</sub>	Storage temperature	15	50	°C	

<sup>1.</sup> Measured on 2-layer application board FR4, Cu thickness = 17  $\mu$  with total exposed pad area = 16  $\mu$ 

Table 3. Absolute maximum ratings

Symbol	Parameter	Value	Unit
IN_LV	Analog input	V <sub>STORE</sub> + 0.3	V
IN_HV	Analog input	20	V
L_HV	Analog input	IN_HV + 0.3	V
CONF	Analog input	5.5	V
MPP	Analog input	5.5	V
MPP-SET	Analog input	5.5	V
MPP-REF	Analog input	5.5	V
BATT	Analog input/output	5.5	V
STORE	Analog input/output	5.5	V
UVP	Analog input	V <sub>STORE</sub> + 0.3	V
EOC	Analog input	V <sub>STORE</sub> + 0.3	V
BATT_CONN	Digital output	5.5	V
BATT_CHG	Digital output	5.5	V
LDO1_EN	Digital input	V <sub>STORE</sub> + 0.3	V
LDO2_EN	Digital input	V <sub>STORE</sub> + 0.3	V
LDO1	Analog output	V <sub>STORE</sub> + 0.3	V
LDO2	Analog output	V <sub>STORE</sub> + 0.3	V
PGND	Power ground	0	V
GND	Signal ground	-0.3 to 0.3	V

Electrical characteristics SPV1050

## 5 Electrical characteristics

 $V_{STORE}$  = 4 V,  $T_{amb}$  = - 40 to 85 °C, unless otherwise specified. Voltage with respect to GND unless otherwise specified.

**Table 4. Electrical characteristics** 

Symbol	Parameter	Parameter Test condition		Min.	Тур.	Max.	Unit
Battery operat	ing range			•		•	
I <sub>BATT</sub>	Maximum battery charging current					70	mA
V <sub>BATT</sub>	BATT pin voltage range			2.2		5.3	V
V <sub>BATTACC</sub>	Battery voltage accuracy			-1		+1	%
R <sub>BATT</sub>	Pass transistor resistance			6	7	8	Ω
Bandgap							
.,,	Internal reference voltage				1.23		V
$V_{BG}$	Accuracy			-1		+1	%
UVP				•	•	•	
V <sub>UVP</sub>	Undervoltage protection range	(V <sub>UVP</sub> + UVP <sub>HYS</sub> ) < (	V <sub>EOC</sub> - EOC <sub>HYS</sub> )	2.2		3.6	V
EOC					I.		
V <sub>EOC</sub>	Battery end-of-charge voltage	(V <sub>UVP</sub> + UVP <sub>HYS</sub> ) < (	V <sub>EOC</sub> -EOC <sub>HYS</sub> )	2.6		5.3	V
EOC <sub>HYS</sub>	EOC hysteresis	V <sub>STORE</sub> decreasing			-1		%
STORE		,		•	l.	•	'
V <sub>STORE</sub>	STORE pin voltage operating range			V <sub>UVP</sub>		V <sub>EOC</sub>	V
Static current	consumption						
I <sub>SD</sub>	Shutdown current	Shut down mode: Before first startup or high T <sub>AMB</sub> < 60 °C	BATT_CONN			1	nA
I <sub>SB</sub>	Standby current	Standby mode: BATT_CONN low, BATT_CHG high, VSTORE = 5.3 V and LDO1,2_EN low T <sub>AMB</sub> = 25 °C			0.8		μА
I <sub>OP</sub>	Operating current in open load	Operating mode (LDOs in open load) BATT_CONN low	LDO1_EN = 1 or LDO2_EN = 1		1.7		μА
	loud	BATT_CHG high T <sub>AMB</sub> = 25 °C LDO1,2_EN = 1		2.6			
		1			l		




Table 4. Electrical characteristics (continued)

Symbol	Parameter	Test condition	Min.	Тур.	Max.	Unit
DC-DC conver	ter		ı		ı	
V <sub>IN_LV</sub>		Boost configuration	0.15		V <sub>EOC</sub>	
V <sub>IN_HV</sub>	Input voltage range	Buck-boost configuration	0.15		18	V
	Minimum input voltage at	Boost configuration BATT_CONN high or at first startup		0.55	0.58	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
V <sub>IN-MIN</sub>	startup	Buck-boost configuration BATT_CONN high or at first startup		2.6	2.8	V
I <sub>B-SU</sub>	Startup input current	Boost configuration		30		μΑ
I <sub>BB-SU</sub>	- Startup input current	Buck-boost configuration		5		μA
R-ON <sub>B</sub>	Low-side MOS resistance		0.5	1.0	1.5	
SR-ON <sub>B</sub>	Synchronous rectifier MOS resistance	Boost configuration	0.5	1.0	1.5	Ω
R-ON <sub>BB</sub>	Low-side MOS resistance		1	1.5	2	
SR-ON <sub>BB</sub>	Synchronous rectifier MOS resistance	Buck-boost configuration	1	1.5	2	Ω
f <sub>SW</sub>	Maximum allowed switching frequency	Boost and buck-boost configurations			1	MHz
UVLO <sub>H</sub>	Undervoltage lockout threshold (V <sub>STORE</sub> increasing)			2.6	2.8	٧
UVLO <sub>L</sub>	Undervoltage lockout threshold (V <sub>STORE</sub> decreasing)	- Boost and buck-boost configurations	2	2.1		V
MPPT			•		•	
T <sub>TRACKING</sub>	MPPT tracking period	BATT_CHG low	12		20	s
T <sub>SAMPLE</sub>	MPPT sampling time	BATT_CHG high	0.3		0.5	S
$V_{MPP}$	MPP pin voltage range	Boost and buck-boost configurations	0.075		V <sub>UVP</sub>	V
MPP <sub>ACC</sub>	MPP tracking accuracy	Boost and buck-boost configurations	95			%
LDO			•	l	•	ı
	LDO1,2 adjusted output	LDO1_EN = 1		1.8		
V <sub>LDO1,2</sub>	voltage	LDO2_EN = 1		3.3		V
	LDO1 dropout	V <sub>UVP</sub> + 200 mV < V <sub>BATT</sub> ≤ 5.3 V I <sub>LDO1</sub> = 100 mA			0.5	0,
$\Delta V_{LDO1,2}$	LDO2 dropout	$3.3 < V_{UVP} + 200 \text{ mV} < V_{BATT} \le 5.3 \text{ V}$ $I_{LDO2} = 100 \text{ mA}$			0.5	. %
t <sub>LDO</sub>	LDO <sub>1,2</sub> startup time	BATT_DIS low C <sub>LDO1,2</sub> = 100 nF			1	ms
I <sub>LDO1</sub> <sup>(1)</sup>	I <sub>OUT</sub> max from LDO1				200	mA
	· · · · · · · · · · · · · · · · · · ·	•				



Electrical characteristics SPV1050

Table 4. Electrical characteristics (continued)

Symbol	Parameter	Test condition	Min.	Тур.	Max.	Unit
I <sub>LDO2</sub> (1)	I <sub>OUT</sub> max from LDO2				200	mA
V <sub>LDO1,2_EN_H</sub>	LDO1,2 enable input HIGH		1			٧
V <sub>LDO1,2_EN_L</sub>	LDO1,2 enable input LOW		·		0.5	٧
Digital output						
V <sub>BATT_CONN_L</sub>	V <sub>BATT_DIS</sub> LOW	1 mA sink current	40	70	150	mV
V <sub>BATT_CHG_L</sub>	V <sub>XBATT_CHG</sub> LOW	1 mA sink current	40	70	150	mV

<sup>1.</sup> Guaranteed by design, not tested in production.

### 6 Functional description

The SPV1050 is an ultralow power energy harvester with an embedded MPPT algorithm, a battery charger and power manager designed for applications up to about 400 mW.

The SPV1050 device integrates a DC-DC converter stage that can be configured as boost or buck-boost by tying the CONF pin to PV+/TEG+ or to ground respectively as shown in *Figure 4* and *Figure 12* on page 20.

If the embedded MPPT algorithm is enabled, the device regulates the working point of the DC-DC converter in order to maximize the power extracted from the source by tracking its output voltage. See further details in *Section 6.2: Boost configuration on page 16* and *Section 6.3: Buck-boost configuration on page 20*.

The MPPT algorithm can be disabled by shorting the MPP-SET pin to the STORE pin, and by providing an external voltage to the MPP-REF pin.

In case of low impedance source (e.g. USB), the MPP-REF must be connected to GND. The IC will switch at the highest duty cycle possible until the  $V_{EOC}$  on the STORE pin is triggered.

In case of high impedance source with limited current capability (i.e. if the source is unable to sustain switching at the maximum duty cycle), the MPP-REF pin must be connected to a voltage reference selected such that  $V_{MPP-REF} > V_{IN(MIN)}$ . This voltage reference can be set through a resistor ladder connected to STORE or any other voltage reference available in the application.

If the MPP pin is connected to the source by a resistor ladder, then the same consideration must be extended to the MPP pin. Referring to *Figure 19* (where connections between MPP-SET to R2-R3 must be open and MPP-SET must be considered as connected to STORE):

- If R1 = 0 Ω: then  $V_{MPP-REF} = V_{IN(MIN)}$
- Otherwise: V<sub>MPP-REF</sub> = V<sub>MPP(MIN)</sub> = V<sub>IN(MIN)</sub> \* (R2+R3)/R1

### 6.1 Battery charger

In order to guarantee the lifetime and safety of the battery, the SPV1050 device controls an integrated pass transistor between the STORE and BATT pins and implements both the undervoltage (UVP) and the end-of-charge (EOC) protection thresholds.




Figure 3. Battery management section

Before the first startup the pass transistor is open, so that the leakage from the battery is lower than 1 nA. The pass transistor will be closed once the voltage on the STORE pin will rise such that the EOC threshold  $V_{EOC}$  is triggered. If the battery is full, and until  $V_{STORE} > V_{EOC}$  - EOC<sub>HYS</sub>, the DC-DC converter will stop switching to avoid battery overcharge.

On the contrary, in order to avoid the overdischarge of the battery, the pass transistor will be opened once the voltage on the STORE pin will decrease down to UVP threshold  $V_{UVP}$ .

These functions are simply implemented by the control of two voltage thresholds,  $V_{UVP}$  and  $V_{EOC}$ , which can be regulated by a resistor partitioning (R4, R5, R6) between STORE, UVP and EOC pins.

The scaled voltages on the UVP and EOC pins will be compared with the internal bandgap voltage reference  $V_{BG}$  set at 1.23 V.

The design rules to setup the R4, R5 and R6 are the following:

#### **Equation 1**

$$V_{BG} = V_{UVP} \cdot (R5 + R6) / (R4 + R5 + R6)$$

#### **Equation 2**

$$V_{RG} = V_{FOC} \cdot R6 / (R4 + R5 + R6)$$

In order to minimize the leakage due to the output resistor partitioning it has to be typically:

4

#### **Equation 3**

#### $10~\text{M}\Omega \leq \text{R4} + \text{R5} + \text{R6} \leq 20~\text{M}\Omega$

Further, the SPV1050 device provides two open drain digital outputs to an external microcontroller:

#### BATT CONN

This pin is pulled down when the pass transistor is closed. It will be released once the pass transistor will be opened (e.g. triggering of  $V_{UVP}$ ). If used, this pin must be pulled-up to the STORE by a 10 M $\Omega$  (typical) resistor.

#### • BATT CHG

This pin is pulled down when the DC-DC converter is switching, while it's released when it is not switching, i.e. when the EOC threshold is triggered until the voltage on the STORE pin drops at  $V_{EOC}$  -  $EOC_{HYS}$ , when the UVLO threshold is triggered or during the  $T_{SAMPLE}$  of the MPPT algorithm. If used, this pin must be pulled-up to the STORE by a 10 M $\Omega$  (typical) resistor.



### 6.2 Boost configuration

Figure 4 shows the boost application circuit.

BATT STORE UVP IN\_LV CONTROL DRIVERS EOC IN\_HV Thermoelectric generator L\_HV CONTROL LOGIC Battery LDO1 TO LOAD1 MPP MPP\_SET MPPT LDO2 MPP\_REF LDO1\_EN BATT\_CON LDO2\_EN BATT CHG CONF Cin PGND GND AM03398

Figure 4. Boost configuration

In case of boost configuration, once the harvested source is connected, the SPV1050 device will start boosting the voltage on the STORE pin. In the range of 0  $\leq$  V<sub>STORE</sub> < 2.6 V the voltage boost is carried on by an integrated high-efficiency charge pump, while the DC-DC converter stage will remain OFF.

Vertical Timebase Trigger Display Cursors Measure Math Analysis Utilities DC-DC TURN ON Switching Charge Pump Switching Timebase -97.2 s Trigger LeCrov 2/10/2014 7:51:35 PM

*Figure 5* shows the behavior of input voltage V<sub>IN</sub> and V<sub>STORE</sub> at the startup.

Figure 5. Boost startup

In the range 2.6 V  $\leq$  V<sub>STORE</sub> < V<sub>EOC</sub> the voltage is boosted by the DC-DC converter. In this voltage range the SPV1050 device sets its internal impedance according to the integrated MPPT algorithm (the MPPT mode is active). The SPV1050 device will stop switching for 400 ms ( $T_{SAMPLE}$ ) every 16 seconds ( $T_{TRACKING}$ ). During the  $T_{SAMPLE}$ , the input open circuit voltage  $V_{OC}$  is sampled by charging the capacitor on the MPP-REF pin. Once the T<sub>SAMPLE</sub> is elapsed, the DC-DC converter will start switching back by setting its own impedance such that V<sub>IN</sub> stays as close as possible to V<sub>MPP</sub> of the source. A resistor partitioning connected between the source and the pins MPP and MPP-SET has to be properly selected, in order to match the manufacturer's specs. Please refer to Section 6.4: MPPT setting on page 24 for further details.

The periodic sampling of V<sub>OC</sub> guarantees the best MPPT in case of source condition variations (e.g. irradiation/thermal gradient and/or temperature changes).

*Figure 6* shows the input voltage waveform of a PV panel supplying  $V_{OC}$  = 1.25 V and  $V_{MPP}$  = 1.05 V.




Figure 6. MPPT tracking

Once the  $V_{EOC}$  threshold is triggered, the switching of the DC-DC converter is stopped until  $V_{STORE}$  will decrease to  $V_{EOC}$  -  $EOC_{HYS}$ .






Figure 7. Triggering of V<sub>EOC</sub> (BATT pin floating)

577

The following plots from Figure 8 to Figure 11 show the power efficiency of the DC-DC converter configured in boost mode at  $T_{amb}$  = 25 °C in some typical use cases at different open circuit voltages:





## 6.3 Buck-boost configuration

Figure 12 shows the buck-boost application circuit.

BATT STORE UVP CONTROL DRIVERS EOC Solar IN\_HV L\_HV CONTROL LOGIC Battery  $\mathsf{C}_{\mathsf{STORE}}$ LDO1 TO LOAD1 MPP MPP\_SET MPPT LDO2 TO LOAD2 MPP\_REF LDO1\_EN BATT\_CON LDO2\_EN BATT\_CHG CONF Cin PGND GND ÷ AM03399

Figure 12. Buck-boost configuration

In case of buck-boost configuration, once the harvested source is connected, the IN\_HV and STORE pins will be internally shorted until  $V_{STORE}$  < 2.6 V. *Figure 13* shows the behavior of the input voltage  $V_{IN}$  HV and  $V_{STORE}$  at the startup.




Figure 13. Buck-boost startup ( $I_{IN} = 5 \mu A$ )

In the range 2.6 V  $\leq$  V<sub>STORE</sub> < V<sub>EOC</sub> the integrated DC-DC converter will start switching. In this operating range the SPV1050 input impedance is set by the embedded MPPT algorithm (the MPPT mode is active). The SPV1050 device will stop switching for 400ms (T<sub>SAMPLE</sub>) every 16 seconds (T<sub>TRACKING</sub>). During the T<sub>SAMPLE</sub>, the input open circuit voltage V<sub>OC</sub> is sampled by charging the capacitor on the MPP-REF pin. Once the T<sub>SAMPLE</sub> is elapsed, the DC-DC converter will start switching back by setting its own impedance such that V<sub>IN</sub> stays as close as possible to V<sub>MPP</sub> of the source. A resistor partitioning connected between the source and the pins MPP and MPP-SET has to be properly selected in order to match the V<sub>MPP</sub> given by the source manufacturer. Please refer to *Section 6.4: MPPT setting* for further details.


The periodic sampling of V<sub>OC</sub> guarantees the best MPPT in case of source condition variations (e.g. irradiation and/or temperature changes).


Figure 14 shows the MPPT tracking form in case of  $V_{OC}$  = 9.9 V and  $V_{MPP}$  = 8.2 V.





The following plots from Figure 15 to Figure 18 show the power efficiency of the DC-DC converter configured in buck-boost mode at  $T_{amb} = 25$  °C in some typical use cases:





### 6.4 MPPT setting

When the MPPT feature is enabled, the SPV1050 device sets its working point such that  $V_{IN} = V_{MPP}$ . In fact,  $V_{MPP}$  is a fraction of the open circuit voltage  $V_{OC}$  of the harvesting source.

Figure 19. MPPT setup circuitry

The maximum power point is set through the input resistor partitioning R1, R2 and R3.

First of all, set the total input resistance (R1 + R2 + R3) considering the maximum acceptable leakage current ( $I_{LEAKAGE}$ ):

#### **Equation 4**

$$I_{LEAKAGE} = V_{OC} / (R1 + R2 + R3)$$

Typically, assuming 10 M $\Omega$  ≤ R1 + R2 + R3 ≤ 20 M $\Omega$ , the leakage on the input resistor partitioning can be considered as negligible.

Then set the R2 + R3 selecting the minimum between the results of equations 5 and 6 which consider that the voltage on the MPP pin must be lower than the minimum  $V_{UVP}(V_{UVP(min)} = 2.2 \text{ V})$  and the energy balance on the inductor even at very low input power (see details in Appendix A, Application tips), respectively:

#### **Equation 5**

$$R2 + R3 \le (R1 + R2 + R3) * V_{UVP(min)} / V_{OC}$$

#### **Equation 6**

$$R2 + R3 \le 51 * (R1 + R2 + R3) * V_{MPP(min)} / V_{EOC}$$

Finally, set the R3 considering the MPP<sub>RATIO</sub> (in case of PV panels MPP<sub>RATIO</sub> =  $V_{MP} / V_{OC}$ ):

#### **Equation 7**



$$MPP_{RATIO} = R3 / (R2 + R3)$$

In boost mode if the electrical characteristics of the selected source and battery are such that  $V_{OC\text{-MAX}} \le V_{UVP(min)}$ , then the resistor R1 can be replaced by a short-circuit. Consequently, only R2 and R3 have to be selected for a proper setting of MPP<sub>RATIO</sub>.

In a PV panel the  $V_{MPP}$  is typically within 70%  $\div$  80% of  $V_{OC}$ .

In a TEG the  $V_{MPP}$  is typically about 50% of  $V_{OC}$ .

The MPPT accuracy can be strongly affected by an improper selection of the input capacitor. The input capacitance  $C_{IN}$  = 4.7  $\mu F$  generally covers the most typical use cases.

The energy extracted from the harvested source, and stored in the input capacitance, is transferred to the load by the DC-DC converter through the inductor. The energy extracted by the inductor depends by the sink current: the higher input currents cause higher voltage drop on the input capacitance and this may result a problem for low voltage (< 1 V) and high energy (> 20 mA) sources. In such application cases the input capacitance has to be increased or, alternatively the L1 inductance has to be reduced.

During the T<sub>SAMPLE</sub> time frame the input capacitor C<sub>IN</sub> is charged up to V<sub>OC</sub> by the source with a T1 time constant resulting from the capacitance and the equivalent resistance R<sub>FO</sub> of the source.

In case of the PV source, assuming I<sub>MPP</sub> the minimum current at which the MPP must be guaranteed, the REQ can be calculated as following:

#### **Equation 8**

$$R_{EQ} = (V_{OC} - V_{MPP}) / I_{MPP} = V_{OC} \cdot (1 - MPP_{RATIO}) / I_{MPP}$$

Thus C<sub>IN</sub> is calculated by the following formula:

#### **Equation 9**

$$C_{IN} \leq T1/R_{EO}$$

The following plots in Figure 20 and Figure 21 show the effect of different C<sub>IN</sub> values on the time constant. If the capacitance is too high, the capacitor may not be charged within the  $T_{SAMPLE}$  = 400 ms time window, thus affecting the MPPT accuracy.

