imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







Figure 1

1. INTRODUCTION

The LightKnack Portable Magnetic L.E.D. Light (see Figure 1) is designed to provide light where it is needed. The light affixes to any magnetic surface via two powerful rare earth magnets, and the housing is made from rugged, glass-filled plastic.

The light's housing is contoured specifically to fit on the TE Connectivity CERTI-CRIMP* II hand tool heads as shown in Figure 1.

2. BATTERY REPLACEMENT (Figure 2)

The LightKnack L.E.D. Light runs on two CR1216 batteries (included). These batteries can be replaced by performing the following procedure:



TE does not sell the batteries, but they are commonly available.

- 1. Remove the four screws at the bottom of the light.
- 2. Remove the bottom cover.



Figure 2

- 3. Remove the old batteries.
- 4. Check that the switch and L.E.D. are in place.

5. Place the new batteries in the light with the positive side toward the bottom cover.

6. Replace the bottom cover and the four screws.

3. ORDERING INFORMATION/REPLACEMENT PARTS

The LightKnack L.E.D. Light can be ordered in packages of three using part number 2119700-1. To order this part, contact your TE Representative, or call 1-800-526-5142, or send a facsimile of your purchase order to 1-717-986-7605, or write to:

CUSTOMER SERVICE (038-035) TYCO ELECTRONICS CORPORATION PO BOX 3608 HARRISBURG PA 17105-3608

4. REVISION SUMMARY

• Initial release of document

TOOLING ASSISTANCE CENTER 1-800-722-1111 PRODUCT INFORMATION 1-800-522-6752