



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts,Customers Priority,Honest Operation,and Considerate Service",our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



OPERATOR ADAPTERS FOR UNIVERSAL CUTOUTS




Used on all Hoffman Type 4 and 12 disconnect enclosures with a universal flange cutout. An operator adapter is required to install a disconnect in Bulletin A21, A28, A34 and A4L3D Hoffman enclosures that have a universal cutout. Operator adapters include an adapter plate and additional components needed to interlock the master door with the disconnect operating mechanism. Installation instructions are included with each operator adapter. Each brand and type of disconnect requires a different operator adapter. Be sure to select the correct operator adapter and enclosure for the disconnect device selected. A 400A (or greater) disconnect switch and 600A (or greater) circuit breaker require the large handle. A 200A (or less) disconnect switch and 400A (or less) circuit breaker require a small handle.

Old Catalog Number	New Catalog Number	Brand and Type of Operator
A21ABA	ABF	Allen-Bradley 1494F & 1494D Fixed-Depth Mechanisms
A21ABVA	ABS	Allen-Bradley 1494V Variable-Depth; Allen-Bradley 140U; all 140G handles; 1494U Universal; 1494C & 194RC Cable-Operated; Small Handle*
A21ABVA	ABL	Allen-Bradley 1494V Variable-Depth; Allen-Bradley 140U, 1494C & 194RC Cable-Operated; Large Handle*
A21ITE	SITES	Siemens I-T-E Max-Flex; Small Handle*
A21ITE	SITEL	Siemens I-T-E Max-Flex; Large Handle*
A21ITE	ABBSC	ABB Controls, Small Handle*
A21ITE	ABBLC	ABB Controls, Large Handle*
A21CHVA	ABBSV	ABB Variable-Depth, Small Handle*
A21CHVA	ECHV	Eaton Cutler-Hammer C361, C371 Variable Depth
A21CHVA	ECHC	Eaton Cutler-Hammer C371 Flex Shaft Cable-Operated
A21WHA	Discontinued	Eaton Cutler-Hammer/Westinghouse SM mechanisms
A21WHAMTA	WAMT	Eaton Cutler-Hammer/Westinghouse Below Handle AMT & Flex-Cable For F Frame Circuit Breakers
A21WHAMTA	WAMTF	Eaton Cutler-Hammer/Westinghouse Flex-Cable For Circuit Breakers Except For F Frame
A21GETDA	GEV	General Electric STDA Variable-Depth
A21GETDA	GEC	General Electric Flexible Cable-Operated
A21SDA	SQDV	Square D® Class 9422 Variable-Depth
A21SDA	SQDC	Square D® Class 9422 Flex-Cable Mechanisms

* Large handle is for 400A or greater disconnect switch and 600A or greater circuit breaker; small handle is for 200A or less disconnect switch and 400A or less circuit breaker.

OPERATOR ADAPTERS FOR PREFERRED CUTOUTS



An operator adapter is required to install a disconnect in Bulletin A21S4, A28S4 and WS2D Hoffman enclosures that have a preferred cutout. Operator adapters include components needed to interlock the master door with the disconnect operating mechanism. Panel drilling and installation instructions are furnished with each operator adapter.

Each brand and type of disconnect requires a different operator adapter. Be sure to select the proper operator adapter and enclosure for the disconnect that you have selected.

BULLETIN: A28Y

Catalog Number	Brand and Type of Operator
APCABVA	Allen-Bradley 1494V variable-depth Allen-Bradley 140U, 140G and 1494C cable-operated mechanisms
APCCHVA	Eaton Cutler-Hammer C361, C371 and C371 Flex Shaft
APCGETDA	General Electric STDA
APCITE	Siemens I-T-E Max-Flex
APCSDA	Schneider Square D® Class 9422 variable-depth and cable mechanisms

BLANK ADAPTER PLATES, MILD STEEL



Used to cover flange cutouts in disconnect enclosures when disconnects are not installed. This greatly increases the versatility of disconnect enclosures, enabling them to also be used as regular Type 12 enclosures. If the UBP model is used, the disconnect enclosure can be used as a regular Type 4 enclosure. Hoffman adapter plates are made from heavy gauge steel and have an oil-resistant gasket to maintain a dust-tight and oil-tight seal. Mounting hardware and instructions are included. Door hardware is not furnished with blank adapter plate. Door hardware must be ordered separately from the disconnect manufacturer when using catalog numbers A22BAP on Bulletin A22 Enclosures and A3456BAP on Bulletin A25 Enclosures.


BULLETIN: A80

Catalog Number	Old Catalog Number	For Mild Steel Enclosure
UBP	A21BAP	With Universal Cutouts (i.e. A21, A28, A4L3D, A34)
A22BAP	---	A22 only
A3456BAP	---	With Preferred Cutouts (i.e. A19, CWD, A25, A26)

A22BAP will fit all Bulletin A22 enclosures except A48AB3812A2LP and A60AB3812A2LP.

A3456BAP will fit all Bulletin A25 enclosures except A60SA3812A24LP.

BLANK ADAPTER PLATES, STAINLESS STEEL




Used to cover flange cutouts in disconnect enclosures when disconnects are not installed. Hoffman adapter plates are made from heavy gauge Type 304 stainless steel and have an oil-resistant gasket to maintain the dust-tight and oil-tight qualities of the enclosure. The plates have a #4 brushed finish. All necessary mounting hardware and instructions are included.

BULLETIN: A80

Catalog Number	For Enclosure
AZ128BAPSS	With preferred cutouts (i.e. A19S, CWSD, A21S4, A28S4, WS2D, A4S2, WS1D)

ENCLOSURE STABILIZERS



Helps prevent injury to workers by stabilizing floor-mount enclosures which are not bolted down. To install, slip the stabilizer under the floor stand and tighten two thumb screws. Made from .19-in. (5-mm) steel plate. Bright orange finish.

BULLETIN: A80

Catalog Number	Description
AENST	Two stabilizers