

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China









Device Programmers and Development Tools for Microcontrollers

Products E-Shop Support Contact News Site Map

Quick Links

Help Desk Downloads All Programmers Device Search **Tools Catalogs**

T Shopping Cart

Total: \$0.00

Your Account

Products

Development Tools ARM 8051

Device programmers

All Models Universal In-System

Gang Adapters

Custom made tools OEM tools

AE-Q48-W79-3

DIP40/QFP48 specialized adapter for Nuvoton/Winbond microcontrollers.



Description:

DIP40/QFP48 specialized adapter for Nuvoton/Winbond microcontrollers. Device package dimensions: body - 7.0 x 7.0 x 1.5 mm, body with pins - 9.0 x 9.0 mm, 0.5 mm pitch.

Supported Devices:

Click the device programmer model below to get an appropriate list of the devices supported by this programmer with this adapter:

- ChipProg-48ChipProg-G4ChipProg-40ChipProg+

Adapter wiring diagram

Adapter Connection Table:

DI P-40	TQFP-48
1	21
2	22
3	23
4	24
5	25
6	26
7	27
8	28
9	29
10	30
11	31
12	32
13	33
14	34
15	35
16	36
17	37
18	38
19	39
20	40,18
21	46
22	47
23	48
24	1
25	2
26	3
27	4
28	5
29	6
30	7
31	8

	32	9	
	33	10	
	34	11	
	35	12	
	36	13	
	37	14	
	38	15	
	39	16	
	40	17,19	
1	1		l
Copyright @ 2007-2010 Phyton Inc			Phana, 719 250 2101 - E maile, info@phyton.com, coloc@phyton.com, cupnort@phyton.com

Copyright © 2007-2010 Phyton, Inc.

Phone: 718-259-3191 • E-mails: info@phyton.com, sales@phyton.com, support@phyton.com