# imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



## AX-SIGFOX MINISTAMP AX-SIGFOX ANTSTAMP

## Ultra-Low Power, AT Command Controlled, Sigfox<sup>®</sup> Compliant Modules

#### Overview

The AX–SIGFOX modules are ultra–low power module solutions for a node on the Sigfox network with both up– and down–link functionality. The AX–SIGFOX modules connect to the customer application using a logic level RS232 UART. AT commands are used to send frames and configure radio parameters.

The AX-SIGFOX module comes in two flavors

- AX–SIGFOX MINISTAMP with 50  $\Omega$  Antenna Port
- AX-SIGFOX ANTSTAMP with On-board -5 dBi Chip Antenna

#### **Functionality and Ecosystem**

- Sigfox up-link and down-link functionality controlled by AT commands
- The AX–SIGFOX modules are part of a whole development and product ecosystem available from ON Semiconductor for any Sigfox requirement. Other parts of the ecosystem include
  - AX-Sigfox ultra-low power, AT command controlled, Sigfox compliant transceiver IC
  - Ready to go AX-Sigfox development kit with fully functional AX-Sigfox module including Sigfox subscription
  - Sigfox Ready certified reference design for the AX-Sigfox IC
  - AX-Sigfox API IC for customers wishing to write their own application software based on the ON Semiconductor Sigfox Library

#### **General Features**

- 18.2 x 22 x 3 mm<sup>3</sup> without chip antenna, 18.2 x 39.7 x 3 mm<sup>3</sup> with chip antenna
- Supply range from 1.8 V to 3.3 V
- -40°C to 85°C
- Temperature sensor
- Supply voltage measurements
- 10 GPIO pins
  - ◆ 4 GPIO pins with selectable voltage measure functionality, differential (1 V or 10 V range) or single ended (1 V range) with 10 bit resolution



### **ON Semiconductor®**

#### www.onsemi.com

- 2 GPIO pins with selectable sigma delta DAC output functionality
- ♦ 2 GPIO pins with selectable output clock
- 3 GPIO pins selectable as SPI master interface

#### **Power Consumption**

- Ultra-low power consumption
  - Charge required to send a Sigfox OOB packet at 14 dBm output power: 0.29 C
  - Deepsleep mode current: 500 nA
  - Sleep mode current: 1.6 μA
  - Standby mode current : 0.5 mA
  - Continuous radio reception at 869.525 MHz: 13 mA
  - Continuous radio transmission at 868.130 MHz for 14 dBm output power: 51 mA for 0 dBm output power: 21 mA
- The output power of AX–SIGFOX modules can be programmed in 1 dB steps from 0 dBm – 14 dBm. They are optimized for best power efficiency at 14 dBm output power. For modules optimized for other output power values e.g 0 dBm transmission with 10 mA please contact us.

#### High Performance Narrow-band Sigfox Receiver

- Carrier frequency 868.525 MHz
- Data-rate 600 bps
- Sensitivity: -126 dBm @ 600 bps, 869.525 MHz, GFSK
- 0 dBm maximum input power

#### **Highly Efficient Transmitter**

- Carrier frequency 868.13 MHz
- Data-rate 100 bps PSK
- Maximum output power 14 dBm
- Power level programmable in 1 dBm steps from 0 dBm to 14 dBm

#### Regulatory

- Sigfox Ready certified
- EN 300 220

#### About the Sigfox Technology

Sigfox uses an Ultra Narrow Band (UNB) based radio technology to connect devices to its global network. The usage of UNB is key to providing a scalable, high–capacity network, with very low energy consumption, while maintaining a simple and easy to rollout star–based cell infrastructure.

The network operates in the globally available ISM bands (license–free frequency bands) and co–exists in these frequencies with other radio technologies, but without any risk of collisions or capacity problems.

Sigfox currently uses the most popular European ISM band on 868 MHz (as defined by ETSI and CEPT) as well

as 902 MHz in the USA (as defined by the FCC), depending on specific regional regulations.

Sigfox only acts as a transport channel, pushing the data towards the customer's IT system.

An important advantage provided by the use of the narrow band technology is the flexibility it offers in terms of antenna design. On the network infrastructure end it allows the use of small and simple antennas, but more importantly, it allows devices to use inexpensive and easily customizable antennas.

The Sigfox protocol is compatible with existing transceivers and is actively being ported to a growing number of platforms.



(Note that the actual product comes with a metal cap)

Figure 1. AX-SIGFOX MINISTAMP/ANTSTAMP Modules

## PINOUT







#### **Table 1. PIN FUNCTION DESCRIPTION**

Pin	Name	Function
1*	GND	Ground
2*	NC	Do not connect
3*	NC	
4*	NC	
5*	GND	Ground
6*	ANT50Ω	50 $\Omega$ antenna port
7*	GND	Ground
8*	NC	Do not connect
9	NC	
10	GPIO8	General purpose IO
11	GPIO7	General purpose IO, selectable SPI functionality (MISO)
12	GPIO6	General purpose IO, selectable SPI functionality (MOSI)
13	GPIO5	General purpose IO, selectable SPI functionality (SCK)
14	GPIO4	General purpose IO, selectable $\Sigma\Delta$ DAC functionality, selectable clock functionality
15	CPU_LED	Module activity status, enabled whenever the module is running
16	RADIO_LED	Radio activity status
17	VTCXO	TCXO enable (used to control the on-board TCXO)
18	GPIO9	General purpose IO and wake-up from deepsleep
19	UART_TX	UART used to communicate with the module at a bitrate of 9600 baud, no parity, 8 data bits and one stop
20	UART_RX	bit.
21	RX_LED	Radio receive activity status
22	TX_LED	Radio transmit activity status
23	NC	Do not connect
24	NC	
25	VDD	Power Supply
26	GND	Ground
27	RESET_N	Optional reset (active low). Do not connect the pin if not used.
28	GND	Ground
29	GPIO0	General purpose IO, selectable ADC functionality, selectable $\Sigma\Delta$ DAC functionality, selectable clock functionality
30	GPIO1	General purpose IO, selectable ADC functionality

#### Table 1. PIN FUNCTION DESCRIPTION

Pin	Name	Function
31	GPIO2	General purpose IO, selectable ADC functionality
32	NC	Do not connect
33	NC	
34	GPIO3	General purpose IO, selectable ADC functionality

NOTE: All digital pins are Schmitt trigger inputs, digital input and output levels are LVCMOS/LVTTL compatible. Pins GPIO[3:0] must not be driven above VDD, all other digital inputs are 5 V tolerant.

All GPIO pins and UART\_RX start-up as inputs with pull-up.

#### Dimensions



All dimensions in millimeter.



The area under the modules must be covered in solder stop. To guarantee good antenna performance with the AX–SIGFOX ANTSTAMP, the left part of the module must remain free from any copper (i.e. no ground plane and no traces).

#### SPECIFICATIONS

#### Table 2. SUPPLIES

Symbol	Description	Condition	Min	Тур	Max	Units
T <sub>AMB</sub>	Operational ambient temperature		-40	27	85	°C
VDD	Supply voltage		1.8	3.0	3.3	V
I <sub>DS</sub>	Deep sleep mode current	AT\$P=2		500		nA
I <sub>SLP</sub>	Sleep mode current	AT\$P=1		1.6		μA
I <sub>STDBY</sub>	Standby mode current			0.5		mA
Continuous Rec	eive	•		•	•	•
I <sub>RX_CONT</sub>	Current consumption in Sigfox RX test mode	AT\$SR=1,1,-1		12.8		mA
Transmit at 14 d	Bm Output Power / Receive (Note 2)	•				
ITXMODAVG_14	Modulated transmitter current			51.0		mA
Q <sub>SFX_OOB_14</sub>	Charge to send a Sigfox out of band message	AT\$S0		0.28		С
Q <sub>SFX_OOB_14</sub>	Charge to send a bit	AT\$SB=0		0.19		С
Q <sub>SFX_OOB_14</sub>	Charge to send a bit with downlink receive message	AT\$SB=0,1		0.33		С
Q <sub>SFX_LFR_14</sub>	Charge to send the longest possible Sigfox frame (12 byte)	AT\$SF=00112233445566778899aabb		0.37		С
Q <sub>SFX_LFR_14</sub>	Charge to send the longest possible Sigfox frame (12 byte) with downlink receive	AT\$SF=00112233445566778899aabb,1		0.46		С
Transmit at 0 dE	Bm Output Power / Receive (Notes 1 and	d 2)		•		
I <sub>TXMODAVG_14</sub>	Modulated Transmitter Current			21.0		mA
Q <sub>SFX_OOB_0</sub>	Charge to send a Sigfox out of band message	AT\$S0		0.12		С
Q <sub>SFX_OOB_0</sub>	Charge to send a bit	AT\$SB=0		0.08		С
Q <sub>SFX_OOB_0</sub>	Charge to send a bit with downlink receive message	AT\$SB=0,1		0.14		С
Q <sub>SFX_LFR_0</sub>	Charge to send the longest possible Sigfox frame (12 byte)	AT\$SF=00112233445566778899aabb		0.27		С
Q <sub>SFX_LFR_0</sub>	Charge to send the longest possible Sigfox frame (12 byte) with downlink	AT\$SF=00112233445566778899aabb,1		0.29		С

 The output power of AX-SIGFOX modules can be programmed in 1 dB steps from 0 dBm – 14 dBm. They are optimized for best power efficiency at 14 dBm output power. For modules optimized for other output power values e.g. 0 dBm transmission with 10 mA please contact us.

2. Antenna gain not included.

receive

#### **Typical Current Waveform**



Figure 4. Typical Current Waveform for a Maximum Length Frame with Downlink Receive at 14 dBm Output Power

#### **Battery Life Calculation Example**

Scenario for example calculation:

- 2 AAA Alkaline batteries in series
- One OOB frame transmission per day at 14 dBm output power
- Four maximum length frames with downlink receive per day at 14 dBm output power
- Device in sleep mode when no other activity
- Neglecting battery self discharge

2 AAA alkaline capacity	1500 mAh * 3600 s/h	5400 C
Sleep charge per day	1.6 μA * 86400 s	0.14 C/day
OOB frame transmission		0.28 C/day
Frame transmission with downlink	4 * 0.46 C/day	1.84 C/day
Total Charge consumption		2.26 C/day
Battery life		6.5 Years

#### Table 3. LOGIC

Symbol	Description	Condition	Min	Тур	Max	Units		
Digital Input	Digital Inputs							
V <sub>T+</sub>	Schmitt trigger low to high threshold point	VDD = 3.3 V		1.55		V		
V <sub>T-</sub>	Schmitt trigger high to low threshold point			1.25		V		
V <sub>IL</sub>	Input voltage, low				0.8	V		
V <sub>IH</sub>	Input voltage, high		2.0			V		
V <sub>IPA</sub>	Input voltage range, GPIO[3:0]		-0.5		VDD	V		
V <sub>IPBC</sub>	V <sub>IPBC</sub> Input voltage range, GPIO[9:4], UART_RX, RESET_N		-0.5		5.5	V		
۱L	Input leakage current		-10		10	μΑ		
R <sub>PU</sub>	Programmable pull-up resistance			65		kΩ		
Digital Outputs								

I <sub>OH</sub>	Output Current, high Ports GPIO[9:0], UART_TX, TX_LED, RX_LED, CPU_LED, RADIO_LED	V <sub>OH</sub> = 2.4 V	8		mA
I <sub>OL</sub>	Output Current, Iow GPIO[9:0], UARTTX, TXLED, RXLED, TXLED, CPULED	V <sub>OL</sub> = 0.4 V	8		mA
l <sub>oz</sub>	Tri-state output leakage current		-10	10	μΑ

#### Table 4. TRANSMITTER

Symbol	Description	Condition	Min	Тур	Max	Units
SBR	Signal bit rate			100		bps
f <sub>carrier</sub>	Carrier frequency			868.13		MHz
PTX <sub>min</sub>	Lowest Transmitter output power	AT\$CW=868130000,1,0		0		dBm
PTX <sub>max</sub>	Highest Transmitter output power	AT\$CW=868130000,1,14 (Note 1)		14		dBm
PTX <sub>step</sub>	Programming step size output power			1		dB
dTX <sub>temp</sub>	Transmitter power variation vs. temperature	–40°C to +85°C		±0.5		dB
dTX <sub>Vdd</sub>	Transmitter power variation vs. VDD	1.8 to 3.3 V		±0.5		dB
PTX <sub>harm2</sub>	Emission @ 2 <sup>nd</sup> harmonic			-51		dBc
PTX <sub>harm3</sub>	Emission @ 3 <sup>rd</sup> harmonic			-63		
PTX <sub>harm4</sub>	Emission @ 4 <sup>th</sup> harmonic			-84		

1. Antenna gain not included.

#### Table 5. RECEIVER

Symbol	Description	Condition	Min	Тур	Max	Units
SBR	Signal bit rate			600		bps
f <sub>carrier</sub>	Carrier frequency			869.525		MHz
IS	Sensitivity	AT\$SB=x,1, AT\$SF=x,1, AT\$SR PER < 0.1		-126		dBm
BLK	Blocking at ±10 MHz offset	Wanted signal is 3 dB above the typical sensitivity limit (PER = 0.1) and the blocker is a continuous wave		78		dB

#### Table 6. ADC / TEMPERATURE SENSOR

Symbol	Description	Condition	Min	Тур	Max	Units	
ADCRES	ADC resolution			10		bit	
VADCREF	ADC reference voltage		0.95	1	1.05	V	
Z <sub>ADC00</sub>	Input capacitance				2.5	pF	
DNL	Differential nonlinearity			± 1		LSB	
INL	Integral nonlinearity			± 1		LSB	
OFF	Offset			3		LSB	
GAIN_ERR	Gain error			0.8		%	
ADC in Differ	ential Mode						
VABS_DIFF	Absolute voltages & common mode voltage in differential mode at each input		0		VDD	V	
V <sub>FS_DIFF01</sub>	Full swing input for differential signals	Gain x1	-500		500	mV	
V <sub>FS_DIFF10</sub>		Gain x10	-50		50	mV	
ADC in Single	e Ended Mode				-		
V <sub>MID_SE</sub>	Mid code input voltage in single ended mode			0.5		V	
VIN_SE00	Input voltage in single ended mode		0		VDD	V	
V <sub>FS_SE01</sub>	Full swing input for single ended signals	Gain x1	0		1	V	
Temperature	Temperature Sensor						
T <sub>RNG</sub>	Temperature range		-40		85	°C	
T <sub>ERR_CAL</sub>	Temperature error			± 2		°C	

#### **COMMAND INTERFACE**

#### Serial Parameters: 9600, 8, N, 1

The AX–SIGFOX modules use the UART (pins UART\_TX, UART\_RX) to communicate with a host and use a bitrate of 9600 baud, no parity, 8 data bits and one stop bit.

#### Power Modes State Diagram



#### Standby Mode

After Power–Up and after finishing a Sigfox transmission, the AX–SIGFOX modules enter Standby mode. In Standby mode, AX–SIGFOX modules listen on the UART for commands from the host. Also, OOB frames are transmitted whenever the OOB timer fires. To conserve power, the AX–SIGFOX modules can be put into Sleep mode or turned off (Deep Sleep mode) completely.

#### Sleep Mode

The command **AT\$P=1** is used to put the AX–SIGFOX modules into Sleep mode. In this mode, only the wakeup timer for out–of–band messages is still running. To wake up the AX–SIGFOX module from Sleep mode, toggle the UART\_RX pin, e.g. by sending a break (break is an RS232 framing violation, i.e. at least 10 bit durations low). When an Out of Band (OOB) message is due, AX–SIGFOX modules automatically wake up to transmit the message, and then return to Sleep mode.

It is strongly recommended to put AX–SIGFOX modules into sleep mode when they are not being used.

#### Deep Sleep Mode

In Deep Sleep mode, the AX–SIGFOX modules are completely turned off. Deep Sleep mode can be activated with the command **AT\$P=2**. To wake–up from Deep Sleep mode the pin GPIO9 is pulled to GND.

When using Deep Sleep mode, two things should be kept in mind:

Everything is turned off, timers are not running at all and all settings are lost (use **AT\$WR** to save settings to flash before

entering Deep Sleep mode). Out-of-band messages will therefore not be sent.

The pins states are frozen in Deep Sleep mode. The user must ensure that this will not result in conditions at the module boundary that draw a lot of current.

#### AT Commands

Numerical Syntax

	•
hexdigit	::= [0-9A-Fa-f]
hexnum	::= "0x" hexdigit+
decnum	::= "0"   [1-9] [0-9]*
octnum	::= "0" [0-7]+
binnum	::= "0b" [01]+
bit	::= [01]
optnum	::= "-1"
frame	::= (hexdigit hexdigit)+
uint	::= hexnum   decnum   octnum   binnum
uint opt	::= uint   optnum

#### Command Syntax

A command starts with 'AT' (note that everything is case sensitive!), continues with the actual command followed by parameters (if any) and ends with any kind of whitespace (space, tab, newline etc.)

If incorrect syntax is detected ("parsing error") all input is ignored up until the next whitespace character.

Also note that any number can be entered in any format (Hexadecimal, Decimal, Octal and binary) by adding the corresponding prefix ('0x', '0', '0b'). The only exception is the 'Send Frame' command (AT\$SF) which expects a list of hexadecimal digits without any prefix.

#### Return Codes

A successful command execution is indicated by sending 'OK'. If a command returns a value (e.g. by querying a register) only the value is returned.

#### Examples

Bold text is sent to AX-SIGFOX module.

Here, we execute command 'I' to query some general information.

#### AT\$I=0

AXSEM AT Command Interface

This sends a Sigfox frame containing { 0xAA : 0xBB : 0x12: 0x34 } without waiting for a response telegram:

AT\$SF=aabb1234

OK

This sends a Sigfox frame containing { 0x00 : 0x11 : 0x22: 0x33 : 0x44 }, then waits for a downlink response telegram, which in this example contains { 0xAA : 0xBB : 0xCC : 0xDD }.

AT\$SF=0011223344,1 OK RX=AA BB CC DD The 'CB' command sends out a continuous pattern of bits, in this case 0xAA = 0b10101010:

AT\$CB=0xAA,1

OK

This transitions the device into sleep mode. Out–of–band transmissions will still be triggered. The UART is powered

#### Table 7. COMMANDS

down. The module can be woken up by a low level on the UART signal, i.e. by sending break.

AT\$P=1 OK

Command	Name	Description			
AT	Dummy Command	Just returns 'OK' and does nothing else. Can be used to check communication.			
AT\$SB=bit[,bit]	Send Bit	Send a bit sta module shou	atus (0 or 1). Op Id receive a dow	tional bit flag indicates if AX–SIGFOX nlink frame.	
AT\$SF=frame[,bit]	Send Frame	Send payload AX-SIGFOX	d data, 1 to 12 b module should	ytes. Optional bit flag indicates if receive a downlink frame.	
AT\$SO	Manually send out of band message	Send the out-of-band message.			
ATSuint?	Get Register	Query a spec "Registers" fo	cific configuration or a list of registe	n register's value. See chapter ers.	
ATSuint=uint	Set Register	Change a co	nfiguration regis	ter.	
AT\$IF=uint	Set TX Frequency	Set the output	it carrier macro	channel for Sigfox frames.	
AT\$IF?	Get TX Frequency	Get the curre	ently chosen TX	frequency.	
AT\$DR=uint	Set RX Frequency	Set the reception carrier macro channel for Sigfox frames.			
AT\$CW=uint,bit[,uint_opt]	Continuous Wave	To run emission tests for Sigfox certification it is necessary to send a continuous wave, i.e. just the base frequency without any modula- tion. Parameters:			
		Name	Range	Description	
		Frequency	800000000- 9999999999, 0	Continuous wave frequency in Hz. Use 868130000 for Sigfox or 0 to keep previous frequency.	
		Mode	0, 1	Enable or disable carrier wave.	
		Power	0–14	dBm of signal   Default: 14	
AT\$CB=uint_opt,bit	Test Mode: TX constant byte	For emission first paramete (pseudo-)rar	testing it is usef er specifies the b ndom pattern. Pa	iul to send a specific bit pattern. The byte to send. Use '–1' for a arameters:	
		Name	Range	Decsription	
		Pattern	0–255, –1	Byte to send. Use '-1' for a (pseudo-)random pattern.	
		Mode	0, 1	Enable or disable pattern test mode.	
AT\$T?	Get Temperature	Measure inte Celsius.	rnal temperature	e and return it in 1/10 <sup>th</sup> of a degree	
AT\$V?	Get Voltages	Return currer transmission	nt voltage and vo in mV.	oltage measured during the last	

#### Table 7. COMMANDS

Command	Name	Description		
AT\$I=uint	Information	Display various product information: 0: Software Name & Version Example Response: AX-Sigfox 1.0.6-ETSI 1: Contact Details Example Response: support@axsem.com 2: Silicon revision lower byte Example Response: 8F 3: Silicon revision upper byte Example Response: 00 4: Major Firmware Version Example Response: 1 5: Minor Firmware Version Example Response: 0 6: Firmware Revision Example Response: 3 7: Firmware Variant (Frequency Band etc. (EU/US)) Example Response: 3 7: Firmware VCS Version Example Response: v1.0.2-36 9: SIGFOX Library Version Example Response: DL0-1.4 10: Device ID Example Response: 00012345 11: PAC Example Response: 0123456789ABCDEF		
AT\$P=uint	Set Power Mode	To conserve power, the AX–SIGFOX module can be put to sleep manually. Depending on power mode, you will be responsible for waking up the AX–SIGFOX module again! 0: software reset (settings will be reset to values in flash) 1: sleep (send a break to wake up) 2: deep sleep (toggle GPIO9 or RESET_N pin to wake up; the AX–SIGFOX module is not running and all settings will be reset!)		
AT\$WR	Save Config	Write all settings to flash (RX/TX frequencies, registers) so that they survive reset/deep sleep or loss of power. Use AT\$P=0 to reset the AX-SIGFOX module and load settings from flash.		
AT:Pn?	Get GPIO Pin	Return the setting of the GPIO Pin $n$ ; $n$ can range from 0 to 9. A character string is returned describing the mode of the pin, fol- lowed by the actual value. If the pin is configured as analog pin, then the voltage (range 01 V) is returned. The mode characters have the following meaning:		
		Mode Description		
		0 Pin drives low   1 Pin drives high   Z Pin is high impedance input   U Pin is input with pull-up   A Pin is analog input (GPIO pin 03 only)   T Pin is driven by clock or DAC (GPIO pin 0 and 4 only)		
		The default mode after exiting reset is U on all GPIO pins.		
AT:Pn=?	Get GPIO Pin Range	Print a list of possible modes for a pin. The table below lists the response.		
		Pin Modes		
		P0 0, 1, Z, U, A, T   P1 0, 1, Z, U, A   P2 0, 1, Z, U, A   P3 0, 1, Z, U, A   P4 0, 1, Z, U, T   P5 0, 1, Z, U   P6 0, 1, Z, U   P7 0, 1, Z, U   P8 0, 1, Z, U   P9 0, 1, Z, U		

#### Table 7. COMMANDS

Command	Name	Description			
AT:Pn=mode	Set GPIO Pin	Set the GPIO pin mode. For a list of the modes see the command AT:Pn?			
AT:ADC Pn[-Pn[(1V 10V)]]?	Get GPIO Pin Analog Voltage	Measure the voltage applied to a GPIO pin. The command also allows measurement of the voltage difference across two GPIO pins. In differential mode, the full scale range may also be specified as 1 V or 10 V. Note however that the pin input voltages must not exceed the range 0VDD. The command returns the result as fraction of the full scale range (1 V if none is specified). The GPIO pins referenced should be initialized to analog mode before issuing this command.			
AT:SPI[(A B C D)]=bytes	SPI Transaction	This command clocks out <i>bytes</i> on the SPI port. The clock frequency is 312.5 kHz. The command returns the bytes read on MISO during output. Optionally the clocking mode may be specified (default is A):			
		Mode	<b>Clock Inversion</b>	Clock Phase	
		A B C D	normal normal inverted inverted	normal alternate normal alternate	
AT:CLK=freq,reffreq	Set Clock Generator	SEL (GPIOx) MOSI MISO (A B C D Note that SEL, and must instea (AT:Pn=0 1). Output a square w the square wave is are 2000000, 100 312500, 156250. F	D7 (D6 (D5 ) D4 D7 (D6 (D5 ) D4 D4 (D5 ) D4 D4 (D5 ) D4 D4 (D5 ) D4 (D5 ) D4 D4 (D5 ) D4 D4 (D5 ) D4 (D5 ) D4 D4 (D5	erated by this command, andard GPIO commands to T mode. The frequency of Possible values for reffreq 20000, 1250000, 625000, are 065535.	
AT:CLK=OFF	Turn off Clock Generator	Switch off the clock generator			
AT:CLK?	Get Clock Generator	Return the settings of the clock generator. Two numbers are returned, freq and reffreq.			
AT:DAC=value	Set ΣΔ DAC	Output a $\Sigma\Delta$ DAC value on the pin(s) set to T mode. Parameter value may be in the range –3276832767. The average output voltage is (1/2 + value / 2^17) × VDD. An external low pass filter is needed to get smooth output voltages. The modulation frequency is 20 MHz. A possible low pass filter choice is a simple RC low pass filter with R = 10 k\Omega and C = 1 $\mu F.$			
AT:DAC=OFF	Turn off $\Sigma\Delta$ DAC	Switch off the DAC			
AT:DAC?	Get $\Sigma\Delta$ DAC	Return the DAC va	alue		

#### Table 8. REGISTERS

Number	Name	Description	Default	Range	Units
300	Out Of Band Period	AX–SIGFOX module sends periodic static messages to indicate that they are alive. Set to 0 to disable.	24	0–24	hours
302	Power Level	The output power of the radio.	14	0–14	dBm

#### **Table 9. DEVICE NUMBERS**

Protocol	MINISTAMP	ANTSTAMP	
SIGFOX 868 MHz	AX-SF10-MINI21-868	AX-SF10-ANT21-868	

#### **Table 10. DEVICE VERSIONS**

Part Number	AT\$I=2	AT\$I=3	AT\$I=4	AT\$I=5
AX-SF10-MINI21-868	0x8F	0x51	0x01	0x00
AX-SF10-ANT21-868	0x8F	0x51	0x01	0x00

#### Life Support Applications

This product is not designed for use in life support appliances, devices, or in systems where malfunction of this product can reasonably be expected to result in personal injury. ON Semiconductor customers using or selling this product for use in such applications do so at their own risk and agree to fully indemnify ON Semiconductor for any damages resulting from such improper use or sale.

#### Sigfox and Sigfox Ready are registered trademarks of Sigfox SARL.

ON Semiconductor and are trademarks of Semiconductor Components Industries, LLC dba ON Semiconductor or its subsidiaries in the United States and/or other countries. ON Semiconductor owns me rights to a number of patents, trademarks, copyrights, trade secrets, and other intellectual property. A listing of ON Semiconductor's product/patent coverage may be accessed at www.onsemi.com/site/pdf/Patent-Marking.pdf. ON Semiconductor reserves the right to make changes without further notice to any products herein. ON Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does ON Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation special, consequential or incidental damages. Buyer is responsible for its products and applications using ON Semiconductor roducts, "huclufing compliance with all laws, regulations and safety requirements or standards, regardless of any support or applications information provided by ON Semiconductor." "Typical" parameters which may be provided in ON Semiconductor dates thesets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. ON Semiconductor does not convey any license under its patent rights or the rights of others. ON Semiconductor and is officers, employees or use ON Semiconductor products for any such unitended or inauthorized application, Buyer shall indemnify and hold ON Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly, ori indirectly, any claim of personal injury or death associated with such unintended or unauthorized application. Buyer shall indemnif

#### PUBLICATION ORDERING INFORMATION

#### LITERATURE FULFILLMENT:

Literature Distribution Center for ON Semiconductor 19521 E. 32nd Pkwy, Aurora, Colorado 80011 USA Phone: 303-675-2175 or 800-344-3860 Toll Free USA/Canada Fax: 303-675-2176 or 800-344-3867 Toll Free USA/Canada Email: orderlit@onsemi.com N. American Technical Support: 800–282–9855 Toll Free USA/Canada Europe, Middle East and Africa Technical Support: Phone: 421 33 790 2910

Japan Customer Focus Center Phone: 81–3–5817–1050 ON Semiconductor Website: www.onsemi.com

Order Literature: http://www.onsemi.com/orderlit

For additional information, please contact your local Sales Representative