



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





## BT-120 Breaker tracers

The Amprobe breaker finders work on energized systems and are designed to quickly and easily identify breakers in residential and commercial environments. Automatic sensitivity adjustment removes ambiguity from the results of the tracing, and the receiver will clearly and quickly identify the breaker with sound and light.

- Used to identify circuit breakers
- Automatic sensitivity adjustment is easier to use and faster than the manual one
- Microprocessor controlled design provides extremely accurate readings (always finds the right breaker)
- Durable and dependable
- BT-120 works with standard 120V breakers
- UL Listed

### No hassle warranty

*No waiting.*

*No shipping charges.*



Our commitment to high-quality products and customer service is demonstrated by our industry exclusive "No Hassle" warranty. In the unlikely event that an Amprobe Test Tool requires warranty service, any of our local dealers are authorized to replace it, on the spot.

(note: \$500 MSLP limit)





## BT-120 Breaker tracers

### Specifications

Voltage Range	90 to 120V
Operating Frequency	50 - 60 Hetz
Storage Temperature	0-40 Degrees C
Operating Temperature	0-40 Degrees C
Sensitivity Adjustment	Automatic
Power Supply	9-Volt Alkaline Battery (Receiver Only)
Transmitter Polarity	Automatic
Humidity	80% RH (non condensing)
Environmental Conditions	For Indoor use, For Altitudes up to 2000 m, Pollution Degree 2
Installation Category II	
Caution	HTP-HVL cord assembly to be used with Circuit Detective Transmitter only according to instructions

### Included Accessories

Users Manual

### Amprobe® Test Tools

website: [www.Amprobe.com](http://www.Amprobe.com)

email: [info@amprobe.com](mailto:info@amprobe.com)

Everett, WA 98203

Tel: 877-AMPROBE

### Amprobe® Test Tools Europe

In den Engematten 14

79286 Glottertal, Germany

Tel.: +49 (0) 7684 8009 - 0