

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



#### Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China









### AirPrime BX310x Wi-Fi/BT Module

#### **Product Technical Specification**





#### Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

#### Safety and Hazards

Do not operate the Sierra Wireless modem in areas where blasting is in progress, where explosive atmospheres may be present, near medical equipment, near life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the Sierra Wireless modem MUST BE IN AIRPLANE MODE OR POWERED OFF. The Sierra Wireless modem can transmit signals that could interfere with this equipment.

Do not operate the Sierra Wireless modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sierra Wireless modem **MUST BE IN AIRPLANE MODE OR POWERED OFF.** When operating, the Sierra Wireless modem can transmit signals that could interfere with various onboard systems.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Sierra Wireless modems may be used at this time.

The driver or operator of any vehicle should not operate the Sierra Wireless modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

#### Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

Patents This product may contain technology developed by or for Sierra Wireless Inc. This

product is manufactured or sold by Sierra Wireless Inc. or its affiliates under one or

more patents licensed from MMP Portfolio Licensing.

**Copyright** ©2017 Sierra Wireless. All rights reserved.

**Trademarks** Sierra Wireless<sup>®</sup>, AirPrime<sup>®</sup>, AirLink<sup>®</sup>, AirVantage<sup>®</sup> and the Sierra Wireless logo are

registered trademarks of Sierra Wireless, Inc.

Windows<sup>®</sup> and Windows Vista<sup>®</sup> are registered trademarks of Microsoft Corporation.

Other trademarks are the property of their respective owners.

#### Contact Information

Sales information and technical support, including warranty and returns	Web: sierrawireless.com/company/contact-us/ Global toll-free number: 1-877-687-7795 6:00 am to 5:00 pm PST
Corporate and product information	Web: sierrawireless.com

#### Revision History

Revision number Changes		Changes
1 August 2017 Creation (limited release)		Creation (limited release)
2 October 2017 General release		General release



1: Introduction
1.1 Module Variants
1.2 General RF/Software Features
1.2.1 Wi-Fi
1.2.2 Bluetooth
1.2.3 Interfaces
1.2.4 Configuration Utility
1.3 General Hardware Features
1.3.1 Physical Dimensions and Connection Interface
2: Functional Specifications1
2.1 Architecture
2.2 Features
3: Technical Specifications1
3.1 Environmental1
3.2 Power Supply Ratings
3.2.1 Power Management1
3.2.2 Current Consumption
3.3 RF1
3.3.1 Generic Radio
3.3.2 Wi-Fi Radio
3.3.3 Bluetooth Radio
3.4 Electrical Specifications
3.4.1 Absolute Maximum Ratings
3.5 Mechanical
3.6 Mechanical Drawings
3.7 Antenna
4: Interfaces Specification
4.1 Overview
4.2 UART

4.3 ADC
4.4 Voltage Measurement
4.5 I2C Interface
4.5.1 Application
4.6 I2S Interface (Digital Audio)
4.7 General Purpose Input/Output (GPIO)
4.8 SPI Bus
4.9 Secure Digital IO (SDIO) Interface
4.10 Module Enable
4.11 Clock
4.12 PWM
5: Regulatory Certifications
United States
Canada31
Bluetooth Qualification Program (BQP)
6: Pinout
6.1 Pin Configuration
6.2 Pin Description
7: Abbreviations



Figure 2-1: AirPrime BX310x Application Schematic	11
Figure 2-2: Block diagram	12
Figure 3-1: AirPrime BX3100 Mechanical Drawing	21
Figure 3-2: AirPrime BX3105 Mechanical Drawing	22
Figure 4-1: Example of I2C Bus Application	25
Figure 6-1: Pin Configuration (Bottom View)	33



#### List of Tables

Table 1-1: Supported RF Frequencies
Table 1-2: AirPrime BX310x Dimensions
Table 1-3: LGA Pad Types
Table 2-1: AirPrime BX310x Capabilities
Table 3-1: Environmental Specifications
Table 3-2: Power Supply Pins
Table 3-3: Power Modes—Descriptions
Table 3-4: Power Modes—Typical Current Consumption
Table 3-5: RF Current Consumption Specifications
Table 3-6: Generic Radio Characteristics
Table 3-7: Generic Radio Characteristics
Table 3-8: Generic Radio Characteristics
Table 3-9: Absolute Maximum Ratings
Table 3-10: Recommended Operating Conditions
Table 4-1: UART0 Pins
Table 4-2: ADC Interface Pins
Table 4-3: Voltage-measurement GPIO Pins
Table 4-4: I2C Interface Pins
Table 4-5: I2S Interface Pins
Table 4-6: GPIO Pins (Dedicated)
Table 4-8: SPI Pin Descriptions
Table 4-7: GPIO Pins (Alternate function)
Table 4-9: SDIO Pin Descriptions
Table 4-10: Enable Pin Description
Table 6-1: Pin Definitions
Table 7-1: Acronyms and Definitions

#### >> 1: Introduction

This document defines and illustrates the AirPrime BX310x (BX3100, BX3105) Wi-Fi/BT Host-less module's high-level product features, interfaces, and hardware features (including electrical and mechanical performance criteria).

#### 1.1 Module Variants

AirPrime BX310x module variants include:

- AirPrime BX3100—External antenna connection
- AirPrime BX3105—Embedded antenna

#### 1.2 General RF/Software Features

The AirPrime BX310x is a low-power, small form-factor self-contained Wi-Fi/Bluetooth (Wi-Fi/BT) module.

With an embedded software suite, the BX310x is an ideal solution for developers who want to guickly and cost-effectively integrate Wi-Fi/BT functionality into their products.

The following table summarizes the module's supported wireless frequencies:

Table 1-1: Supported RF Frequencies

Technology	RF band	Notes	
Wi-Fi	• 2.4GHz (2.400–2.485 GHz)	<ul><li>802.11b/g/n/e/i</li><li>Max data rate—MCS7 HT40 150 Mbps</li></ul>	
Bluetooth	v4.2 BR/EDR and BLE compliant		

#### 1.2.1 Wi-Fi

The AirPrime BX310x supports 2.4 GHz Wi-Fi operation. Key features include:

- TCP/IP
- 802.11 b/g/n/e/i
- Connection methods—BSS STA, SoftAP, Wi-Fi Direct (Wi-Fi P2P)
- Transmit power—Adjustable, up to 21 dBm (maximum)

For a list of additional supported Wi-Fi functionality, protocols, and features, see Features on page 12.

#### 1.2.2 Bluetooth

The AirPrime BX310x supports 2.4 GHz Bluetooth classic and BLE operation. Key features include:

- Bluetooth v4.2 BR/EDR and BLE compliant
- SPP (Serial Port Profile)

For a list of additional supported Bluetooth functionality, protocols, and features, see Features on page 12.

#### 1.2.3 Interfaces

The AirPrime BX310x provides the following interfaces and peripheral connectivity:

- Power supply—See Power Supply Ratings on page 15.
- RF—See RF on page 18.
- UART serial link—See UART on page 23.
- ADC—See ADC on page 24.
- Voltage measurement—See Voltage Measurement on page 24.
- I<sup>2</sup>C—See I2C Interface on page 24.
- Digital audio (I<sup>2</sup>S)—See I2S Interface (Digital Audio) on page 26.
- GPIOs—See General Purpose Input/Output (GPIO) on page 26.
- SPI bus—See SPI Bus on page 27.
- SDIO—See Secure Digital IO (SDIO) Interface on page 28.
- Module enable—See Module Enable on page 28.
- System clock outputs—See Clock on page 29.
- PWM—See PWM on page 29.

#### 1.2.4 Configuration Utility

The AirPrime BX310x includes a browser-based utility for device configuration. For usage details, refer to the AirPrime BX Series Development Kit User Guide available at source.sierrawireless.com (forthcoming).

#### 1.3 General Hardware Features

#### 1.3.1 Physical Dimensions and Connection Interface

AirPrime BX310x modules are compact, robust, fully shielded and labeled modules with the dimensions noted in Table 1-2.

Table 1-2: AirPrime BX310x Dimensions<sup>a</sup>

	Nominal			
Parameter	BX3100 <sup>b</sup>	BX3105	Tolerance	Units
Length	11.5	13.5	±0.10	mm
Width	9.5	11.5	±0.10	mm
Thickness	2.4	2.4	±0.20	mm
Weight	TBD	TBD	TBD	g

a. Dimensions are accurate as of the release date of this document.

The AirPrime BX310x module is an LGA form factor device. All electrical and mechanical connections are made through the 70 Land Grid Array (LGA) pads on the bottom side of the PCB. (See Figure 6-1 on page 33 for details.)

BX3100 is a CF3 xSmall module, which belongs to the Common Flexible Form Factor (CF3) family of WWAN modules

The LGA pads have the following distribution:

Table 1-3: LGA Pad Types

Pad Type/Quantity		Dimensions	Pitch	
Signal Pads	54 outer pads	0.75x0.35 mm	0.65 mm	
Ground Pads	16 inner pads	1.0x1.0 mm	1.83 mm/1.48 mm	

# 2: Functional Specifications

## Architecture

The following figure presents an overview of the AirPrime BX310x module's internal architecture and external interfaces.




Figure 2-1: AirPrime BX310x Application Schematic




Figure 2-2: Block diagram

#### 2.2 Features

Table 2-1 summarizes the AirPrime BX310x module's RF (Wi-Fi and Bluetooth), Power, software, and hardware capabilities.

Note: Table contents are preliminary and subject to change.

Table 2-1: AirPrime BX310x Capabilities

Feature	Description	
Module	<ul> <li>Secure boot</li> <li>Secure update</li> <li>FOTA (Firmware update Over The Air)</li> <li>Sierra Wireless AirVantage support</li> <li>CF3-compliant footprint (BX3100)</li> </ul>	

Table 2-1: AirPrime BX310x Capabilities (Continued)

Feature	Description	
Wi-Fi	<ul> <li>Protocols: <ul> <li>802.11 b/g/n/e/i</li> <li>802.11 n (2.4 GHz), up to 150 Mbps; MCS0-7 in 20/40 MHz bandwidths</li> <li>Receiving STBC (Space-time Block Code) 2x1</li> <li>802.11 e: QoS for wireless multimedia technology</li> <li>Additional 802.11i security features (pre-authentication, TSN, etc.)</li> <li>WMM-PS, UAPSD</li> <li>A-MPDU, A-MSDU aggregation</li> <li>Block ACK (RTS/CTS/ACK/BA)</li> <li>Fragmentation/defragmentation</li> <li>CCMP (CBC-MAC, counter model), TKIP (MIC, RC4), WAPI (SMS4), WEP (RC4), CRC</li> <li>Frame encapsulation (802.11h/RFC 1042)</li> <li>Pre-authentication, TSN</li> </ul> </li> <li>Supported channels—1–14</li> <li>Autoconnection—After device reset, automatically connects to available AP based on previous configuration</li> <li>Infrastructure BSS Station mode/SoftAP mode: AP mode, STA mode, concurrent AP/STA mode</li> <li>Up to 8 simultaneous Wi-Fi clients</li> <li>IP configuration—IP address in STA mode via DHCP or static assignment</li> <li>Authentication (security) modes: WPA, WPA2, WPA/WPA2, WPA2 Enterprise</li> <li>UMA-compliant and certified</li> <li>Open interface for various upper layer authentication schemes over EAP (e.g. TLS, PEAP, LEAP, SIM, AKA, customer-specific)</li> <li>Adaptive rate fallback algorithm</li> <li>Automatic retransmission/response on slow hosts</li> </ul>	

Table 2-1: AirPrime BX310x Capabilities (Continued)

Feature Description		
Bluetooth	<ul> <li>Bluetooth v4.2 BR/EDR and BLE compliant</li> <li>Supported channels: BT Classic—0–78; BLE—0–39</li> <li>Supported v4.2 modes: BR (Basic Rate); EDR (Enhanced Data Rate); LE (Low Energy)</li> <li>BT classic mandatory features</li> <li>BT low-energy mandatory features</li> <li>Class 1/Class 2/Class 3 transmitter without external power amplifier</li> <li>Class 1 operation without external PA</li> <li>Enhanced power control (&gt;30 dB dynamic control range)</li> <li>+10 dBm transmitting power</li> <li>NZIF receiver with -98 dBm sensitivity</li> <li>Modulation—p/4 DQPSK, 8 DPSK</li> <li>ACL, SCO, eSCO, AFH</li> <li>Adaptive Frequency Hopping (AFH)</li> <li>BT 4.2 controller and host stack</li> <li>Service Discover Protocol (SDP)</li> <li>General Access Profile (GAP)</li> <li>Security Manage Protocol (SMP)</li> <li>Bluetooth Low Energy (BLE)</li> <li>ATT/GATT</li> <li>BLE Beacon</li> <li>SPP, RFCOMM</li> <li>Profiles: SPPAutoconnection—After device reset, automatically connects to available AP based on previous configuration.</li> <li>UART features: GATT profiles, Data transfer (HTTP, HTTPS, MQTT, TCP/UDP), Define personal services</li> <li>Roles—Simultaneous Central (access point)/Peripheral (client)</li> <li>Simultaneous BT Classic and BLE connections</li> <li>Simultaneous BT Classic and BLE connections</li> </ul>	
Configuration	<ul> <li>PCM/I2S</li> <li>Device configuration methods:</li> <li>Built-in web-based configuration utility. See Configuration Utility on page 9.</li> <li>AT commands available over UART, Wi-Fi, and BT links. Refer to AirPrime BX310x AT Command Reference at source.sierrawireless.com.</li> </ul>	
Security	<ul> <li>All standard IEEE802.11 security features, including WFA, WPA/WPA2, WAPI</li> <li>Secure boot</li> <li>Flash encryption</li> <li>Cryptographic hardware acceleration: AES, HASH (SHA-2) library, RSA, ECC, Random Number Generator (RNG)</li> </ul>	
Power management	Multiple power modes to reduce power consumption: Active, Radio off, Light sleep, Deep sleep, Hibernation Sleep Patterns: Association sleep pattern, ULP sensor-monitored pattern	

#### >> 3: Technical Specifications

#### 3.1 Environmental

The environmental specifications for operation and storage of the AirPrime BX310x are defined in Table 3-1.

Table 3-1: Environmental Specifications

Parameter	Range
Ambient Operating Temperature	-40°C to +85°C
Ambient Storage Temperature	-40°C to +105°C (Recommended)
Ambient Humidity	TBD

#### 3.2 Power Supply Ratings

DC power is supplied via the pins described in Table 3-2 on page 15.

Note: Operation above the maximum specified operating voltage (see Table 3-10 on page 20) is not recommended, and specified typical performance or functional operation of the device is neither implied nor guaranteed.

Table 3-2: Power Supply Pins

Pin	Name	Voltage	Direction	Function
33	VGPIO	3.3V	Output	Supply voltage reference for secondary I2C interface (pins 53/54)
50	VDD_3V3_RF	2.7–3.6V	Input	RF/Analog signal power supply
51	VDD_3V3_PA	2.7–3.6V	Input	Internal Power Amplifier power supply
52	VDD_3V3_BB	1.8–3.3V	Input	Baseband/Digital I/O power supply

#### 3.2.1 Power Management

The AirPrime BX310x switches between several power modes to minimize current consumption. The following tables describe these modes and their typical current consumption:

Table 3-3: Power Modes — Descriptions

Power Mode	CPU	Wi-Fi/BT radio/ baseband	RTC	ULP co- processor	Notes
Active	On	On	On	On	Fully functional
Radio off	On	Off	On	On	
Light sleep	Pause	Off	On	On	Wake up events will wake the module.
Deep sleep	Off	Off	On	On/Off	Connection data stored in RTC memory
Hibernate	Off	Off	Off	Off	Only RTC timer or specific RTC GPIOs can wake the module.

Table 3-4: Power Modes — Typical Current Consumption

Power Mode	Description	Current Consumption
	Wi-Fi Tx packet 13 dB~21 dBm	160~260 mA
Active (RF on)	Wi-Fi/BT Tx packet 0 dBm	120 mA
Active (111 on)	Wi-Fi/BT Rx and listening	80~90 mA
	Association sleep patter (by Light-sleep)	0.9 mA@DTIM3, 1.2 mA@DTIM1
		Max speed: 20 mA
Modem-sleep	CPU is powered on.	Normal speed: 5~10 mA
		Slow speed: 3 mA
Light-sleep	-	0.8 mA
	ULP processor powered on	0.15 mA
Deep-sleep	ULP sensor-monitored pattern	25 μA @ 1% duty
	RTC timer + RTC memory	10 μΑ
Hibernation	RTC timer only	5 μΑ

#### 3.2.2 Current Consumption

Current consumption measurements are conducted at the module antenna port with 3.0 V supply at  $25^{\circ}$ C ambient temperature.

All transmitter measurements are based on 90% duty cycle and continuous transmit mode.

Table 3-5: RF Current Consumption Specifications

Mode	Min	Тур	Max	Unit
Transmit 802.11b, DSSS 1 Mbps, POUT=+18.0 dBm	-	225	-	mA
Transmit 802.11b, CCK 11 Mbps, POUT=+18.0 dBm	-	205	-	mA
Transmit 802.11g, OFDM 54 Mbps, POUT = +14 dBm	-	160	-	mA
Transmit 802.11n, MCS7 HT20, POUT=+11.5 dBm	-	152	-	mA
Transmit 802.11n, MCS7 HT40, POUT=+11.5 dBm	-	152	-	mA
Receive 802.11b, packet length=1024 byes, -80 dBm	-	85	-	mA
Receive 802.11g, packet length=1024 bytes, -70 dBm	-	85	-	mA
Receive 802.11n HT20, packet length=1024 bytes, -65 dBm	-	80	-	mA
Receive 802.11n HT40, packet length=1024 bytes, -65 dBm	-	80	-	mA
Power Save, DTIM 1		TBD		mA
Power Save, DTIM 3		TBD		mA
Power Save, DTIM 10		TBD		mA
Continuous Transmit Bluetooth 1 Mbps		TBD		mA
Continuous Transmit Bluetooth 2 Mbps		TBD		mA
Continuous Transmit Bluetooth 3 Mbps		TBD		mA
Continuous Bluetooth Receive		TBD		mA
1.28 sec page scan (non-interlaced)		TBD		mA
1.28 sec LE ADV		TBD		mA
1.28 sec Sniff as master		TBD		mA
1.28 sec Sniff as slave		TBD		mA
Modem Sleep		10		mA
Light Sleep		0.8		mA
Deep Sleep		25		μА
Hibernation		5		μА

#### 3.3 RF

#### 3.3.1 Generic Radio

Measurements conducted at 25°C ambient temperature.

Table 3-6: Generic Radio Characteristics

Description	Min	Тур	Max	Unit
BX3100 RF Port Impedance		50		Ω
Frequency Band	2.4	2.45	2.485	GHz
BX3105 Antenna Gain		TBD		dBi

#### 3.3.2 Wi-Fi Radio

Measurements conducted at 25°C ambient temperature.

**Table 3-7: Generic Radio Characteristics** 

Description	Min	Тур	Max	Unit
Transmit 802.11b, CCK 11 Mbps, Output Power, EVM and Mask Compliant		18.0		dBm
Transmit 802.11g, OFDM 54 Mbps, Output Power, EVM and Mask Compliant		14.0		dBm
Transmit 802.11n, MCS7 HT20 72.2 Mbps, Output Power, EVM and Mask Compliant		11.5		dBm
Transmit 802.11n, MCS7 HT40 135 Mbps, Output Power, EVM and Mask Compliant		11.5		dBm
Receiver Sensitivity 11b DSSS, 1 Mbps		TBD		dBm
Receiver Sensitivity 11b CCK, 11 Mbps		TBD		dBm
Receiver Sensitivity 11g OFDM, 6 Mbps		TBD		dBm
Receiver Sensitivity 11g OFDM, 54 Mbps		TBD		dBm
Receiver Sensitivity 11n HT20 OFDM, 72.2 Mbps		TBD		dBm
Receiver Sensitivity 11n HT40 OFDM, 135 Mbps		TBD		dBm
BX3100 Harmonics 2F0		-35		dBm
BX3100 Harmonics 3F0		-50		dBm

#### 3.3.3 Bluetooth Radio

Measurements conducted at 25°C ambient temperature.

**Table 3-8: Generic Radio Characteristics** 

Description	Min	Тур	Max	Unit
Transmit Power BR 1 Mbps, ACR & Modulation Compliant		TBD		dBm
Transmit Power BR 2 Mbps, ACR & Modulation Compliant		TBD		dBm
Transmit Power BR 3 Mbps, ACR & Modulation Compliant		TBD		dBm
Transmit Power LE 1 Mbps, ACR & Modulation Compliant		TBD		dBm
Receiver Sensitivity BR 1 Mbps		TBD		dBm
Receiver Sensitivity EDR 2 Mbps		TBD		dBm
Receiver Sensitivity EDR 3 Mbps		TBD		dBm
Receiver Sensitivity LE 1 Mbps		TBD		dBm
Out-of-band blocking performance 30 MHz~2000 MHz		TBD		dBm
Out-of-band blocking performance 2500 MHz~3000 MHz		TBD		dBm
Out-of-band blocking performance 3000 MHz~12.5 GHz		TBD		dBm

#### 3.4 Electrical Specifications

#### 3.4.1 Absolute Maximum Ratings

Table 3-9: Absolute Maximum Ratings

	Parameter	Min	Max	Units
$V_{IL}$	Input low voltage	-0.3	0.25×V <sub>IO</sub>	V
V <sub>IH</sub>	Input high voltage	0.75×V <sub>IO</sub>	3.3	V
I <sub>IL</sub>	Input leakage current	-	50	nA
V <sub>OL</sub>	Output low voltage	-	0.1×V <sub>IO</sub>	V
V <sub>OH</sub>	Output high voltage	0.8×V <sub>IO</sub>	-	V
C <sub>pad</sub>	Input pin capacitance	-	2	pF
V <sub>IO</sub>	VDDIO	1.8	3.3	V
I <sub>MAX</sub>	Maximum drive capability	-	12	mA
T <sub>STR</sub>	Storage temperature range	-40	150	°C


Table 3-10: Recommended Operating Conditions

	Parameter	Min	Тур	Max	Units
$V_{BAT}$	Battery regulator supply voltage	2.8	3.3	3.6	V
V <sub>IO</sub>	I/O supply voltage	1.8	3.3	3.3	٧
T <sub>OPR</sub>	Operating temperature range	-40	-	85	°C
V <sub>IL</sub>	CMOS low level input voltage	0	-	0.3×V <sub>IO</sub>	V
V <sub>IH</sub>	CMOS high level input voltage	0.7×V <sub>IO</sub>	-	V <sub>IO</sub>	V
$V_{TH}$	CMOS threshold voltage	-	0.5×V <sub>IO</sub>	-	V

#### 3.5 Mechanical

#### 3.6 Mechanical Drawings

The AirPrime BX310x module's LGA footprint is a 70-pad array of copper pads (see Physical Dimensions and Connection Interface on page 9). The following drawings illustrate the device footprint and dimensions.



Note: Dimensions in Figure 3-1 and Figure 3-2 are preliminary and subject to change.

Figure 3-1: AirPrime BX3100 Mechanical Drawing




Figure 3-2: AirPrime BX3105 Mechanical Drawing

#### 3.7 Antenna

The AirPrime BX3100 uses an LGA pad (pin 40—RF\_MAIN), which the application must connect to an external antenna.

The AirPrime BX3105 includes an integrated PCB antenna. Leave the LGA pad (pin 40) unconnected.

#### >> 4: Interfaces Specification

#### 4.1 Overview

This section describes the interfaces supported by the AirPrime BX310x embedded module and provides specific voltage, timing, and circuit recommendations for each interface.

#### **4.2 UART**

The AirPrime BX310x provides one UART interface for asynchronous communication between the AirPrime BX310x module and a host device (e.g. a PC or host processor):

UART0—4-wire, RS-232-compliant interface

Note: Up to two additional UART interfaces can be added by configuring GPIOs using AT commands.

Flow control is managed using:

- RTS/CTS signals (This method is required for higher UART interface speeds.)
   or
- Software XON/XOFF

Table 4-1 on page 23 describes the signals used for UARTO.

Note: UART signals are named with respect to the module, and directions are listed with respect to the module. For example, UARTO RXD is an output from the module to the host.

Table 4-1: UARTO Pinsa

Pin	Interface	Name	Direction	Function	Voltage Level
2		UARTO_RTS	I	Ready To Send, flow control	
3	UART0	UART0_CTS	0	Clear To Send, flow control	VDD PADS BB
4	UANTO	UART0_TXD	I	Transmit Data	VDD_PADS_BB
5		UART0_RXD	0	Receive Data	

a. If UART0 pins are not used, leave open.

#### **4.3 ADC**

The AirPrime BX310x provides two general purpose ADC (Analog to Digital Converter) inputs that are used to measure analog voltages.

Table 4-2: ADC Interface Pinsa

Pin	Signal name	Direction <sup>b</sup>	Function	Voltage Level
18	VDET_1	I	Analog to Digital Converter	VDD PADS BB
19	VDET_2	I	Analog to Digital Converter	VDD_I AD3_BB

a. Leave open any pins that are not used.

#### 4.4 Voltage Measurement

The AirPrime BX310x supports the measurement of analog voltages using the following methods:

- ADCs—Two input pins that can be used for direct voltage measurements. See ADC on page 24.
- Combination of four GPIOs and external capacitors—Small analog signals can
  be measured by configuring (using AT commands) the pins in Table 4-3 below to
  support a low-noise programmable gain amplifier with the addition of external
  270 pF capacitors between pins 31/32 and pins 34/36. The internal ULP-coprocessor is also designed to measure the voltages while operating in the sleep
  mode, to enable low power consumption; the CPU can be woken up by a
  threshold setting and/or via other triggers.

Table 4-3: Voltage-measurement GPIO Pinsa

Pin	Signal Name	Direction <sup>b</sup>	Voltage level	
31	SENSOR_VP	I	- VDD PADS BB	
32	SENSOR_CAPP	I		
34	SENSOR_CAPN	I	- VDD_FADS_BB	
36	SENSOR_VN	I		

a. Leave open any pins that are not used.

#### 4.5 I<sup>2</sup>C Interface

The AirPrime BX310x module provides two I<sup>2</sup>C (Inter-Integrated Circuit) dedicated serial ports (bus interface) based on [8] The I2C Bus Specification, Version 2.1, January 2000 (Phillips Semiconductor document number 9398 393 40011).

b. Signal direction with respect to the module.

b. Signal direction with respect to the module.

The interfaces use the pins indicated in Table 4-4.

Table 4-4: I<sup>2</sup>C Interface Pins<sup>a</sup>

Pin	Signal name	Direction	Function	Voltage Level	
9	I2C1_SCL	I/O	Primary I2C interface	- VDD_PADS_BB	
17	I2C1_SDA	I/O	Primary I2C interface		
53	I2C2_SDA	I/O	Secondary I2C interface	VGPIO	
54	I2C2_SCL	I/O	Secondary I2C interface		

a. Leave open any pins that are not used.

This implementation of the I<sup>2</sup>C interface includes the following characteristics:

- Supported voltage:
  - Primary I2C (1.8 V/3.3 V, configurable)
  - Secondary I2C (3.3 V)
- Standard-mode interface—Data transfer rates up to 100 kbit/s
- Fast-mode interface—Data transfer rates up to 400 kbit/s)
- Master mode operation
- Addressing modes—7-bit; 10-bit; Dual addressing mode

External 2.2 k $\Omega$  pull-up resistors must be applied to I<sup>2</sup>C signals (see Figure 4-1 on page 25).

For I<sup>2</sup>C bus details, including I2C bus waveform and timing details, refer to the I2C Bus Specification.

#### 4.5.1 Application




Figure 4-1: Example of I<sup>2</sup>C Bus Application