



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



LMOSTBMPL3115A2 Quick Start Guide

1 Unpack the Kit

- Unpack the board. Verify package contents according to the kit website: freescale.com/sensortoolbox.
- Assemble the hardware by connecting the development board to the USB interface board. Both of these board types have a small arrow to indicate where to connect. See the image below. More information can be found at freescale.com/sensortoolbox.



2 Download Latest Software

- At freescale.com/sensortoolbox download the latest software version.
- All Sensor Toolbox kits use the same software and driver, so the install only needs to be done once. Follow the on-screen instructions to install the communication driver for the tool. Check back occasionally for software updates.

3 Turn It On


- Plug in the USB and turn the board on using the power switch.
- Run the Sensor Toolbox link on your desktop.
- Explore other sensor kits at freescale.com/sensortoolbox.






Connector for All
Sensor Toolbox Pressure
Sensor Development Boards

Sensor
Interface
Board




MPL3115A2
3 x 5 x 1.1 mm
LGA Package



KITSTBMPL3115A2
Development Board

LFSTBUSB
Communication Board



Power
Switch

USB Mini-b
Connector

Learn More at freescale.com/sensortoolbox

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Xtrinsic is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.
© 2011 Freescale Semiconductor, Inc.



Doc Number: DEMOMPL3115A2QSG / REV 0
Agile Number: 926-78612 / REV A