# imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



# Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





# 60V, 30µA I<sub>Q</sub>, Low Dropout Voltage Linear Regulator

# Purpose

The RT9074 is a high input-voltage linear regulator specifically designed to minimize external components. The input voltage range is from 4.5V to 60V. The device supplies 100mA of output current with a maximum dropout voltage of 300mV. This document explains the function and use of the RT9074-33GSP evaluation board (EVB) and provides information to enable operation and modification of the evaluation board and circuit to suit individual requirements.

# **Table of Contents**

Purpose	1
Introduction	2
Key Performance Summary Table	2
Bench Test Setup Conditions	3
Schematic, Bill of Materials & Board Layout	4
More Information	6
Important Notice for Richtek Evaluation Board	6



### Introduction

#### **General Product Information**

The RT9074 is a high input-voltage linear regulator specifically designed to minimize external components. The input voltage range is from 4.5V to 60V. The device supplies 100mA of output current with a maximum dropout voltage of 300mV. Its 30µA quiescent and 5µA shutdown currents make it ideal for use in battery-powered applications.

#### **Product Feature**

- Wide Input Voltage Range : 4.5V to 60V
- Low Quiescent Current : 30µA
- Low Dropout Voltage : 300mV maximum at 100mA
- ±3% Output Tolerance Over Line and Load
- Stable with 1µF Output Capacitor (Aluminum, Tantalum or Ceramic)
- Inherent Reverse-Current Protection (No diode needed)
- -60V Reverse-Battery Protection

### Key Performance Summary Table

Key Features	Evaluation Board Number : PCB030_V1		
Default Input Voltage	5V		
Max Output Current	100mA		
Default Output Voltage	3.3V		
Default Marking & Package Type	RT9074-33GSP, SOP-8 (Exposed Pad)		
Other Key Features	4.5V to 60V Input Voltage Range Low Dropout Voltage : 300mV maximum at 100mA ±3% Output Tolerance Over Line and Load Inherent Reverse-Current Protection (No diode needed) -60V Reverse-Battery Protection		
Protection	Current Limit Thermal Shutdown		



# **Bench Test Setup Conditions**

#### Headers Description and Placement



Please carefully inspect the EVB IC and external components, comparing them to the following Bill of Materials, to ensure that all components are installed and undamaged. If any components are missing or damaged during transportation, please contact the distributor or send e-mail to evb service@richtek.com

#### Test Points

The EVB is provided with the test points and pin names listed in the table below.

Test point/ Pin name	Signal	Comment (expected waveforms or voltage levels on test points)		
VIN	Input voltage	Input voltage range = 4.5V to 60V		
VOUT	Output voltage	Default output voltage = 3.3V		
SHDN	HDNShutdown Control test pointShutdown Control Input (Active High). Connect disable the output voltage and reduce the IC's qu to 5μA (typical).			
GND	Ground	Ground		
SENSE	Output Voltage Sense point	Output Voltage Sense.		
FB	Feedback Input test point	Feedback Input. Connect to the center tap of a resistor divider for setting the output voltage. (Adjustable versions only)		


#### **Power-up & Measurement Procedure**

- 1. Connect input power ( $4.5V < V_{IN} < 60V$ ) and input ground to VIN and GND test pins respectively.
- 2. Connect positive end and negative terminals of load to VOUT and GND test pins respectively.
- 3. Connect power ( $0V \le V_{IN} \le 60V$ ) and ground to SHDN and GND test pins respectively.
- 4. Setting SHDN to GND be 0V for enable the RT9074.
- 5. Verify the output voltage (approximately 3.3V) between VOUT and GND.
- 6. Connect an external load up to 100mA to the VOUT and GND terminals and verify the output voltage and current.



# Schematic, Bill of Materials & Board Layout

#### EVB Schematic Diagram




#### **Bill of Materials**


Reference	Qty	Part Number	Description	Package	Manufacture
U1	1	RT9074-33GSP	LDO	SOP-8 (Exposed Pad)	RICHTEK
C1	1	GRM21AR72A224KAC5L	0.22µF/±10%/100V/X7R Ceramic Capacitor	0805	Murata
C2	1	GRM31CR71H225KA88L	2.2µF/±10%/50V/X7R Ceramic Capacitor	1206	Murata
R1, EC1, R2, EC2, R4, C4	6		Not Installed	0603	
R3	1		0Ω, Resistor	0603	
R5	1		100kΩ/±1%, Resistor	0603	
GP1, GP2, GP3, GP4	4	VIN, VOUT, GND	Golden Pin		
TP1, TP2, TP3	3	SHDN, SENSE, FB	Test Pin		



### PCB Layout



**Top View** 



Bottom View



# More Information

For more information, please find the related datasheet or application notes from Richtek website <u>http://www.richtek.com</u>.

# Important Notice for Richtek Evaluation Board

THIS DOCUMENT IS FOR REFERENCE ONLY, NOTHING CONTAINED IN THIS DOCUMENT SHALL BE CONSTRUED AS RICHTEK'S WARRANTY, EXPRESS OR IMPLIED, UNDER CONTRACT, TORT OR STATUTORY, WITH RESPECT TO THE PRESENTATION HEREIN. IN NO EVENT SHALL RICHTEK BE LIABLE TO BUYER OR USER FOR ANY AND ALL DAMAGES INCLUDING WITHOUT LIMITATION TO DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES.