



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts,Customers Priority,Honest Operation,and Considerate Service",our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





For more information,  
visit [freescale.com/  
sensortoolbox](http://freescale.com/sensortoolbox)

FRDM  
STBC-  
P3115

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners.  
© 2015 Freescale Semiconductor, Inc.  
FRDMSTBCP3115QRC REV 1  
920-28981 REV A

# FRDMSTBC-P3115

FRDM  
STBC-  
P3115

## Quick Reference Card

Pressure Sensor Toolbox Development Board

MPL3115A2 I<sup>2</sup>C precision altimeter sensor




**Get Started**

Download tools and  
documentation under  
**Jump-Start Your Design**  
at [freescale.com/  
sensortoolbox](http://freescale.com/sensortoolbox)



FREESCALE FREEDOM PLATFORM

- 1 Verify package contents:
  - FRDMSTBC-P3115 development board
- 2 Connect the FRDMSTBC-P3115 development board to a Freescale Freedom development board, such as the FRDM-KL25Z (or any Arduino R3 compatible board). Refer to the Freescale Freedom development board Quick Start Guide for driver information.
- 3 Plug one end of a USB cable into the SDA port on the assembly. Plug the other end of the cable into the USB port on the computer.
- 4 Download and install the latest Sensor Toolbox software at: [freescale.com/sensortoolbox](http://freescale.com/sensortoolbox)
- 5 Start the Sensor Toolbox software.



Get to Know the FRDMSTBC-P3115



Learn more at [freescale.com/sensortoolbox](http://freescale.com/sensortoolbox)