Chipsmall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts,Customers Priority,Honest Operation,and Considerate Service",our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!

Contact us

i.MX23 Applications Processor Reference Manual

IMX23RM
Rev. 1
11/2009

How to Reach Us:

Home Page:

www.freescale.com

Web Support:

http://www.freescale.com/support

USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc.
Technical Information Center, EL516
2100 East Elliot Road
Tempe, Arizona 85284
+1-800-521-6274 or
+1-480-768-2130
www.freescale.com/support

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
www.freescale.com/support

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku
Tokyo 153-0064
Japan
0120 191014 or
+81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor China Ltd.
Exchange Building 23F
No. 118 Jianguo Road
Chaoyang District
Beijing 100022
China
+86 010 5879 8000
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor
  Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
+1-800 441-2447 or
+1-303-675-2140
Fax: +1-303-675-2150
LDCForFreescaleSemiconductor
  @hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Document Number: IMX23RM
Rev. 1, 11/2009

Contents

Chapter 1
Product Overview

i.MX23 Applications Processor Reference Manual, Rev. 1

Contents

Contents

Chapter 5
Interrupt Collector

Chapter 6
Digital Control and On-Chip RAM

Chapter 7
On-Chip OTP (OCOTP) Controller

Contents

Contents

i.MX23 Applications Processor Reference Manual, Rev. 1

Contents

Chapter 13
General-Purpose Media Interface (GPMI)

Contents

Contents

Contents

Chapter 18
LCD Interface (LCDIF)

Contents

Contents

Chapter 22
Timers and Rotary Decoder

Chapter 23
Real-Time Clock, Alarm, Watchdog, Persistent Bits

Contents

Contents

Chapter 27
Debug UART

Chapter 28
AUDIOIN/ADC

Chapter 29
AUDIOOUT/DAC

Contents

Chapter 30
SPDIF Transmitter

Chapter 31
Serial Audio Interface (SAIF) (BGA169 Only)

Chapter 32
Power Supply

Contents

Chapter 33
Low-Resolution ADC and Touch-Screen Interface

Contents

Contents

Chapter 36
Pin Descriptions

Chapter 37
Pin Control and GPIO

Contents

Chapter 38 Digital Video Encoder Programmers' Manual

Chapter 39
Register Macro Usage

Contents

Chapter 40
Memory Map

Chapter 41
i.MX23 Part Numbers and Ordering Information

Chapter 42
Package Drawings

Appendix A
Revision History

Appendix B
Register Names

Appendix C
Acronyms and Abbreviations

Contents

Figures

i.MX23 Applications Processor Reference Manual, Rev. 1

Figures

Figures