Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts,Customers Priority,Honest Operation,and Considerate Service",our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!

Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832
Email & Skype: info@chipsmall.com Web: www.chipsmall.com
Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China

Skywire click

PID: MIKROE-2405

Weight: 30 g

Condition: New product

Skywire™ click is an adapter click, which hosts NimbeLink/Skywire™ cellular modems (using stacking headers) to MikroElektronika development boards. It carries the MCP1826 low dropout regulator from Microchip.

NOTE: the Skywire™ modem and the Thermo 3 click are not included in this offer.

Table of contents

Skywire™ click is an adapter click, which hosts **NimbeLink/Skywire™ cellular modems** (using stacking headers) to **MikroElektronika development boards**. It carries the MCP1826 low dropout regulator from Microchip. Skywire™ click is designed to run either on 3.3V or 5V power supply. The click communicates with the target MCU over UART interface, and the following mikroBUS™ pins: PWM, AN, INT, RST, CS.

NOTE: the Skywire™ modem and the Thermo 3 click are not included in this offer.

Additional mikroBUS™ socket

Skywire™ click has the capability to host an additional mini sized click board™. It also has its own power supply to make the needed voltage for the modules.

Skywire cellular modems

Skywire™ cellular modems are the smallest on the market today. This product family from NimbeLink covers everything from **2G and 3G to LTE**. They all share the same footprint and pinout, and are flexible for implementation.

Key features

- MCP1826 LDO regulator
    - 1000 mA Output Current Capability
    - Output voltage range of 0.8V to 5.0V
- Additional socket for a mini sized click board™
- Interface: UART
- 3.3V or 5V power supply

SPECIFICATION

Product Type	Adapter
On-board modules	MCP1826 LDO regulator
Key Features	Additional socket for mini sized click board™, MCP1826 LDO regulator, 3.3V or 5V power supply
Key Benefits	Adapts Nimbelink/Skywire modules with MikroElektronika development systems
Interface	UART
Power Supply	3.3V or 5V
Compatibility	mikroBUS
Click board size	L (57.15 x 25.4 mm)

Pinout diagram

This table shows how the pinout on **Skywire click** corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin	mikroBUS™			Pin	Notes
Enable	EN	1 AN	PWM	16	CTS	Clear To Send
RESET	RST	2 RST	INT	15	AD1_J	ADC IN
Request To Send	RTS	3 CS	TX	14	TX	UART transmit
Not connected	NC	4 SCK	RX	13	RX	UART receive
Not connected	NC	5 MISO	SCL	12	NC	Not connected
Not connected	NC	6 MOSI	SDA	11	NC	Not connected
Power supply	+3.3V	7 3.3V	5V	10	+5V	Power supply
Ground	GND	8 GND	GND	9	GND	Ground

Programming

The following code snippet starts the main function in the Skywire application.

This is a simple main function, which excepts a call and replies with an SMS to caller. The content of the SMS is the current temperature measurement in degrees Celsius.

```
01: void main()
02: {
03:     measure_f = false;
04:     system_init();
05:     skywire_power_on();
06:     at_init( rsp_handler, UART3_Write, buffer, sizeof( buffer ) );
07:     at_cmd_save( "+CLCC", 1000, NULL, NULL, NULL, callerid_handler );
// Assigning caller ID handler
08:     at_cmd_single( "AT" );
09:     at_cmd_single( "AT+CSCS="GSM"" );
10:     at_cmd_single( "AT+CMGF=1" );
```

```
11:      while( 1 )
12:      {
13:          at_process();
14:
15:          if( measure_f )
16:          {
17:              measure_temp();
18:              at_cmd_single( "AT+CLCC" );
19:              at_cmd_single( "ATH" );
20:              Delay_ms( 2000 );
// Delay needed after ATH
21:              reply_to_caller();
22:              measure_f = false;
23:          }
24:      }
25: }
```

Jumpers and settings

The following table describes the functions of the onboard jumpers.

Designator	Name	Default Position	Default Option	Description
JP1	PWR.SEL.	Left	3.3V	Power Supply Voltage Selection 3.3V/5V, left position 3.3V, center position 5V
ADC1	ADC1	Populated	3.3V	Connects ADC1 pin of the modem to the mikroBUS pin