

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China








THERMO K click

THERMO K click



THERMO K click carries the **MCP9600 IC from Microchip** and and depending on the type of probe it uses, the click can measure temperatures from -200 °C to +1372 °C. THERMO K click is designed to run either on 3.3V or 5V power supply. It communicates with the target MCU through I2C interface.

Features and usage notes

Temperature range

With the type-K probe, available in our store [4], this click can measure temperature up to +480 °C.

MCP9600 from Microchip

The MCP9600 IC converts thermocouple EMF to degree Celsius with integrated Cold-Junction compensation. It corrects the thermocouple nonlinear error characteristics of eight thermocouple types and outputs ±1.5°C accurate temperature data.

4 alert outputs

THERMO K click has 4 alert outputs onboard that can be used to detect multiple temperature zones. You can define on which specific temperature the THERMO K click will send an alarm.

Low power modes

Low-Power modes are available for battery-powered applications. In shut-down mode the module uses only 2 µA.

Thermocouple probe

In order to use THERMO K click you need to connect the appropriate K-type thermocouple probe (not included in the package) into the PCC-SMP connector.

Key features

• MCP9600 IC from Microchip

• Four Programmable Temperature Alert Outputs

Operating Current: 300 μA (typical)
Shutdown Current: 2 μA (typical)

• Interface: I2C

• 3.3V or 5V power supply

Jumpers and settings

Designator	Name	Default Position	Default Option	Description: describe the use + list all options with respective descriptions
JP1	PWR.SEL.	Left	3V3	Power Supply Voltage Selection 3V3/5V, left position 3v3, right position 5V
JP2	ADDR. SEL.	Right	GND	I2C address Selection. Left position (VDD) is $1100111x$ and right position (GND) is $1100000x$.

Additional information

Our store ^[5] offers Thermocouple Type-K Glass Braid Insulated probes.

Pinout diagram

This table shows how the pinout on THERMO K click corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin		• •				Pin	Notes
		• • •		mikroBUS tm				
Alert 4 output	ALERT4	1	AN		PWM	16	ALERT2	Alert 2 output
Alert 3 output	ALERT3	2	RST		INT	15	ALERT1	Alert 1 output
Not connected	NC	3	CS		TX	14	NC	Not connected
Not connected	NC	4	SCK		RX	13	NC	Not connected
Not connected	NC	5	MISO		SCL	12	SCL	I2C Clock
Not connected	NC	6	MOSI		SDA	11	SDA	I2C Data
Power supply	+3.3V	7	+3.3V		+5V	10	+5V	Power supply
Ground	GND	8	GND		GND	9	GND	Ground

Programming

The demo shows the temperature on the TFT or LCD display.

It measures every half a second.

We have examples for PIC, dsPIC, PIC32, ARM, AVR and FT90x compilers.

The code snippet is from the Example folder of the PIC compiler and P18F87K22 MCU.

This example is a temperature reading routine.

First, we are reading the "Thermocouple Temperature Register" and then we are converting the value to a temperature in the Celsius scale.

```
float Read_Temperature()
   float Temperature;
   tmp_data[0] = MCP9600_TH;
   I2C1_Start();
   I2C1_Wr( MCP9600_I2C_ADDR );
   I2C1_Wr( tmp_data[ 0 ] );
   I2C1_Stop();
   Delay_us( 50 );
   I2C1_Start();
   12C1_Wr( MCP9600_I2C_ADDR | 1 );
   tmp_data[0] = I2C1_Rd(1);
   tmp_data[1] = I2C1_Rd(0);
   I2C1_Stop();
   if((tmp_data[0] & 0x80) == 0x80)
   {
       tmp_data[0] = tmp_data[0] & 0x7F;
       Temperature = 1024 - (tmp_data[0]*16 + tmp_data[1] / 16);
   }
   else
   {
       Temperature = (tmp_data[0] * 16 + (float)tmp_data[1] / 16);
   }
   return Temperature;
```

Resources

- THERMO K schematic [3]
- MCP9600 datasheet ^[1]
- Libstock Library ^[6]
- mikroBUSTM standard specifications ^[7]

References

- [1] http://ww1.microchip.com/downloads/en/DeviceDoc/20005426B.pdf
- [2] https://shop.mikroe.com/click/sensors/thermo-k
- [3] http://cdn-docs.mikroe.com/images/3/3e/THERMO_K_click_schematic.pdf
- $[4] \ https://shop.mikroe.com/accessories/sensors/thermocouple-type-k-glass-braid-insulated$
- $[5] \ https://shop.mikroe.com/accessories/sensors/thermocouple-type-k-glass-braid-insulated?search_query=thermocouple\&results=2.$
- [6] http://libstock.mikroe.com/projects/view/1976/thermo-k-click
- [7] http://download.mikroe.com/documents/standards/mikrobus/mikrobus-standard-specification-v200.pdf

Article Sources and Contributors

THERMO K click Source: http://docs.mikroe.com/index.php?oldid=3004 Contributors: Lana.vulic

Image Sources, Licenses and Contributors

File:THERMO K click.jpg Source: http://docs.mikroe.com/index.php?title=File:THERMO_K_click.jpg License: unknown Contributors: Lana.vulic File:mikrobus logo.png Source: http://docs.mikroe.com/index.php?title=File:Mikrobus_logo.png License: unknown Contributors: Vojislav.gvozdic

License

Creative Commons Attribution https://creativecommons.org/licenses/by/4.0/