imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



Input Modules, Remote Indication

PGA FAMILY, PGB FAMILY



INPUT MODULES				
Product		Features	Accessory For	
PGA-0120 Temperature Input Module		Provides 8 programmable inputs to connect Pt100, Ni100, Ni120, and Cu10 RTDs.	PGR-6200 PGR-6300	
PGA-0140 Differential Current Module	mmm A	Adds motor differential protection, compatible with core balance and summation current transformer connections.	PGR-6200 PGR-6300	
PGA-0CIM Current Input Module		Interface between current transformers and PGR-6200 and PGR-7200 series relays. Prevents open-CT hazards.	PGR-6200 PGR-7200	

REMOTE INDICATION				
Product		Features	Accessory For	
PGB-0302 Remote Indication and Reset Assembly		Panel-mounted remote indication and reset, standard 22 mm mounting with NEMA 4 and NEMA 13 rating.	PGM-8325	
PGB-0325 Remote Indication and Reset Assembly		Panel-mounted remote indication and reset with NEMA 1 rating.	PGM-8325	
PGB-6130 Remote Indication and Reset Assembly		Remote indication of overcurrent, phase imbalance, phase loss, phase sequence, and overtemperature. Remote reset included.	PGR-6130	
PGB-6800 Remote Indication and Reset Assembly		Remote indication of overcurrent, undercurrent, phase imbalance, phase loss, and phase sequence. Remote reset included.	PGR-6800	
PGA-0500 Analog % Current Meter		Panel-mounted analog meter displays ground-fault current as a percentage of the set-point.	PGR-2601 PGR-5701 PGR-4300 PGR-6100 PGR-4704 PGR-6100	
PGA-0510 Analog Ohm Meter		Panel-mounted analog ohmmeter displays insulation resistance from 0 $\boldsymbol{\Omega}$ to infinity.	PGR-3200 PGR-6100 PGR-8600	