

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







Optical Touch Switch W-100 SERIES

FIBER SENSORS

Related Information ■ General terms and conditions...... F-7

■ General precautions P.1501

SENSORS PHOTOELECTRIC

LASER

MICRO

PHOTOELECTRIC SENSORS

AREA SENSORS

PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY **SENSORS**

PARTICUI AR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASUREMENT SENSORS

STATIC ELECTRICITY PREVENTION DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES

ENERGY CONSUMPTION VISUALIZATION COMPONENTS

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Light Curtains Safety Components

Control Units Definition of Sensing Heights

SW-100







Conforming to OSHA / ANSI

Gentle start-up switches in accordance with ergonomics

Greater convenience with less stress on the hands. Inventive start-up switches in accordance with ergonomics.

Sensing surface

Beam axes



Operate the switch simply by touching it

This is an optical-type switch (two beam axes) which allows you to start equipment simply by touching the sensing surface to interrupt the light beams.



Reduces load on hands and fingers

Provides a zero force, low impact, machine control solution.



Prevents medical issues

The switch reduces the possibility of medical problems that are associated with high impact push buttons, such as tendonitis or carpal tunnel syndrome.

Reduction in false operation from dropped objects

SW-101

The response time is set for a slight delay so that the switch will not respond a falling object, such as a dropped tool. The switch is designed so that it will operate when touched by hand, but false operation will rarely occur when something is dropped onto it.



A switch that pursues the prevention requirement for malfunctioning as required by ISO 13851 (JIS B 9712) two-hand control devices

SW-111



Safeguard prevents false operation

SW-111 saves the hassle of making an additional safeguard. In addition, with its ISO 13851 complying shape, even a knock on the elbow will not cause a false operation (light interruption).

No false operation by wrist



No false operation by elbow




No false operation by plastic sheet



Experimental cone (ISO 13851)

SW-111 does not produce false operation on the experimental cone specified by ISO 13851.



Intended startup is possible

SW-111's detection does not operate when a hand is just placed onto the unit.

With a design that only detects when fingers are bent in and lightly grip onto the unit, an intended startup is possible.



Detection does not operate when a hand is only placed onto the unit.



Detection only operates when fingers are bent in and lightly grip onto the unit.




Application example

When used as two-hand control devices

Equipped with external input indicators

Two sets of external input indicators (two colors) are provided, so that they can be used as operation indicators for a variety of purposes.



Prevents false operation caused by dirt

If the light is continuously interrupted for more than 10 sec. by dust, etc., the switch is disabled and the fault indicator (yellow) illuminates.

Uses a long-life Photo-MOS relay

Because a Photo-MOS relay is used for the output, a single unit can be configured without a specific output polarity. In addition, there is no need for periodic replacement of parts such as contact-type relays.

FIBER SENSORS

LASER SENSORS

PHOTOELECTRIC SENSORS

MICRO PHOTOELECTRIC SENSORS

AREA SENSORS

PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY **SENSORS**

PARTICUI AR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASUREMENT SENSORS

STATIC ELECTRICITY PREVENTION DEVICES

LASER MARKERS

PLC

SW-111

HUMAN MACHINE INTERFACES

ENERGY CONSUMPTION VISUALIZATION COMPONENTS

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING

Selection Guide Light Curtains

Safety Components Optical Touch Switch

Control Units

Definition of Sensing Heights

SW-100

FIBER SENSORS

LASER SENSORS PHOTO-ELECTRIC SENSORS

MICRO PHOTO-ELECTRIC SENSORS AREA SENSORS

LIGHT CURTAINS/ SAFETY COMPONENTS PRESSURE/ FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS PARTICULAR USE SENSORS

SENSOR OPTIONS SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS MEASURE-MENT SENSORS STATIC

PREVENTION DEVICES LASER MARKERS

HUMAN MACHINE INTERFACES ENERGY CONSUMPTION

PLC

COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Selection
Guide
Light
Curtains
Safety
Components
Optical Touch
Switch
Control
Units
Definition of
Sensing
Heights

SW-100

ORDER GUIDE

Designation		Appearance	Model No.	Power supply	Output
Optical touch switch			SW-101	12 to 24V DC	
	With safeguard		SW-111	±10 %	Semiconductor Photo-MOS relay output × 3

OPTIONS

Designation	Model No.	Description	
Mounting tool	SW-MT1	Tool for tightening mounting nuts with a commercially-available wrench. (Refer to p.701)	
Sensing surface protective sheet for SW-101	SW-PS1	A transparent stick-on sheet that protects the sensing surface of SW-101 from dirt and scratches. 5 sheets per set	

Sensing surface protective sheet for SW-101

SW-PS1


SPECIFICATIONS


Designation Item Model No.			Optical touch switch				
				With safeguard			
			SW-101	SW-111			
Sensing method			Thru-beam type photoelectric sensor (2 beam axes)				
Applicable standards		ards	CSA 22.2 No.14, CSA 22.2 No.0.8, ANSI / NFPA 79, UL 508, EN 60947-5-2 (EMC only)				
Power supply			12 to 24 V DC ±10 % Ripple P-P 10 % or less				
Current consumption		tion	100 mA or less (excluding external connection load)				
Outputs			Semiconductor Photo-MOS relay output × 3 • Maximum load current: 100 mA • Applied voltage: 30 V DC or less (between output and +V) • Residual voltage: 1.5 V or less (at 100 mA of load current)				
	Output operation		Output 1 : When an object is detected (beam is interrupted): OFF / When an object is not detected (beam is received): ON Output 2, 3 : When an object is detected (beam is interrupted): ON / When an object is not detected (beam is received): OFF				
	Short-circuit protection		Incorporated				
Response time			100 ms or less when an object is detected, 50 ms or less when an object is not detected				
Time-out function			Switchable either effective or ineffective by short-circuiting terminals (disabled when short-circuited)				
External input			0 to 1 V or 10 V to +V: Valid (External input indicator lights up), 4 to 6 V or Open: Invalid (External input indicator lights off)				
	Power indicator (POWER)		Green LED (lights up when the power is ON)				
ors	Operation indicator (OPE.)		Green LED (lights up when an object is detected)				
Indicators	External input indicator 1		Green LED (lights up when external input 1 is valid)				
<u>l</u>	External input indicator 2		Orange LED (lights up when external input 2 is valid)				
	Fault indicator (FAULT)		Yellow LED (blinks or lights up when fault occurs)				
4)	Protection		IP65 (IEC), TYPE 1 (UL 50) (excluding terminal part)				
ance	Ambient temperature		-25 to +50 °C −13 to +122 °F (No dew condensation or icing allowed), Storage: -30 to +70 °C −22 to +158 °F				
sist	Ambient humidity		30 to 85 % RH, Storage: 30 to 85 % RH				
a	Ambient illuminance		Incandescent light: 3,000 ℓx at the light-receiving face				
nent	Voltage withstandability		1,000 V AC for one min. between all supply terminals connected together and enclosure				
Environmental resistance	Insulation resistance		20 MΩ, or more, with 500 V DC megger between all s	supply terminals connected together and enclosure			
Envi	Vibration resistance		10 to 500 Hz frequency, 3 mm 0.118 in amplitude in X, Y and Z directions for two hours each 1	10 to 150 Hz frequency, 0.75 mm 0.030 in amplitude in X, Y and Z directions for two hours each α			
	Shock resistance		500 m/s ² acceleration (50 G approx.) in X, Y and Z directions for three times each				
	novable-type	Connector	3.5 mm 0.138 in pitch, 2-level socket: 12 pins				
	ninals	Terminal part	3.5 mm 0.138 in pitch spring-cage terminals: 6 pins × 2 (F	FMC1,5 / 6-ST-3,5 manufactured by Phoenix Contact)			
Cable			0.2 to 1.5 mm ² [including single wire or ferrule (sleeve)]				
Maximum cable length			Up to 20 m 65.617 ft (for cable from 0.2 to 0.3 mm²), Up to 100 m 328.084 ft (for cable from 0.3 to 1.5 mm²)				
Material			Enclosure: Polycarbonate, Polyester, O-ring: Silicone rubber, Mounting nut: PBT, Mounting packing: Silicone rubber				
Weight			Net weight: 130 g approx. Gross weight: 200 g approx.	Net weight: 150 g approx. Gross weight: 220 g approx.			

I/O CIRCUIT AND WIRING DIAGRAMS


I/O circuit diagram

If case of connecting output to Minus common






Terminal arrangement diagram



If case of connecting output to Plus common



Non-voltage contact or NPN open-collector transistor

Contact "closed" or transistor "ON": Valid (External input indicator lights up) Contact "open" or transistor "OFF": Invalid (External input indicator lights off) FIBER SENSORS

LASER SENSORS

PHOTO-ELECTRIC SENSORS MICRO PHOTO-ELECTRIC SENSORS

AREA SENSORS

PRESSURE / FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASURE-MENT SENSORS

STATIC ELECTRICITY PREVENTION DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES

FA COMPONENTS

MACHINE VISION SYSTEMS

Light Curtains Safety Components

Control Units

SW-100

LASER SENSORS PHOTO-ELECTRIC SENSORS

AREA SENSORS

PRESSURE

SENSORS

PARTICULAR SENSORS SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASURE MENT SENSORS

STATIO ELECTRICITY PREVENTION DEVICES

LASER MARKERS

PLC

HUMAN

ENERGY CONSUMPTION VISUALIZATION COMPONENTS

COMPONENTS

MACHINE VISION SYSTEMS

CURING SYSTEMS

Light Curtains

Control

SW-100

PRECAUTIONS FOR PROPER USE

• Never use this product in a device for personnel protection.

- In case of using devices for personnel protection, use products which meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.
- · Do not use this product as a device for emergency stop.
- This product is used to start up the machinery. Securing safety for the startup of machinery should be performed separately.



- · When using the products for two-hand control, comply with the following contents.
- Select a model of a control device for two-hand control, based on results of risk
- · Make sure to use a controller for two-hand control which complies with ISO 13851 (EN 574, JIS B 9712)
- · For another requirements such as mounting of this product, or prevention of accidental actuation and of defeat etc., comply with ISO 13851 (EN 574, JIS B 9712) and ANSI B11.1, B11.9. Furthermore, comply with the regulations established by national or regional security committees (Occupational Safety and Health Administration: OSHA, the European Standardization Committee,


Mounting

· Fasten a mounting nut (accessory) from the reverse side of the mounting plate. (Note 1)

The tightening torque should be 2 to 3 N·m.

Notes: 1) A mounting tool (SW-MT1) for fastening the mounting nut is available separately. The shape of fastening part of SW-MT1 is M10 nut.

2) Make sure to use the attached mounting packing, or waterproof property will be invalid.




Time-out function

• Unintended beam interrupted status caused by dirt on the sensing surface, etc. can be monitored.

When beam interrupted status (sensing status) continues for 10 sec. or more, output 1 turns ON and output 2 and 3 turn OFF (output status is the same as non-sensing

This function can be invalid by short-circuiting "between switching terminals of time-out function (terminal No. 7 and No. 8)" as described below.

Note: When time-out function is operated, the fault indicator (yellow) lights up. In this case, once beam is received, the fault indicator lights off and the sensor returns to normal operation.



Others

- When the power of the thru-beam type photoelectric sensor inside the main body turns on in beam interrupted status, output 1 turns ON and output 2 and 3 turn OFF, then the fault indicator (yellow) lights up. In this case, once beam is received, the fault indicator lights off and the sensor returns to normal operation.
- Use a power supply unit conforming to the EMC Directive and the Low Voltage Directive. (Only for use in Europe)
- · Use a power supply unit conforming to Class 2. (Only for use in the North America)
- Use a power supply unit with an output holding time of 20 ms or more.
- · Do not use during the initial transient time (300 ms approx.) after the power supply is switched on.

DIMENSIONS (Unit: mm in)

The CAD data in the dimensions can be downloaded from our website.

Note: The panel thickness should

be 3 mm 0.118 in or less.

LASER SENSORS

PHOTO-ELECTRIC SENSORS

AREA SENSORS

PRESSURE / FLOW SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

WIRE-SAVING SYSTEMS

MEASURE-MENT SENSORS

DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES

FA COMPONENTS

MACHINE VISION SYSTEMS


Selection Guide

Light Curtains Safety Component

Control Units

SW-100

SW-101 Optical touch switch




Panel cut-out dimensions

ø30.5 ø1.201


<When mounting with a resin plate> 4.8

33^{+0.5}




<When mounting with a metal plate>

SW-111 Optical touch switch




Panel cut-out dimensions

<When mounting with a resin plate>



<When mounting with a metal plate>



Note: The panel thickness should be 3 mm 0.118 in or less.