



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





## Product Discontinuation

August 13<sup>th</sup>, 2015

CUI regrets to announce plans to obsolete our Level V external adapters effective immediately. Driving this announcement is a recent change of required efficiency standards by the United States Department of Energy for external adapters, <http://www.cui.com/efficiencystandards>. This includes the following series, linear adapters, and additional custom adapters; EMSA 15 W Series, EMSA 16 W Series, EMSA 18 W Series, EMSA 18W UN Series, EMSA 30 W Series, EMSA 40 W Series, EMSA 5 W USB Series, EMSA 6 W Series, EPSA 6 W Series, EPSA 12 W EU Series, EPSA 12 W UK Series, EPSA 12 W Series, EPSA 15 W Series, EPSA 18 W EU Series, EPSA 18 W Series, EPSA 18 W UK Series, EPSA 20 W Series, EPSA 24 W Series, EPSA 5 W EU USB Series, EPSA 5 W USB Series, EPSA 6 W EU Series, EPSA 6 W Series, EPSA 6 W UK Series, ETSA 100 W U Series, ETSA 12 W UD Series, ETSA 18 W U Series, ETSA 18 W UD Series, ETSA 24 W Series, ETSA 40 W U Series, ETSA 40 W UD Series, ETSA 40W U Series, ETSA 60 W U Series, ETSA 60W UD Series, ETSA 90 W U Series, ETSA 90 W UD Series. We will accept last time buy (LTB) orders until November 11<sup>th</sup>, 2015 with a final shipment date of September, 1 2016. Acceptance of LTB orders is subject to product availability and at the discretion of CUI. Every effort will be made to fulfill these orders. However, in the event that we have some supply constraint, we reserve the right to short ship the order.

| Obsolete Part Number      | Recommended Alternatives |
|---------------------------|--------------------------|
| EMSA050260K-P5P-SZ-C1     | SMI 18 series            |
| EMSA050260NEBA-P6RP-SZ-C1 | SMI 18 series            |
| EMSA050260NEB-P5P-SZ-C1   | SMI 18 series            |
| EMSA050260N-P12P-SZ-C1    | SMI 18 series            |
| EMSA050260N-P5P-SZ        | SMI 18-5-N-P5            |
| EMSA050260N-P5P-SZ-C1     | SMI 18 series            |
| EMSA050260-P5P-SZ         | SMI 18-5-V-P5            |
| EMSA050260-P5P-SZ-C1      | SMI 18 series            |
| EMSA050260-P5P-SZ-C2      | SMI 18 series            |
| EMSA050260-P6P-SZ-C1      | SMI 18 series            |
| EMSA050260-P6P-SZ-C2      | SMI 18 series            |
| EMSA050260-P7P-SZ-C1      | SMI 18 series            |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                           |                  |
|---------------------------|------------------|
| EMSA060250EBA-P5RP-SZ-C1  | SMI 18 series    |
| EMSA060250E-S-SZ-C1       | SMI 18 series    |
| EMSA060250-P6P-SZ-C1      | SMI 18 series    |
| EMSA120125K-P86P-SZ-C1    | SMI 18 series    |
| EMSA120125NEBA-P5P-SZ-C1  | SMI 18 series    |
| EMSA120125-P122-SZ-C1     | SMI 18 series    |
| EMSA120125-P5P-SZ         | SMI 18-12-V-P5   |
| EMSA120125-P5P-SZ-C1      | SMI 18 series    |
| EMSA120125-P5P-SZ-C2      | SMI 18 series    |
| EMSA120125-P7P-SZ-C1      | SMI 18 series    |
| EMSA120125UHN-P18-SZ-C1   | SMI 18 series    |
| EMSA050300EB-P5P-SZ-C1    | SMI 18 series    |
| EMSA050300EB-P7P-SZ       | SMI 18-5-EB-P7   |
| EMSA050300K-P13RP-SZ      | SMI 18-5-K-P13R  |
| EMSA050300K-P5P-SZ        | SMI 18-5-K-P5    |
| EMSA050300K-P5P-SZ-C1     | SMI 18 series    |
| EMSA050300K-P5P-SZ-C2     | SMI 18 series    |
| EMSA050300NA-P12P-SZ      | SMI 18-5-NA-P12  |
| EMSA050300NEBA-P13P-SZ-C1 | SMI 18 series    |
| EMSA050300NEBA-P13P-SZ-C2 | SMI 18 series    |
| EMSA050300NEBA-P13P-SZ-C3 | SMI 18 series    |
| EMSA050300NEBA-P13P-SZ-C4 | SMI 18 series    |
| EMSA050300NEBA-P5P-SZ     | SMI 18-5-NEBA-P5 |
| EMSA050300NEBA-P5P-SZ-C1  | SMI 18 series    |
| EMSA050300NEBA-P5RP-SZ-C1 | SMI 18 series    |
| EMSA050300NEBA-P8P-SZ-C1  | SMI 18 series    |
| EMSA050300NEB-P7P-SZ      | SMI 18-5-NEB-P7  |
| EMSA050300NEC-P6P-SZ      | SMI 18-5-NEC-P6  |
| EMSA050300N-P135P-SZ-C1   | SMI 18 series    |
| EMSA050300N-P5P-SZ        | SMI 18-5-N-P5    |
| EMSA050300N-P6RP-SZ       | SMI 18-5-N-P6R   |
| EMSA050300N-P7P-SZ        | SMI 18-5-N-P7    |
| EMSA050300N-ST-SZ         | SMI 18-5-N-ST    |
| EMSA050300-P10P-SZ        | SMI 18-5-V-P10   |
| EMSA050300-P123P-SZ-C1    | SMI 18 series    |
| EMSA050300-P12P-SZ        | SMI 18-5-V-P12   |
| EMSA050300-P132P-SZ-C1    | SMI 18 series    |
| EMSA050300-P141P-SZ-C1    | SMI 18 series    |
| EMSA050300-P150P-SZ-C1    | SMI 18 series    |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                          |                   |
|--------------------------|-------------------|
| EMSA050300-P42P-SZ-C1    | SMI 18 series     |
| EMSA050300-P5P-SZ        | SMI 18-5-V-P5     |
| EMSA050300-P5RP-SZ       | SMI 18-5-V-P5R    |
| EMSA050300-P6P-SZ        | SMI 18-5-V-P6     |
| EMSA050300-P6P-SZ-C1     | SMI 18 series     |
| EMSA050300-P6RP-SZ       | SMI 18-5-V-P5R    |
| EMSA050300-P6RP-SZ-C1    | SMI 18 series     |
| EMSA050300-P7P-SZ        | SMI 18-5-V-P7     |
| EMSA050300-P8P-SZ        | SMI 18-5-V-P8     |
| EMSA050300-ST-SZ         | SMI 18-5-V-ST     |
| EMSA053300N-P5RP-SZ-C1   | SMI 18 series     |
| EMSA060300A-P5P-SZ       | SMI 18 series     |
| EMSA060300E-P86P-SZ-C1   | SMI 18 series     |
| EMSA060300K-P5P-SZ       | SMI 18 series     |
| EMSA060300K-P5RP-SZ      | SMI 18 series     |
| EMSA060300NEBA-P59P-SZ   | SMI 18 series     |
| EMSA060300NEBA-P5P-SZ    | SMI 18 series     |
| EMSA060300NEBA-P5P-SZ-C1 | SMI 18 series     |
| EMSA060300NEBA-P7P-SZ    | SMI 18 series     |
| EMSA060300N-P5P-SZ       | SMI 18 series     |
| EMSA060300-P10N-SZ       | SMI 18 series     |
| EMSA060300-P10P-SZ       | SMI 18 series     |
| EMSA060300-P5N-SZ        | SMI 18 series     |
| EMSA060300-P5P-SZ        | SMI 18 series     |
| EMSA060300-P5P-SZ        | SMI 18 series     |
| EMSA060300-P5P-SZ-C1     | SMI 18 series     |
| EMSA060300-P5RP-SZ       | SMI 18 series     |
| EMSA060300-P6N-SZ        | SMI 18 series     |
| EMSA060300-P6P-SZ        | SMI 18 series     |
| EMSA060300-P6P-SZ-C1     | SMI 18 series     |
| EMSA060300-P7P-SZ        | SMI 18 series     |
| EMSA060300-P7P-SZ-C1     | SMI 18 series     |
| EMSA090167-P6P-SZ-C1     | SMI 18 series     |
| EMSA090170NEBA-P5P-SZ    | SMI 18-9-NEBA-P5  |
| EMSA090170-P14P-SZ-C1    | SMI 18 series     |
| EMSA090170-P5P-SZ-C1     | SMI 18 series     |
| EMSA090170-P7P-SZ-C1     | SMI 18 series     |
| EMSA090170UN-P5P-SZ      | SMI 18-9-VRZGS-P5 |
| EMSA090200K-P5P-SZ       | SMI 18-9-K-P5     |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                             |                  |
|-----------------------------|------------------|
| EMSA090200N-P14P-SZ-C1      | SMI18 series     |
| EMSA090200N-P6P-SZ          | SMI18-9-N-P6     |
| EMSA090200N-P6P-SZ-C1       | SMI18 series     |
| EMSA090200N-P7P-SZ          | SMI18-9-N-P7     |
| EMSA090200N-P7RP-SZ-C1      | SMI18 series     |
| EMSA090200-P11P-SZ          | SMI18-9-V-P11    |
| EMSA090200-P163-SZ-C1       | SMI18 series     |
| EMSA090200-P5N-SZ           | SMI18-9-V-N5     |
| EMSA090200-P5P-SZ           | SMI18-9-V-P5     |
| EMSA090200-P5P-SZ-C1        | SMI18 series     |
| EMSA090200-P5P-SZ-C3        | SMI18 series     |
| EMSA090200-P5P-SZ-C4        | SMI18 series     |
| EMSA090200-P5RP-SZ          | SMI18-9-V-P5R    |
| EMSA090200-P6P-SZ           | SMI18-9-V-P6     |
| EMSA090200-P6RP-SZ          | SMI18-9-V-P6R    |
| EMSA090200-ST-SZ            | SMI18-9-V-ST     |
| EMSA120150E-P5P-SZ          | SMI18-12-E-P5    |
| EMSA120150E-P6P-SZ          | SMI18-12-E-P6    |
| EMSA120150E-ST-SZ           | SMI18-12-E-ST    |
| EMSA120150K-P5P-SZ          | SMI18-12-K-P5    |
| EMSA120150K-P5P-SZ-C1       | SMI18 series     |
| EMSA120150K-P6P-SZ          | SMI18-12-K-P6    |
| EMSA120150NEBA-P195RP-SZ-C1 | SMI18 series     |
| EMSA120150NEBA-P5P-SZ       | SMI18-12-NEBA-P5 |
| EMSA120150NEBA-P5P-SZ-C1    | SMI18 series     |
| EMSA120150NEBA-P7P-SZ-C1    | SMI18 series     |
| EMSA120150NECS-P5P-SZ-C1    | SMI18 series     |
| EMSA120150N-P109-SZ-C1      | SMI18 series     |
| EMSA120150N-P13P-SZ-C1      | SMI18 series     |
| EMSA120150N-P14P-SZ         | SMI18-12-N-P14   |
| EMSA120150N-P14P-SZ-C2      | SMI18 series     |
| EMSA120150N-P14P-SZ-C3      | SMI18 series     |
| EMSA120150N-P14P-SZ-C4      | SMI18 series     |
| EMSA120150N-P5P-SZ          | SMI18-12-N-P5    |
| EMSA120150N-P5P-SZ-C2       | SMI18 series     |
| EMSA120150N-P5RP-SZ         | SMI18-12-N-P5R   |
| EMSA120150N-P7P-SZ          | SMI18-12-N-P7    |
| EMSA120150-P10P-SZ          | SMI18-12-V-P10   |
| EMSA120150-P134-SZ          | SMI18 series     |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
[www.cui.com](http://www.cui.com)

|                        |                 |
|------------------------|-----------------|
| EMSA120150-P13P-SZ-C10 | SMI 18 series   |
| EMSA120150-P15P-SZ     | SMI 18 series   |
| EMSA120150-P200-SZ-C1  | SMI 18 series   |
| EMSA120150-P59P-SZ-C1  | SMI 18 series   |
| EMSA120150-P5P-SZ      | SMI 18-12-V-P5  |
| EMSA120150-P5P-SZ      | SMI 18-12-V-P5  |
| EMSA120150-P5P-SZ-C1   | SMI 18 series   |
| EMSA120150-P5P-SZ-C10  | SMI 18 series   |
| EMSA120150-P5P-SZ-C2   | SMI 18 series   |
| EMSA120150-P5P-SZ-C3   | SMI 18 series   |
| EMSA120150-P5P-SZ-C4   | SMI 18 series   |
| EMSA120150-P5P-SZ-C5   | SMI 18 series   |
| EMSA120150-P5P-SZ-C6   | SMI 18 series   |
| EMSA120150-P5P-SZ-C7   | SMI 18 series   |
| EMSA120150-P5P-SZ-C8   | SMI 18 series   |
| EMSA120150-P5P-SZ-C9   | SMI 18 series   |
| EMSA120150-P5RP-SZ     | SMI 18-12-V-P5R |
| EMSA120150-P5RP-SZ     | SMI 18-12-V-P5R |
| EMSA120150-P6P-SZ      | SMI 18-12-V-P6  |
| EMSA120150-P6P-SZ-C1   | SMI 18 series   |
| EMSA120150-P6P-SZ-C2   | SMI 18 series   |
| EMSA120150-P6RP-SZ     | SMI 18-12-V-P6R |
| EMSA120150S-P5P-SZ     | SMI 18-12-S-P5  |
| EMSA120150-ST-SZ       | SMI 18-12-V-ST  |
| EMSA120150-ST-SZ-C10   | SMI 18 series   |
| EMSA150100N-P5P-SZ-C1  | SMI 18 series   |
| EMSA150100-P5P-SZ-C1   | SMI 18 series   |
| EMSA150100-P5P-SZ-C2   | SMI 18 series   |
| EMSA150120K-P5P-SZ     | SMI 18-15-K-P5  |
| EMSA150120K-P5RP-SZ    | SMI 18-15-K-P5R |
| EMSA150120N-P8P-SZ-C1  | SMI 18 series   |
| EMSA150120N-P9P-SZ     | SMI 18-15-N-P9  |
| EMSA150120N-ST-SZ-C1   | SMI 18 series   |
| EMSA150120-P5P-SZ      | SMI 18-15-V-P5  |
| EMSA150120-P5P-SZ-C1   | SMI 18 series   |
| EMSA150120-P5RP-SZ     | SMI 18-15-V-P5R |
| EMSA150120-P6P-SZ      | SMI 18-15-V-P6  |
| EMSA150120-P6RP-SZ     | SMI 18-15-V-P6R |
| EMSA150120-P8P-SZ      | SMI 18-15-V-P8  |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                          |                |
|--------------------------|----------------|
| EMSA180100EB-P5P-SZ      | SMI18-18-EB-P5 |
| EMSA180100K-P5P-SZ       | SMI18-18-K-P5  |
| EMSA180100NEBA-PFC-SZ-C1 | SMI18 series   |
| EMSA180100N-P5P-SZ       | SMI18-18-N-P5  |
| EMSA180100N-P5RP-SZ-C1   | SMI18 series   |
| EMSA180100-P5P-SZ        | SMI18-18-V-P5  |
| EMSA180100-P5RP-SZ       | SMI18-18-V-P5R |
| EMSA180100-P6P-SZ        | SMI18-18-V-P6  |
| EMSA180100-P6RP-SZ       | SMI18-18-V-P6R |
| EMSA180100-P7RP-SZ       | SMI18-18-V-P7R |
| EMSA200090K-P5P          | SMI18-20-K-P5  |
| EMSA200090N-P6P-SZ-C1    | SMI18 series   |
| EMSA200090-P5N-SZ        | SMI18-20-V-N5  |
| EMSA200090-P5P-SZ        | SMI18-20-V-P5  |
| EMSA200090-P5RP          | SMI18-20-V-P5R |
| EMSA200090-P6P           | SMI18-20-V-P6  |
| EMSA200090-P6RP          | SMI18-20-V-P6R |
| EMSA240075K-P5P-SZ       | SMI18-24-K-P5  |
| EMSA240075K-P5P-SZ       | SMI18-24-K-P5  |
| EMSA240075K-P5P-SZ-C1    | SMI18 series   |
| EMSA240075K-ST-SZ        | SMI18-24-K-ST  |
| EMSA240075N-P5N-SZ       | SMI18-24-N-N5  |
| EMSA240075N-P5N-SZ-C1    | SMI18 series   |
| EMSA240075N-P5P-SZ       | SMI18-24-N-P5  |
| EMSA240075N-P5P-SZ-C1    | SMI18 series   |
| EMSA240075N-P5P-SZ-C2    | SMI18 series   |
| EMSA240075-P10P-SZ       | SMI18-24-V-P10 |
| EMSA240075-P5P-SZ        | SMI18-24-V-P5  |
| EMSA240075-P5P-SZ-C1     | SMI18 series   |
| EMSA240075-P5P-SZ-C2     | SMI18 series   |
| EMSA240075-P5RP-SZ       | SMI18-24-V-P5R |
| EMSA240075-P6P-SZ        | SMI18-24-V-P6  |
| EMSA240075-P6RP-SZ       | SMI18-24-V-P6R |
| EMSA240075-P7P-SZ        | SMI18-24-V-P7  |
| EMSA240075-S/T-SZ        | SMI18-24-V-ST  |
| EMSA120150K-P5P-SZ-C4    | SMI18 series   |
| EMSA120150-UN-P10P-SZ    | SMI18 series   |
| EMSA120150-UN-P11P-SZ    | SMI18 series   |
| EMSA120150-UN-P12P-SZ    | SMI18 series   |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                          |                  |
|--------------------------|------------------|
| EMSA120150-UN-P12RP-SZ   | SMI18 series     |
| EMSA120150-UN-P13P-SZ    | SMI18 series     |
| EMSA120150-UN-P13P-SZ-C1 | SMI18 series     |
| EMSA120150-UN-P13RP-SZ   | SMI18 series     |
| EMSA120150-UN-P14P-SZ    | SMI18 series     |
| EMSA120150-UN-P14RP-SZ   | SMI18 series     |
| EMSA120150-UN-P5P-SZ     | SMI18 series     |
| EMSA120150-UN-P5RP-SZ    | SMI18 series     |
| EMSA120150-UN-P6P-SZ     | SMI18 series     |
| EMSA120150-UN-P6RP-SZ    | SMI18 series     |
| EMSA120150-UN-P7P-SZ     | SMI18 series     |
| EMSA120150-UN-P7RP-SZ    | SMI18 series     |
| EMSA120150-UN-P8P-SZ     | SMI18 series     |
| EMSA120150-UN-P8RP-SZ    | SMI18 series     |
| EMSA120150-UN-P9P-SZ     | SMI18 series     |
| EMSA120150-UN-P9RP-SZ    | SMI18 series     |
| EMSA120150-UN-ST-SZ      | SMI18 series     |
| EMSA120250B-P120-SZ-C1   | SMI36 series     |
| EMSA120250EBA-P59P-SZ-C1 | SMI36 series     |
| EMSA120250EBA-P5P-SZ     | SMI36-12-EBA-P5  |
| EMSA120250E-P120-SZ-C1   | SMI36 series     |
| EMSA120250E-P5P-SZ       | SMI36-12-E-P5    |
| EMSA120250K-P171-SZ-C1   | SMI36 series     |
| EMSA120250K-P177P-SZ-C1  | SMI36 series     |
| EMSA120250K-P5P-SZ       | SMI36-12-K-P5    |
| EMSA120250NEBA-P51-SZ-C1 | SMI36 series     |
| EMSA120250NEBA-P5P-SZ    | SMI36-12-NEBA-P5 |
| EMSA120250N-P120-SZ-C1   | SMI36 series     |
| EMSA120250N-P5P-SZ       | SMI36-12-N-P5    |
| EMSA120250N-P5P-SZ       | SMI36-12-N-P5    |
| EMSA120250N-P5P-SZ-C1    | SMI36 series     |
| EMSA120250N-ST-SZ        | SMI36-12-N-ST    |
| EMSA120250-P10P-SZ       | SMI36-12-V-P10   |
| EMSA120250-P11P-SZ       | SMI36-12-V-P11   |
| EMSA120250-P127-SZ-C1    | SMI36 series     |
| EMSA120250-P139-SZ-C1    | SMI36 series     |
| EMSA120250-P15P-SZ-C1    | SMI36 series     |
| EMSA120250-P5P-SZ        | SMI36-12-V-P5    |
| EMSA120250-P5P-SZ        | SMI36-12-V-P5    |





20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                             |                   |
|-----------------------------|-------------------|
| EMSA120250-P5P-SZ-C1        | SMI36 series      |
| EMSA120250-P5RP-SZ          | SMI36-12-V-P5R    |
| EMSA120250-P6P-SZ           | SMI36-12-V-P6     |
| EMSA120250-P6P-SZ-C1        | SMI36 series      |
| EMSA120250-P6P-SZ-C2        | SMI36 series      |
| EMSA120250-P6RP-SZ          | SMI36-12-V-P6R    |
| EMSA120250-P7P-SZ           | SMI36-12-V-P7     |
| EMSA120250-ST-SZ            | SMI36-12-V-ST     |
| EMSA150200NEBA-P5P-SZ-C1    | SMI36 series      |
| EMSA150200N-P10P-SZ         | SMI36-15-N-P10    |
| EMSA200150K-P5P-SZ          | SMI36-20-K-P5     |
| EMSA200150K-P5P-SZ-C1       | SMI36 series      |
| EMSA200150NEBA-P6P-SZ-C1    | SMI36 series      |
| EMSA200150NEBA-P6P-SZ-C2    | SMI36 series      |
| EMSA200150N-P5P-SZ-C1       | SMI36 series      |
| EMSA200150-P5P-SZ           | SMI36 series      |
| EMSA200150-P5RP-SZ          | SMI36 series      |
| EMSA200150-P6P-SZ           | SMI36 series      |
| EMSA200150-P6RP-SZ          | SMI36 series      |
| EMSA240125K-P5P-SZ          | SMI36-24-K-P5     |
| EMSA240125NEBA-P14RP-SZ-C1  | SMI18 series      |
| EMSA240125NE-P5P-SZ         | SMI36-24-NE-P5    |
| EMSA240125N-P5P-SZ          | SMI36-24-N-P5     |
| EMSA240125N-P7P-SZ          | SMI36-24-N-P7     |
| EMSA240125N-ST-SZ-C1        | SMI36 series      |
| EMSA240125-P5P-SZ           | SMI36-24-V-P5     |
| EMSA240125-P5RP-SZ          | SMI36-24-V-P5R    |
| EMSA240125-P6P-SZ           | SMI36-24-V-P6     |
| EMSA240125-P6RP-SZ          | SMI36-24-V-P6R    |
| EMSA240125-ST-SZ            | SMI36-24-V-ST     |
| EMSA240167ABEN-P145-SZ-C1   | SMI36 series      |
| EMSA120300K-P13P-SZ-C1      | SMI36 series      |
| EMSA120300K-P5P-SZ          | SMI36-12-K-P5     |
| EMSA120300K-P6P             | SMI36-12-K-P6     |
| EMSA120300K-P6P-SZ-C1       | SMI36 series      |
| EMSA120300NEBA-P13P-SZ      | SMI36-12-NEBA-P13 |
| EMSA120300NEBA-P194RP-SZ-C1 | SMI36 series      |
| EMSA120300NEBA-P6P-SZ       | SMI36-12-NEBA-P6  |
| EMSA120300N-P10P-SZ         | SMI36-12-N-P10    |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                        |                  |
|------------------------|------------------|
| EMSA120300N-P10P-SZ    | SMI36-12-N-P10   |
| EMSA120300N-P11P-SZ    | SMI36-12-N-P11   |
| EMSA120300N-P12RP-SZ   | SMI36-12-N-P12R  |
| EMSA120300N-P177-SZ-C1 | SMI36 series     |
| EMSA120300N-P5P-SZ     | SMI36-12-N-P5    |
| EMSA120300N-P5P-SZ-C2  | SMI36 series     |
| EMSA120300N-P6P-SZ     | SMI36-12-N-P6    |
| EMSA120300N-P6P-SZ-C1  | SMI36 series     |
| EMSA120300N-ST-SZ-C1   | SMI36 series     |
| EMSA120300-P11P-SZ     | SMI36-12-V-P11   |
| EMSA120300-P12P-SZ     | SMI36-12-V-P12   |
| EMSA120300-P132P-SZ-C1 | SMI36 series     |
| EMSA120300-P13P-SZ     | SMI36-12-V-P13   |
| EMSA120300-P5P-SZ      | SMI36-12-V-P5    |
| EMSA120300-P5P-SZ-C1   | SMI36 series     |
| EMSA120300-P5P-SZ-C3   | SMI36 series     |
| EMSA120300-P5RP-SZ     | SMI36-12-V-P5R   |
| EMSA120300-P5RP-SZ-C2  | SMI36 series     |
| EMSA120300-P6P-SZ      | SMI36-12-V-P6    |
| EMSA120300-P6RP-SZ     | SMI36-12-V-P6R   |
| EMSA120300-ST-SZ       | SMI36-12-V-ST    |
| EMSA200200K-P5P-SZ     | SMI36 series     |
| EMSA200200-P5P-SZ      | SMI36 series     |
| EMSA200200-P5RP-SZ     | SMI36 series     |
| EMSA200200-P6P-SZ      | SMI36 series     |
| EMSA200200-P6RP-SZ     | SMI36 series     |
| EMSA240167K-P5P-SZ     | SMI36-24-K-P5    |
| EMSA240167NEBA-P5P-SZ  | SMI36-24-NEBA-P5 |
| EMSA240167N-P5P-SZ     | SMI36-24-N-P5    |
| EMSA240167N-ST-SZ-C1   | SMI36 series     |
| EMSA240167-P10P-SZ     | SMI36-24-V-P10   |
| EMSA240167-P5P-SZ      | SMI36-24-V-P5    |
| EMSA240167-P5P-SZ-C1   | SMI36 series     |
| EMSA240167-P5P-SZ-C1   | SMI36 series     |
| EMSA240167-P5RP-SZ     | SMI36-24-V-P5R   |
| EMSA240167-P6P-SZ      | SMI36-24-V-P6    |
| EMSA240167-P6RP-SZ     | SMI36-24-V-P6R   |
| EMSA240167-ST-SZ       | SMI36-24-V-ST    |
| EMSA120300E-P5P-SZ     | SMI36-12-E-P5    |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

EMSA120300E-P6P-SZ  
EMSA120300N-P7P-SZ  
EMSA050100-I38-SZ  
EMSA050100-I38-SZ-C1  
EMSA050100-I38-SZ-C3  
EMSA050100-I38-SZ-C4  
EMSA050100-I38-SZ-C4  
EMSA050100-I38-SZ-C5  
EMSA050100K-I38-SZ  
EMSA050100NEBA-I38-SZ  
EMSA050100NEBA-I38-SZ-C1  
EMSA050100N-I38-SZ  
EMSA050100-P7RP-SZ-C1  
EMSA050100N-I38-SZ-C1  
EMSA040150NA-P7P-SZ  
EMSA050120EB-P5P-SZ-C1  
EMSA050120E-P12P-SZ-C1  
EMSA050120E-P13P-SZ  
EMSA050120-I38-SZ-C1  
EMSA050120K-P122-SZ  
EMSA050120K-P5P-SZ  
EMSA050120K-P7P-SZ  
EMSA050120NEBA-P122-SZ-C1  
EMSA050120NEBA-P5P-SZ  
EMSA050120NEBA-P8P-SZ-C1  
EMSA050120NEB-P5P-SZ  
EMSA050120NEB-P6P-SZ  
EMSA050120NEB-P70P-SZ-C1  
EMSA050120N-P122-SZ  
EMSA050120N-P12P-SZ-C1  
EMSA050120N-P5P-SZ  
EMSA050120N-P5P-SZ  
EMSA050120N-P5P-SZ-C1  
EMSA050120N-P5P-SZ-C2  
EMSA050120N-P5RN-SZ  
EMSA050120N-P7P-SZ-C1  
EMSA050120N-P7P-SZ-C2  
EMSA050120N-P8P-SZ  
EMSA050120-P122-SZ-C1

SMI36-12-E-P6  
SMI36-12-N-P7  
SMI5-5-V-I38  
SMI5-USB series  
SMI5-USB series  
SMI5-USB series  
SMI5-USB series  
SMI5-USB series  
SMI5-5-K-I38  
SMI5-5-NEBA-I38  
SMI5-USB series  
SMI5-5-N-I38  
SMI6 series  
SMI5-USB series  
SMI6 series  
SMI6 series  
SMI6 series  
SMI6-5-E-P13  
SMI5-USB series  
SMI6 series  
SMI6-5-K-P5  
SMI6-5-K-P7  
SMI6 series  
SMI6-5-NEBA-P5  
SMI6 series  
SMI6-5-NEB-P5  
SMI6-5-NEB-P6  
SMI6 series  
SMI6 series  
SMI6 series  
SMI6-5-N-P5  
SMI6-5-N-P5  
SMI6 series  
SMI6 series  
SMI6-5-N-N5R  
SMI6 series  
SMI6 series  
SMI6-5-N-P8  
SMI6 series



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                           |                |
|---------------------------|----------------|
| EMSA050120-P12P-SZ        | SMI6-5-V-P12   |
| EMSA050120-P12P-SZ-C1     | SMI6 series    |
| EMSA050120-P12RP-SZ       | SMI6-5-V-P12R  |
| EMSA050120-P12RP-SZ-C1    | SMI6 series    |
| EMSA050120-P193-SZ-C1     | SMI6 series    |
| EMSA050120-P37-SZ-C1      | SMI6 series    |
| EMSA050120-P5N-SZ         | SMI6-5-V-N5    |
| EMSA050120-P5P-SZ         | SMI6-5-V-P5    |
| EMSA050120-P5P-SZ         | SMI6-5-V-P5    |
| EMSA050120-P5P-SZ-C1      | SMI6 series    |
| EMSA050120-P5RP-SZ        | SMI6-5-V-P5R   |
| EMSA050120-P5RP-SZ        | SMI6-5-V-P5R   |
| EMSA050120-P6P-SZ         | SMI6-5-V-P6    |
| EMSA050120-P6P-SZ         | SMI6-5-V-P6    |
| EMSA050120-P6P-SZ-C1      | SMI6 series    |
| EMSA050120-P7P-SZ         | SMI6-5-V-P7    |
| EMSA050120-ST-SZ          | SMI6-5-V-ST    |
| EMSA060100ABEN-P12P-SZ-C1 | SMI6 series    |
| EMSA060100EBA-P6P-SZ-C1   | SMI6 series    |
| EMSA060100NEBA-P5N-SZ-C1  | SMI6 series    |
| EMSA060100N-P6P-SZ-C1     | SMI6 series    |
| EMSA060100-P5P-SZ-C1      | SMI6 series    |
| EMSA060100-P5P-SZ-C2      | SMI6 series    |
| EMSA060100-P5P-SZ-C3      | SMI6 series    |
| EMSA060100-P5RP-SZ        | SMI6 series    |
| EMSA090067BE-P7P-SZ       | SMI18-9-BE-P7  |
| EMSA090067EB-P6P-SZ-C1    | SMI18 series   |
| EMSA090067K-P5P-SZ        | SMI18-9-K-P5   |
| EMSA090067K-P5P-SZ        | SMI18-9-K-P5   |
| EMSA090067K-ST-SZ         | SMI18-9-K-ST   |
| EMSA090067NEB-P5P-SZ      | SMI18-9-NEB-P5 |
| EMSA090067N-P12P-SZ-C1    | SMI18 series   |
| EMSA090067N-P5P-SZ-C1     | SMI18 series   |
| EMSA090067N-P7P-SZ        | SMI18-9-N-P7   |
| EMSA090067-P167P-SZ-C1    | SMI18 series   |
| EMSA090067-P42P-SZ-C1     | SMI18 series   |
| EMSA090067-P5P-SZ         | SMI18-9-V-P5   |
| EMSA090067-P5RN-SZ-C1     | SMI18 series   |
| EMSA090067-P5RP-SZ        | SMI18-9-V-P5R  |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                            |                  |
|----------------------------|------------------|
| EMSA090067-P6P-SZ          | SMI 18-9-V-P6    |
| EMSA090067-P7P-SZ          | SMI 18-9-V-P7    |
| EMSA090067-P7RP-SZ         | SMI 18-9-V-P7R   |
| EMSA090067-P8P-SZ          | SMI 18-9-V-P8    |
| EMSA090067-ST-SZ           | SMI 18-9-V-ST    |
| EMSA100060-P49P-SZ-C1      | SMI 6 series     |
| EMSA120050BCE-P5RP-SZ-C1   | SMI 6 series     |
| EMSA120050B-P120-SZ-C1     | SMI 6 series     |
| EMSA120050C-P5RP-SZ        | SMI 6-12-C-P5R   |
| EMSA120050EBAC-P6P-SZ      | SMI 6-12-EBAC-P6 |
| EMSA120050E-P120-SZ-C1     | SMI 6 series     |
| EMSA120050K-P10P-SZ        | SMI 6-12-K-P10   |
| EMSA120050K-P5P-SZ         | SMI 6-12-K-P5    |
| EMSA120050K-P5P-SZ-C1      | SMI 6 series     |
| EMSA120050K-P5P-SZ-C2      | SMI 6 series     |
| EMSA120050K-P5RP-SZ        | SMI 6-12-K-P5R   |
| EMSA120050K-P6P-SZ         | SMI 6-12-K-P6    |
| EMSA120050NC-P5RP-SZ       | SMI 6-12-NC-P5R  |
| EMSA120050NEBAC-P126-SZ-C1 | SMI 6 series     |
| EMSA120050NEB-P6P-SZ       | SMI 6-12-NEB-P6  |
| EMSA120050N-P10P-SZ        | SMI 6-12-N-P10   |
| EMSA120050N-P120-SZ-C1     | SMI 6 series     |
| EMSA120050N-P5RP-SZ        | SMI 6-12-N-P5R   |
| EMSA120050N-ST-SZ          | SMI 6-12-N-ST    |
| EMSA120050-P11P-SZ         | SMI 6-12-V-P11   |
| EMSA120050-P122-SZ-C1      | SMI 6 series     |
| EMSA120050-P5P-SZ          | SMI 6-12-V-P5    |
| EMSA120050-P5P-SZ-C2       | SMI 6 series     |
| EMSA120050-P5P-SZ-C3       | SMI 6 series     |
| EMSA120050-P5RP-SZ         | SMI 6-12-V-P5R   |
| EMSA120050-P5RP-SZ         | SMI 6-12-V-P5R   |
| EMSA120050-P6P-SZ          | SMI 6-12-V-P6    |
| EMSA120050-P6P-SZ          | SMI 6-12-V-P6    |
| EMSA120050-P6RP-SZ         | SMI 6-12-V-P6R   |
| EMSA120050-P7P-SZ          | SMI 6-12-V-P7    |
| EMSA120050-P7P-SZ-C1       | SMI 6 series     |
| EMSA120050-P7RP-SZ         | SMI 6-12-V-P7R   |
| EMSA120050-P9P-SZ          | SMI 6-12-V-P9    |
| EMSA120050-ST-SZ           | SMI 6-12-V-ST    |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
[www.cui.com](http://www.cui.com)

EMSA150040K-P5P-SZ  
EMSA150040-P5P-SZ  
EMSA150040-P5RP-SZ  
EMSA150040-P6P-SZ  
EMSA150040-P6RP-SZ  
EMSA150040-ST-SZ  
EPS030100-P12P  
EPS030100-P1P  
EPS030100-P5P  
EPS030100-P6RP  
EPS030100-P7P  
EPS033100-P5P  
EPS033100-P5RP  
EPS033100-P6P  
EPS033100-P6RP  
EPS033100-P7P  
EPS045100-P12P  
EPS045100-P5N  
EPS045100-P5P  
EPS045100-P5P  
EPS045100-P5RP  
EPS045100-P6P  
EPS045100-P6RP  
EPS045100-P7P  
EPS050100-P10-SZ  
EPS050100-P11P  
EPS050100-P12P  
EPS050100-P12P-C1  
EPS050100-P12P-C1  
EPS050100-P12P-C2  
EPS050100-P12P-C3  
EPS050100-P12P-C4  
EPS050100-P12P-C5  
EPS050100-P12P-C7  
EPS050100-P12P-C8  
EPS050100-P13P  
EPS050100-P13P  
EPS050100-P13P  
EPS050100-P13P-C1

SMI6-15-K-P5  
SMI6-15-V-P5  
SMI6-15-V-P5R  
SMI6-15-V-P6  
SMI6-15-V-P6R  
SMI6-15-V-ST  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-5-N-P12  
SWI6-5-N-N5  
SWI6-5-N-P5  
SWI6-5-N-P5  
SWI6-5-N-P5R  
SWI6-5-N-P6  
SWI6-5-N-P6R  
SWI6-5-N-P7  
SWI6-5-N-P10  
SWI6-5-N-P11  
SWI6-5-N-P12  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-N series  
SWI6-5-N-P13  
SWI6-5-N-P13  
SWI6-5-N-P13  
SWI6-N series



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
[www.cui.com](http://www.cui.com)

|                   |                 |
|-------------------|-----------------|
| EPS050100-P5N     | SWI6-5-N-N5     |
| EPS050100-P5P     | SWI6-5-N-P5     |
| EPS050100-P5P     | SWI6-5-N-P5     |
| EPS050100-P5P-C1  | SWI6-N series   |
| EPS050100-P5RP    | SWI6-5-N-P5R    |
| EPS050100-P5RP    | SWI6-5-N-P5R    |
| EPS050100-P6P     | SWI6-5-N-P6     |
| EPS050100-P6P     | SWI6-5-N-P6     |
| EPS050100-P6P     | SWI6-5-N-P6     |
| EPS050100-P6RP    | SWI6-5-N-P6R    |
| EPS050100-P7P     | SWI6-5-N-P7     |
| EPS050100-P7P     | SWI6-5-N-P7     |
| EPS050100-P7P     | SWI6-5-N-P7     |
| EPS050100-P9P     | SWI6-5-N-P9     |
| EPS050100-ST-C1   | SWI6-N series   |
| EPS060100-P11P    | SWI6-5.9-N-P11  |
| EPS060100-P13RP   | SWI6-5.9-N-P13R |
| EPS060100-P5N     | SWI6-5.9-N-N5   |
| EPS060100-P5P     | SWI6-5.9-N-P5   |
| EPS060100-P5P     | SWI6-5.9-N-P5   |
| EPS060100-P5P-C1  | SWI6-N series   |
| EPS060100-P5RN    | SWI6-5.9-N-N5R  |
| EPS060100-P5RP    | SWI6-5.9-N-P5R  |
| EPS060100-P6P     | SWI6-5.9-N-P6   |
| EPS060100-P6RP    | SWI6-5.9-N-P6R  |
| EPS060100-P7P     | SWI6-5.9-N-P7   |
| EPS060100-P7RP    | SWI6-5.9-N-P7R  |
| EPS075080-P10P    | SWI6-N series   |
| EPS075080-P5P     | SWI6-N series   |
| EPS090055U-P7N-SZ | SWI6-N series   |
| EPS090066-P14P    | SWI6-N series   |
| EPS090066-P1P     | SWI6-N series   |
| EPS090066-P5N     | SWI6-N series   |
| EPS090066-P5P     | SWI6-N series   |
| EPS090066-P5RP    | SWI6-N series   |
| EPS090066-P5RP-C1 | SWI6-N series   |
| EPS090066-P6P     | SWI6-N series   |
| EPS090066-P6RP    | SWI6-N series   |
| EPS090066-P7N     | SWI6-N series   |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
[www.cui.com](http://www.cui.com)

|                       |               |
|-----------------------|---------------|
| EPS090066-P7P         | SWI6-N series |
| EPS090066-P7P         | SWI6-N series |
| EPS090066-P7P-C1      | SWI6-N series |
| EPS090066-P7P-C2      | SWI6-N series |
| EPS090066-P9P-C1      | SWI6-N series |
| EPS090066-S/T         | SWI6-N series |
| EPS090066-S/T-C1      | SWI6-N series |
| EPS090066-S/T-C1      | SWI6-N series |
| EPS090066-ST          | SWI6-N series |
| EPS090066-ST-C1       | SWI6-N series |
| EPS120050-P10P        | SWI6-12-N-P10 |
| EPS120050-P12P        | SWI6-12-N-P12 |
| EPS120050-P136P-SZ-C1 | SWI6-N series |
| EPS120050-P13P        | SWI6-12-N-P13 |
| EPS120050-P1P         | none          |
| EPS120050-P1RP        | none          |
| EPS120050-P5N         | SWI6-12-N-N5  |
| EPS120050-P5P         | SWI6-12-N-P5  |
| EPS120050-P5P         | SWI6-12-N-P5  |
| EPS120050-P5P-C2      | SWI6-N series |
| EPS120050-P5P-C3      | SWI6-N series |
| EPS120050-P5P-C4      | SWI6-N series |
| EPS120050-P5RP        | SWI6-12-N-P5R |
| EPS120050-P5RP-C1     | SWI6-N series |
| EPS120050-P6P         | SWI6-12-N-P6  |
| EPS120050-P6P-C1      | SWI6-N series |
| EPS120050-P7P         | SWI6-12-N-P7  |
| EPS120050-P7P         | SWI6-12-N-P7  |
| EPS120050-P7P-C1      | SWI6-N series |
| EPS120050-ST          | SWI6-12-N-ST  |
| EPS120050-ST-SZ       | SWI6-12-N-ST  |
| EPS150040-P5P         | SWI6-N series |
| EPS150040-P5P         | SWI6-N series |
| EPS150040-P5RP        | SWI6-N series |
| EPS150040-P6P         | SWI6-N series |
| EPS150040-P6RP        | SWI6-N series |
| EPS150040-ST          | SWI6-N series |
| EPS180033-P5N         | SWI6-N series |
| EPS180033-P5P         | SWI6-N series |





20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
[www.cui.com](http://www.cui.com)

|                         |                |
|-------------------------|----------------|
| EPS180033-P5P           | SWI6-N series  |
| EPS180033-P5P           | SWI6-N series  |
| EPS180033-P5P-C1        | SWI6-N series  |
| EPS180033-P5RP          | SWI6-N series  |
| EPS180033-P6P           | SWI6-N series  |
| EPS180033-P6RP          | SWI6-N series  |
| EPS180033-ST            | SWI6-N series  |
| EPS240025-P5N           | SWI6-N series  |
| EPS240025-P5P           | SWI6-N series  |
| EPS240025-P5P           | SWI6-N series  |
| EPS240025-P5P-C1        | SWI6-N series  |
| EPS240025-P5RP          | SWI6-N series  |
| EPS240025-P6P           | SWI6-N series  |
| EPS240025-P6RP          | SWI6-N series  |
| EPS240025-P8P           | SWI6-N series  |
| EPS240025-P9P           | SWI6-N series  |
| EPS240025-ST-SZ         | SWI6-N series  |
| EPSA033180UW-P5RP-SZ    | SWI6-N series  |
| EPSA033180UW-P6P-SZ     | SWI6-N series  |
| EPSA033180UW-P6RP-SZ    | SWI6-N series  |
| EPS030100-P5P           | SWI6-N series  |
| EPSA050200UE-I38-SZ-C1  | SWI12-E series |
| EPSA050200UE-P6P-EJ-C1  | SWI12-E series |
| EPSA050250UE-P5P-EJ     | SWI12-5-E-P5   |
| EPSA080150UE-P5P-SZ-C1  | SWI12-E series |
| EPSA120100UE-P5P-EJ     | SWI12-E series |
| EPSA480025UE-P6P-SZ-C1  | SWI12-E series |
| EPSA050150U-S/T-DB-C1   | SWI12-N series |
| EPSA050200-I38-SZ-C1    | SWI12-N series |
| EPSA050200UA-P6P-EJ-C1  | SWI12-N series |
| EPSA050200UH-P13P-DB-C1 | SWI12-N series |
| EPSA050200UH-P5RP-SZ-C1 | SWI12-N series |
| EPSA050200U-I38-SZ-C1   | SWI12-N series |
| EPSA050200U-P131P-DB-C1 | SWI12-N series |
| EPSA050200U-P5P-SZ-C1   | SWI12-N series |
| EPSA050200U-P6P-EJ-C1   | SWI12-N series |
| EPSA050200U-P6P-SZ-C1   | SWI12-N series |
| EPSA050200U-P7P-SZ-C1   | SWI12-N series |
| EPSA050200U-P7P-SZ-C2   | SWI12-N series |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                          |                |
|--------------------------|----------------|
| EPSA050200UPS-P5P-SZ-C2  | SWI12-N series |
| EPSA050250UB-P5RP-EJ     | SMI18 series   |
| EPSA050250UB-P6P-EJ      | SMI18 series   |
| EPSA050250UB-P6RP-EJ     | SMI18 series   |
| EPSA050250UE-P5RP-EJ     | SWI12-5-E-P5R  |
| EPSA050250UE-P6RP-EJ     | SWI12-5-E-P6R  |
| EPSA050250U-P11P-EJ      | SWI12-5-N-P11  |
| EPSA050250U-P12P-EJ      | SWI12-5-N-P12  |
| EPSA050250U-P12P-EJ-C1   | SWI12-N series |
| EPSA050250U-P12P-EJ-C2   | SWI12-N series |
| EPSA050250U-P12P-SZ-C1   | SWI12-N series |
| EPSA050250U-P12P-SZ-C2   | SWI12-N series |
| EPSA050250U-P12P-SZ-C3   | SWI12-N series |
| EPSA050250U-P12RP-EJ     | SWI12-5-N-P12R |
| EPSA050250U-P13P-EJ      | SWI12-5-N-P13  |
| EPSA050250U-P173P-EJ-C1  | SWI12-N series |
| EPSA050250U-P1P-EJ       | none           |
| EPSA050250U-P42P-EJ-C1   | SWI12-N series |
| EPSA050250U-P5P-EJ       | SWI12-5-N-P5   |
| EPSA050250U-P5P-SZ-C1    | SWI12-N series |
| EPSA050250U-P5RP-EJ      | SWI12-5-N-P5R  |
| EPSA050250U-P6N-EJ-C1    | SWI12-N series |
| EPSA050250U-P6P-EJ       | SWI12-5-N-P6   |
| EPSA050250U-P6RP-EJ      | SWI12-5-N-P6R  |
| EPSA050250U-P6RP-SZ      | SWI12-5-N-P6R  |
| EPSA050250U-P7P-EJ       | SWI12-5-N-P7   |
| EPSA050250U-P7P-EJ-C1    | SWI12-N series |
| EPSA050250U-P7P-SZ-C1    | SWI12-N series |
| EPSA050250U-P9P-EJ-C2    | SWI12-N series |
| EPSA050250U-ST-EJ        | SWI12-5-N-ST   |
| EPSA055200U-P5P-SZ-C1    | SWI12-N series |
| EPSA060200UA-P5RP-DB-C1  | SWI12-N series |
| EPSA060200U-P5P-EJ       | SWI12-6-N-P5   |
| EPSA060200U-P5RP-DB-C1   | SWI12-N series |
| EPSA060200U-P5RP-EJ      | SWI12-6-N-P5R  |
| EPSA060200U-TDP001-DB-C1 | SWI12-N series |
| EPSA090130UB-P5P-EJ-C2   | SWI12-N series |
| EPSA090130UE-P5P-EJ-C2   | SWI12-N series |
| EPSA090130U-P5N-EJ       | SWI12-N series |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                         |                |
|-------------------------|----------------|
| EPSA090130U-P5P-EJ      | SWI12-N series |
| EPSA090130U-P5P-EJ-C1   | SWI12-N series |
| PSA090130U-P5P-EJ-C2    | SWI12-N series |
| EPSA090130U-P5RP-EJ     | SWI12-N series |
| EPSA090130U-P6P-EJ      | SWI12-N series |
| EPSA090130U-P7RP-EJ-C1  | SWI12-N series |
| EPSA090130U-Z5RP        | SWI12-N series |
| EPSA120100UH-P5P-DB-C1  | SWI12-N series |
| EPSA120100UH-P5P-EJ-C1  | SWI12-N series |
| EPSA120100UH-P5P-SZ-C1  | SWI12-N series |
| EPSA120100U-P11P-EJ     | SWI12-12-N-P11 |
| EPSA120100U-P125-SZ-C1  | SWI12-N series |
| EPSA120100U-P137-SZ-C1  | SWI12-N series |
| EPSA120100U-P192-EJ-C1  | SWI12-N series |
| EPSA120100U-P5N-EJ      | SWI12-12-N-N5  |
| EPSA120100U-P5P-DB-C2   | SWI12-N series |
| EPSA120100U-P5P-EJ      | SWI12-12-N-P5  |
| EPSA120100U-P5P-EJ-C1   | SWI12-N series |
| EPSA120100U-P5P-SZ-C1   | SWI12-N series |
| EPSA120100U-P5P-SZ-C2   | SWI12-N series |
| EPSA120100U-P5P-SZ-C3   | SWI12-N series |
| EPSA120100U-P5P-SZ-C4   | SWI12-N series |
| EPSA120100U-P5RP-EJ     | SWI12-12-N-P5R |
| EPSA120100U-P6P-EJ      | SWI12-12-N-P6  |
| EPSA120100U-P6P-SZ-C1   | SWI12-N series |
| EPSA120100U-P6RP-SZ     | SWI12-12-N-P6R |
| EPSA120100U-P7P-EJ      | SWI12-12-N-P7  |
| EPSA120100U-P7P-EJ      | SWI12-12-N-P7  |
| EPSA120100U-P7RP-EJ     | SWI12-12-N-P7R |
| EPSA120100U-P9P-EJ      | SWI12-12-N-P9  |
| EPSA120100UPS-P93-SZ-C1 | SWI12-N series |
| EPSA120100U-SRW-EJ      | SWI12-12-N-SC  |
| EPSA120100U-ST-EJ       | SWI12-12-N-ST  |
| EPSA135074U-P14RP-DB-C1 | SWI12-N series |
| EPSA150080-P5P-SZ-C1    | SWI12-N series |
| EPSA150080-P76P-SZ-C1   | SWI12-N series |
| EPSA240050UH-P5P-SZ-C1  | SWI6-N series  |
| EPSA280035B-PXXX-SZ-C1  | none           |
| EPSA280035E-PXXX-SZ-C1  | SWI12-E series |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

EPSA280035-PXXX-SZ-C1  
EPSA480025U-P6P-SZ-C1  
EPSA050200UB-P6P-EJ-C1  
EPSA050250UB-P5P-EJ  
EPSA120100UB-P5P-EJ  
EPSA050250U-P6P-TA-C1  
EPSA090130U-P11P-EJ  
EPSA120100U-P6RP-EJ-C1  
EPSA050250UE-P6P-EJ  
EPSA050250UE-P7  
EPSA050120UB-P5RP-EJ  
EPSA050120UB-P6P-EJ  
EPSA050120UB-P6RP-EJ  
EPSA050120UE-P5RP-EJ  
EPSA050120UE-P6RP-EJ  
EPSA060200U-P6P-EJ  
EPSA060200U-P6RP-EJ  
EPSA090130U-P5RN-EJ  
EPSA090130U-P6RP-EJ  
EPSA090130U-ST-EJ  
EPSA120050UB-P5RP-EJ  
EPSA120050UB-P6P-EJ  
EPSA120050UB-P6RP-EJ  
EPSA120050UE-P5RP-EJ  
EPSA120050UE-P6P-EJ  
EPSA120050UE-P6RP-EJ  
EPSA120100UB-P5RP-EJ  
EPSA120100UB-P6P-EJ  
EPSA120100UB-P6RP-EJ  
EPSA120100UE-P5RP-EJ  
EPSA120100UE-P6P-EJ  
EPSA120100UE-P6RP-EJ  
EPSA120100U-P6RP-EJ  
EPSA120150UB-P5RP-EJ  
EPSA120150UB-P6P-EJ  
EPSA120150UB-P6RP-EJ  
EPSA120150UE-P5RP-EJ  
EPSA120150UE-P6P-EJ  
EPSA120150UE-P6RP-EJ

SWI12-N series  
SWI12-N series  
SMI18 series  
SMI18 series  
SMI18 series  
SWI12-N series  
SWI12-N series  
SWI12-N series  
SWI12-5-E-P6  
SWI12-5-E-P7  
SMI6 series  
SMI6 series  
SMI6 series  
SWI6-5-E-P5R  
SWI6-5-E-P6R  
SWI12-6-N-P6  
SWI12-6-N-P6R  
SWI12-N series  
SWI12-N series  
SWI12-N series  
SMI6 series  
SMI6 series  
SMI6 series  
SWI6-12-E-P5R  
SWI6-12-E-P6  
SWI6-12-E-P6R  
SMI18 series  
SMI18 series  
SMI18 series  
SWI12-E series  
SWI12-E series  
SWI12-E series  
SWI12-12-N-P6R  
SMI18 series  
SMI18 series  
SMI18 series  
SWI18-12-E-P5R  
SWI18-12-E-P6  
SWI18-12-E-P6R



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                           |                |
|---------------------------|----------------|
| EPSA050300N-P7P-SZ        | SWI18-5-N-P7   |
| EPSA050300U-P5P-DB-C1     | SWI18-N series |
| EPSA050300U-P7P-DB-C1     | SWI18-N series |
| EPSA060250U-P8P-SZ-C1     | SWI18-N series |
| EPSA120125UH-P103-DB-C1   | SWI18-N series |
| EPSA140107UH-P6P-EJ-C1    | SWI18-N series |
| EPSA060300EU-P5P-SZ-C1    | SWI18-N series |
| EPSA090200EUH-P97RP-DB-C1 | SWI18-N series |
| EPSA120150UE-P5P-EJ       | SWI18-12-E-P5  |
| EPSA060300U-P5P-SZ-C1     | SWI18-N series |
| EPSA090200U-P13RP-DB-C1   | SWI18-N series |
| EPSA090200U-P5P-SZ-C1     | SWI18-N series |
| EPSA120150UE-P6RP-SZ-C1   | SWI18-E series |
| EPSA120150UH-P5P-DB-C1    | SWI18-N series |
| EPSA120150UH-P5P-SZ-C1    | SWI18-N series |
| EPSA120150UH-P6RP-DB-C1   | SWI18-N series |
| EPSA120150UH-P6RP-SZ-C1   | SWI18-N series |
| EPSA120150U-P142P-EJ-C1   | SWI18-N series |
| EPSA120150U-P177-EJ-C1    | SWI18-N series |
| EPSA120150U-P5P-SZ-C2     | SWI18-N series |
| EPSA120150U-P5RP-DB-C1    | SWI18-N series |
| EPSA120150U-P5RP-DB-C2    | SWI18-N series |
| EPSA120150U-P7P-EJ-C1     | SWI18-N series |
| EPSA150120UH-P5P-SZ-C1    | SWI18-N series |
| EPSA150120U-P5P-DB-C1     | SWI18-N series |
| EPSA180100U-ST-EJ-C1      | SWI6-N series  |
| EPSA060300BU-P5P-SZ-C1    | SWI18-N series |
| EPSA120150UB-P5P-EJ       | SMI18 series   |
| EPSA120150UB-P6RP-SZ-C1   | SMI18 series   |
| EPSA120150UE-P6RP-DB-C1   | SWI18-E series |
| EPSA050400U-P5P-EJ        | SWI24-N series |
| EPSA050400U-P5P-EJ-C1     | SWI24-N series |
| EPSA120200E-P171P-SZ-C1   | SWI24-E series |
| EPSA240100UE-P5P-SZ-C1    | SWI24-E series |
| EPSA120200-P142P-DB-C1    | SWI24-N series |
| EPSA120200UH-P6P-DB-C1    | SWI24-N series |
| EPSA120200U-P11P-SZ       | SWI24-12-N-P11 |
| EPSA120200U-P13N-SZ       | SWI24-12-N-N13 |
| EPSA120200U-P14RP-SZ-C1   | SWI24-N series |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                         |                |
|-------------------------|----------------|
| EPSA120200U-P14RP-SZ-C2 | SWI24-N series |
| EPSA120200U-P171-SZ-C1  | SWI24-N series |
| EPSA120200U-P171-SZ-C2  | SWI24-N series |
| EPSA120200U-P174P-SZ-C1 | SWI24-N series |
| EPSA120200U-P177-SZ-C1  | SWI24-N series |
| EPSA120200U-P179-EJ-C1  | SWI24-N series |
| EPSA120200U-P50P-SZ-C1  | SWI24-N series |
| EPSA120200U-P5N-SZ      | SWI24-12-N-N5  |
| EPSA120200U-P5P-SZ      | SWI24-12-N-P5  |
| EPSA120200U-P5P-SZ-C1   | SWI24-N series |
| EPSA120200U-P5P-SZ-C2   | SWI24-N series |
| EPSA120200U-P5P-SZ-C3   | SWI24-N series |
| EPSA120200U-P5RP-SZ     | SWI24-12-N-P5R |
| EPSA120200U-P6P-SZ      | SWI24-12-N-P6  |
| EPSA120200U-P6P-SZ-C1   | SWI24-N series |
| EPSA120200U-P6RP-SZ     | SWI24-12-N-P6R |
| EPSA120200U-P7P-SZ      | SWI24-12-N-P7  |
| EPSA120200U-P8R-DB-C1   | SWI24-N series |
| EPSA120200U-ST-SZ       | SWI24-12-N-ST  |
| EPSA150160UH-P5P-SZ-C1  | SWI24-N series |
| EPSA150160UH-ST-SZ-C1   | SWI24-N series |
| EPSA150160U-P5N-SZ      | SWI24-15-N-N5  |
| EPSA150160U-P5P-SZ      | SWI24-15-N-P5  |
| EPSA150160U-P5RP-SZ-C1  | SWI24-N series |
| EPSA150160U-P6RP-SZ     | SWI24-15-N-P6R |
| EPSA150160U-P7P-SZ-C1   | SWI24-N series |
| EPSA150160U-P8P-EJ-C1   | SWI24-N series |
| EPSA150160U-ST-SZ-C1    | SWI24-N series |
| EPSA180130UH-P5P-EJ-C1  | SWI24-N series |
| EPSA240100UH-P5RP-SZ-C1 | SWI24-N series |
| EPSA240100U-P146-SZ-C1  | SWI24-N series |
| EPSA240100U-P5N-SZ      | SWI24-24-N-N5  |
| EPSA240100U-P5P-SZ      | SWI24-24-N-P5  |
| EPSA240100U-P5RP-SZ     | SWI24-24-N-P5R |
| EPSA240100U-P5RP-SZ     | SWI24-24-N-P5R |
| EPSA240100U-P6P-SZ      | SWI24-24-N-P6  |
| EPSA240100U-ST-SZ       | SWI24-24-N-ST  |
| EPSA120200U-P177-EJ-C1  | SWI24-N series |
| EPSA120200U-P7P-EJ-C1   | SWI24-N series |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                         |                   |
|-------------------------|-------------------|
| EPSA150160U-P8P-SZ      | SWI24-15-N-P8     |
| EPSA240100U-P201-SZ-C1  | SWI24-N series    |
| EPSA120200UE-P5P-SZ     | SWI24-E series    |
| EPSA120200U-P12P-SZ     | SWI24-12-N-P13    |
| EPSA120200U-P5P-SZ      | SWI24-12-N-P5     |
| EPSA150160UE-P5P-SZ     | SWI24-15-E-P5     |
| EPSA150160U-P10P-SZ     | SWI24-15-N-P10    |
| EPSA150160U-P5RP-SZ     | SWI24-15-N-P5R    |
| EPSA150160U-P6P-SZ      | SWI24-15-N-P6     |
| EPSA150160U-ST-SZ       | SWI24-15-N-ST     |
| EPSA240100UE-P5P-SZ     | SWI24-24-E-P5     |
| EPSA240100U-P10P-SZ     | SWI24-24-N-P10    |
| EPSA240100U-P11P-SZ     | SWI24-24-N-P11    |
| EPSA240100U-P6RN-SZ     | SWI24-24-N-N6R    |
| EPSA240100U-P6RP-SZ     | SWI24-24-N-P6R    |
| EPSA050100UE-I38-EJ     | SWI5-5-E-I38      |
| EPSA050100UB-P12P-DB    | SMI5-USB          |
| EPSA050100UH-P122-EJ-C1 | SWI5-E-USB series |
| EPSA050100U-I38-EJ      | SWI5-5-N-I38      |
| EPSA050100U-I38-EJ-C1   | SWI5-E-USB series |
| EPSA050100U-I38-EJ-C2   | SWI5-E-USB series |
| EPSA050100U-I38-EJ-C3   | SWI5-E-USB series |
| EPSA050100U-I38-EJ-C4   | SWI5-E-USB series |
| EPSA050100U-I38-EJ-C5   | SWI5-E-USB series |
| EPSA050100U-I38-EJ-C6   | SWI5-E-USB series |
| EPSA050100U-I38-EJ-C7   | SWI5-E-USB series |
| EPSA050100U-I38-SZ      | SWI5-5-N-I38      |
| EPSA050100U-I38-SZ-C5   | SWI5-E-USB series |
| EPSA050100U-P71P-DB-C1  | SWI6-N series     |
| EPSA050100U-P7P-SZ      | SWI6-5-N-P7       |
| EPSA050100UE-I38-SZ-C1  | SWI5-E-USB series |
| EPSA050100UE-I38-SZ-C2  | SWI5-E-USB series |
| EPSA050100UE-I38-SZ-C3  | SWI5-E-USB series |
| EPSA050100UE-I38-SZ-C4  | SWI5-E-USB series |
| EPSA050120UE-P12P-EJ    | SWI6-5-E-P12      |
| EPSA050120UE-P5P-EJ     | SWI6-5-E-P5       |
| EPSA050120UE-P6P-EJ     | SWI6-5-E-P6       |
| EPSA050120UE-P7P-EJ     | SWI6-5-E-P7       |
| EPSA060100UE-P126-SZ-C1 | SWI6-E series     |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
[www.cui.com](http://www.cui.com)

|                         |                |
|-------------------------|----------------|
| EPSA060100UE-P12P-EJ-C1 | SWI6-E series  |
| EPSA060100UE-P7P-SZ-C1  | SWI6-E series  |
| EPSA060100U-P10P-SZ     | SWI6-5.9-N-P10 |
| EPSA120050UE-P12P-EJ    | SWI6-12-E-P12  |
| EPSA120050UE-P5P-DB-C1  | SWI6-E series  |
| EPSA120050UE-P5P-EJ     | SWI6-12-E-P5   |
| EPSA120050UE-P5P-SZ-C1  | SWI6-E series  |
| EPSA033180U-P5P-SZ      | SWI6-N series  |
| EPSA033180U-P6P-SZ      | SWI6-N series  |
| EPSA033180U-P9P-SZ-C1   | SWI6-N series  |
| EPSA033180UW-P5P-SZ     | SWI6-N series  |
| EPSA040150UW-P5P-SZ     | SWI6-N series  |
| EPSA050120-P5P-SZ       | SWI6-5.9-N-P5  |
| EPSA050120U-I38-SZ-C1   | SWI6-N series  |
| EPSA050120U-P12P-EJ-C1  | SWI6-N series  |
| EPSA050120U-P12P-SZ     | SWI6-5-N-P12   |
| EPSA050120U-P14P-SZ     | SWI6-5-N-P14   |
| EPSA050120U-P193-SZ-C1  | SWI6-N series  |
| EPSA050120U-P46-SZ-C1   | SWI6-N series  |
| EPSA050120U-P5P-SZ      | SWI6-5-N-P5    |
| EPSA050120U-P5P-SZ-C1   | SWI6-N series  |
| EPSA050120U-P6P-SZ      | SWI6-5-N-P6    |
| EPSA050120U-P7P-SZ      | SWI6-5-N-P7    |
| EPSA050120U-P8P-SZ      | SWI6-5-N-P8    |
| EPSA050120U-ST-SZ       | SWI6-5-N-ST    |
| EPSA050120UW-P5P-SZ     | SWI6-5-N-P5    |
| EPSA060083U-I38-SZ-C1   | SWI6-N series  |
| EPSA060100UA-P126-SZ-C1 | SWI6-N series  |
| EPSA060100UA-P7P-SZ-C1  | SWI6-N series  |
| EPSA060100U-P126-SZ-C1  | SWI6-N series  |
| EPSA060100U-P13RP-C1    | SWI6-N series  |
| EPSA060100U-P5P-SZ      | SWI6-5.9-N-P5  |
| EPSA060100U-P5RN-SZ     | SWI6-5.9-N-N5R |
| EPSA060100U-P5RP-SZ     | SWI6-5.9-N-P5R |
| EPSA060100U-P6P-SZ      | SWI6-5.9-N-P6  |
| EPSA060100U-P7P-SZ      | SWI6-5.9-N-P7  |
| EPSA060100UW-P5P-SZ     | SWI6-5.9-N-P5  |
| EPSA060100UW-P5RP-SZ    | SWI6-5.9-N-P5R |
| EPSA060100UW-P6P-SZ     | SWI6-5.9-N-P6  |





20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                        |                |
|------------------------|----------------|
| EPSA060100UW-P6RP-SZ   | SWI6-5.9-N-P6R |
| EPSA060100UW-P7P-SZ    | SWI6-5.9-N-P7  |
| EPSA060100UW-P8P-SZ    | SWI6-5.9-N-P8  |
| EPSA090066U-P5P-DB-C1  | SWI6-N series  |
| EPSA090067U-P5P-SZ     | SWI6-N series  |
| EPSA090067U-P6P-SZ     | SWI6-N series  |
| EPSA090067U-S/T-SZ-C1  | SWI6-N series  |
| EPSA090067U-ST-SZ      | SWI6-N series  |
| EPSA090067UW-P5P-SZ    | SWI6-N series  |
| EPSA090067UW-P5RP-SZ   | SWI6-N series  |
| EPSA090067UW-P6P-SZ    | SWI6-N series  |
| EPSA090067UW-P6RP-SZ   | SWI6-N series  |
| EPSA120050B-P5P-SZ-C1  | SWI6-N series  |
| EPSA120050E-P5P-SZ-C1  | SWI6-E series  |
| EPSA120050U-P10P-SZ    | SWI6-12-N-P10  |
| EPSA120050U-P12P-SZ-C1 | SWI6-N series  |
| EPSA120050U-P5P-SZ     | SWI6-12-N-P5   |
| EPSA120050U-P5P-SZ     | SWI6-12-N-P5   |
| EPSA120050U-P5P-SZ-C2  | SWI6-N series  |
| EPSA120050U-P5RP-DB-C1 | SWI6-N series  |
| EPSA120050U-P5RP-SZ    | SWI6-12-N-P5R  |
| EPSA120050U-P6P-SZ     | SWI6-12-N-P6   |
| EPSA120050U-P7P-SZ-C1  | SWI6-N series  |
| EPSA120050U-ST-SZ      | SWI6-12-N-ST   |
| EPSA120050UW-P5P-SZ    | SWI6-N series  |
| EPSA120050UW-P5RP-SZ   | SWI6-N series  |
| EPSA120050UW-P6RP-SZ   | SWI6-N series  |
| EPSA150040U-P5P-SZ     | SWI6-N series  |
| EPSA150040U-P6P-SZ     | SWI6-N series  |
| EPSA150040UW-P5P-SZ    | SWI6-N series  |
| EPSA150040UW-P5RP-SZ   | SWI6-N series  |
| EPSA150040UW-P6P-SZ    | SWI6-N series  |
| EPSA150040UW-P6RP-SZ   | SWI6-N series  |
| EPSA180033U-P5P-SZ     | SWI6-N series  |
| EPSA180033U-P6P-SZ     | SWI6-N series  |
| EPSA180033UW-P5P-SZ    | SWI6-N series  |
| EPSA180033UW-P5RP-SZ   | SWI6-N series  |
| EPSA180033UW-P6P-SZ    | SWI6-N series  |
| EPSA180033UW-P6RP-SZ   | SWI6-N series  |



20050 SW 112th Ave. Tualatin, Oregon 97062  
phone: 800.275.4899 fax: 503.612.2383  
www.cui.com

|                         |                  |
|-------------------------|------------------|
| EPSA240025U-P5P-SZ      | SWI6-N series    |
| EPSA240025U-P6P-SZ      | SWI6-N series    |
| EPSA240025U-ST-SZ       | SWI6-N series    |
| EPSA240025UW-P5P-SZ     | SWI6-N series    |
| EPSA240025UW-P5RP-SZ    | SWI6-N series    |
| EPSA240025UW-P6RP-SZ    | SWI6-N series    |
| EPSA050120UB-P12P-EJ    | SMI6 series      |
| EPSA050120UB-P5P-EJ     | SMI6 series      |
| EPSA060100UB-P126-SZ-C1 | SMI6 series      |
| EPSA120050UB-P5P-EJ     | SMI6 series      |
| EPSA033180U-P7P-SZ      | SWI6-N series    |
| EPSA050120U-P193-SZ-C2  | SWI6-N series    |
| EPSA050120UW-P6P-SZ     | SWI6-5-N-P6      |
| EPSA050120UW-P7P-SZ     | SWI6-5-N-P7      |
| EPSA120050UW-P6P-SZ     | SWI6-N series    |
| EPSA150040UW-P7P-SZ     | SWI6-N series    |
| EPSA240025UW-P6P-SZ     | SWI6-N series    |
| EPSA050120UW-P5RP-SZ    | SWI6-5-N-P5R     |
| EPSA050120UW-P6RP-SZ    | SWI6-5-N-P6R     |
| ETSA120833U-P73RP-SZ-C1 | SDI120-U Series  |
| ETSA120834UC-P51-WP     | SDI120-12-UC-P51 |
| ETSA120834U-P51-WP      | SDI120-12-U-P51  |
| ETSA160625UC-P51-WP     | SDI120-16-UC-P51 |
| ETSA160625U-P51-WP      | SDI120-16-U-P51  |
| ETSA190527UC-P51-WP     | SDI120-19-UC-P51 |
| ETSA190527U-P51-WP      | SDI120-19-U-P51  |
| ETSA240417UC-P51-WP     | SDI120-24-UC-P51 |
| ETSA240417U-P51-WP      | SDI120-24-U-P51  |
| ETSA240417U-P6P-WP-C1   | SDI120-U Series  |
| ETSA360278UC-P51-WP     | SDI120-U Series  |
| ETSA360278U-P51-WP      | SDI120-U Series  |
| ETSA360278U-P5P-WP-C1   | SDI120-U Series  |
| ETSA360278U-P6P-WP-C1   | SDI120-U Series  |
| ETSA480209UC-P51-WP     | SDI120-48-UC-P51 |
| ETSA480209U-P51-WP      | SDI120-48-U-P51  |
| ETSA120834U2-P51-WP     | SDI120-12-U2-P51 |
| ETSA120834U3-P51-WP     | SDI120-12-U-P51  |
| ETSA120834U4-P51-WP     | SDI120-12-U4-P51 |
| ETSA120834U5-P51-WP     | SDI120-12-U5-P51 |