



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832


Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



Phoenard Phoenix Shield

SKU 102990206



DESCRIPTION

This Phoenard board extension can be docked using the bottom 30-pin connector, exposing most (not all!) Arduino pins. You can then connect Arduino board extensions to the device easily.

Features

Standard Arduino shield design

Functional ISP interface and digital/analog I/O

Specification

Safe operating conditions

Temperature: -10 ~ 60 degrees celcius

Humidity: 20% - 90%

Power

Main board voltage: 3v3

Accessible pins

Analog: 6 analog pins (A0 - A5)

Digital: 5 general purpose I/O; supports PWM (digital pins 4, 5, 6, 7, 9)

ISP Interface: 6-pin (MISO/MOSI/SCK/SS/RESET/GND)

Serial Interface: Serial 1 (RX0/TX0)

Power: 3v3 (main board), 5v (USB power)

Part List

1 x Phoenix Shield PCBA

Note

This board uses a 3v3 main board voltage and may not be compatible with all 5v sensors and devices. The 5v power on the extension connector is only present when USB power is provided.

A starters guide together with documentation and software examples is available on our website:

Getting started

Software documentation

Forums

Copyright © 2008-2015 Seeed Technology Co., Ltd All rights reserved