



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





WIRELESS RF MODULE MANUAL

27985

912 MHz TRANSCIVER

5

6. Apply power to the Stamp and the Transceiver. (Now your ready to start using your Transceiver to send serial bytes.)
7. Using the SEROUT instruction, you can send a serial byte to another Transceiver. (Make sure you use the baud rate of 9600, N, 8, 1) (If you are using the BS2 an example would be "SEROUT 1, 84, [your-data]").

Transceiver hook-up (RECEIVE)

1. Plug the Transceiver into a solderless breadboard, do not solder directly to the pins of the module.
2. The module itself should be positioned vertically, so it is perpendicular to the bread board and any solid ground area you might have under it (this will give you more range).

6

3. Connect all pins labeled GND to ground. (Make sure the ground is common with your Basic Stamp.)
4. Connect the +3V to +5VDC pin to a clean, regulated +3V to +5VDC (+/- 5%) power supply at 30mA. (If you are using a B.O.E. type of Parallax Board, you can connect it to the +5VDC supply on the board. Typically this will be the output of a 7805 voltage regulator.
5. Connect the RXD (Receive Data) pin to any I/O on your Basic Stamp. (Make sure this pin is configured as an INPUT.)
6. Apply power to the Stamp and the Transceiver. (Now your ready to start using your Transceiver to receive serial bytes.)
7. Using the SERIN instruction, you can receive a serial byte sent by another Transceiver. (Make sure you use the baud rate of 9600, N, 8, 1). (If you are using the BS2 an example would be "SERIN 1, 84, [variable-to-receive-data-byte]").

7

Antenna and Grounding

- Do not allow the antenna to touch any surface or conductive material.
- Unfold antenna and make sure its pointing straight. If it can not be straight due to your application having limited space it is ok to fold it, but your range will be reduced.
- Do not attempt to increase the length or change the antenna, as it will reduce performance and or damage the module.
- When ever possible, provide as much ground area under the module as possible. For example a copper clad circuit board that is one foot square, directly under the bread board the modules is mounted on, is perfect. Note it is very important to connect a thick ground strap (wire) from the module grounds to the ground area for it to be effective. • Do not allow the antennas to touch.

8

Misl.

Single direction communication requires at least:
2 Transceivers.

Bi-directional communication requires at least:
2 Transceivers.

Multi Point Communications can be achieved by:
Placing one transmitter at each node that needs to send information.

2

Contact Info:

Web: <http://www.parallax.com>
<http://www.stampsinclass.com>

Email:
stamptech@parallax.com

Sales / Technical Support:
Tel: (916) 624-8333
Fax: (916) 624-8003

Address:
599 Menlo Drive • Rocklin, CA 95765

MANUFACTURED BY
RF DIGITAL
www.rfdigital.com

(C) Copyright, 2007

Updated:
6/4/2007 4:30 PM

3

General

This manual covers one item:

- 27985 RF Transceiver Module
It receives RF and outputs your data (and)
It accepts your data and outputs RF.
This RF module is used to send remote control data back and forth between two or more Basic Stamps.

Reference the color label on the modules pin names on the back of the module.

Transceiver hook-up (TRANSMIT)

1. Plug the transmitter into a solderless breadboard, do not solder directly to the pins of the module.
2. The module itself should be positioned vertically, so it is perpendicular to the bread board and any solid ground area you might have under it (this will give you more range).

4

3. Connect all pins labeled GND to ground. (Make sure the ground is common with your Basic Stamp.) You only really need one pin connected to ground, but connecting the other ones, may give you a better ground connection for purposes of range.
4. Connect the +3V to +5VDC pin to a clean, regulated +3V to +5VDC (+/- 5%) power supply at 30mA. (If you are using a B.O.E. type of Parallax Board, you can connect it to the +5VDC supply on the board. Typically this will be the output of a 7805 voltage regulator.
5. Connect the TXD (Transmit Data) pin to any I/O on your

d

Placing one receiver at each node that needs to receive information.

Placing one transceiver at each node that needs to send and receive information.

Regulatory Warnings

These modules (boards) are NOT FCC approved. They are designed to comply with the FCC Part 15 Rules and Regulations. They are not in a finished product form. They are strictly intended for experimental purposes only. If you wish to use these modules in an actual product (a non-experimental capacity), the module must first be designed into the product, then the whole product must be approved by the FCC. For a list of FCC approved Labs

WARRANTY

Parallax Inc. warrants its products against defects in materials and workmanship for a period of 90 days from receipt of product. If you discover a defect, Parallax Inc. will, at its option, repair or replace the merchandise, or refund the purchase price. Before returning the product to Parallax, call for a Return Merchandise Authorization (RMA) number. Write the RMA number on the outside of the box used to return the merchandise to Parallax. Please enclose the following along with the returned merchandise: your name, telephone number, shipping address, and a description of the problem. Parallax will return your product or its replacement using the same shipping method used to ship the product to Parallax.

that can test your final product for compliance contact RF Digital Corporation at (818) 541-7622 or visit the web site at <http://www.rfdigital.com>.

It is the responsibility of the user to be aware of the regulatory requirements in their area of operation and application. For exact information contact the FCC Office at:

Federal Communications Commission

<http://www.fcc.gov>

USE OUTSIDE OF THE U.S.A. It is the responsibility of the user to be aware of the regulatory requirements in their area of operation and application. Contact your local regulatory agency and obtain compliance information.

DISCLAIMER OF LIABILITY

Parallax Inc. is not responsible for special, incidental, or consequential damages resulting from any breach of warranty, or under any legal theory, including lost profits, downtime, goodwill, damage to or replacement of equipment or property, or any costs of recovering, reprogramming, or reproducing any data stored in or used with Parallax products. Parallax Inc. is also not responsible for any personal damage, including that to life and health, resulting from use of any of our products. You take full responsibility for your Parallax product application, no matter how life-threatening it may be.

For O.E.M. Design-In Guidance for the modules please contact::

RF Digital Corporation
2029 Verdugo Blvd. Suite 750
Montrose, CA 91020
Tel: (818) 541-7622
Fax: (818) 541-7644
Web: www.rfdigital.com
Email: support@rfdigital.com

Operational Warnings

Do not expose the boards to direct outdoor environment. If they will be used outdoors, keep them away from water, moisture and direct sunlight.

Please go to
For more documentation please visit the
Parallax web site at:
<http://www.parallax.com>

The serial input and output pins operate at +3V to +5V and 0V logic levels. Do not attempt to connect directly to a computer RS232 port as this will damage the module. Typical levels at a

computer RS232 port are +10V and -10V; these voltages would immediately damage the module. The module is intended to interface directly with the Basic Stamp, other +3V to +5V logic devices and controllers.

In classroom environments, many transmitters and receivers may be within communication range. When not in use, disconnect power from your project, including the module, to assure there is no chance for unintentional transmission. Transmissions from other devices can disallow other students to perform their wireless experiments.