

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







Installation Procedure For Resistant Hoods

Assembly steps:

- 1. Hold connector shell in the position shown on the picture. The holes of the shell have to be placed over the screws in the hood. Attention: Do not push the shell further into the hood to avoid damaging the detent latches in the hood.
- 2. Place the assembly key between the connector shell and the hood over the detent latch. Gently pry open the hood while pushing the connector down into the slot behind the detent latch. Remove the assembly key.
- 3. Verify that the shell is positioned behind the detent latch on one side of the hood. Place the assembly key between the opposite side of the connector shell and the hood over the detent latch. Gently pry open the hood while pushing the connector down into the slot behind the detent latch.
- 4. Remove the assembly key. Verify that the shell is placed in both slots behind the detent latches.

