



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts,Customers Priority,Honest Operation,and Considerate Service",our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com


Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





---

# User's manual FLIR T6xx series







**Important note**

Before operating the device, you must read, understand, and follow all instructions, warnings, cautions, and legal disclaimers.

**Důležitá poznámka**

Před použitím zařízení si přečtěte veškeré pokyny, upozornění, varování a vyvázání se ze záruky, ujistěte se, že jim rozumíte, a řiďte se jimi.

**Viktig meddelelse**

Før du betjener enheden, skal du læse, forstå og følge alle anvisninger, advarsler, sikkerhedsforanstaltninger og ansvarsfraskrivelser.

**Wichtiger Hinweis**

Bevor Sie das Gerät in Betrieb nehmen, lesen, verstehen und befolgen Sie unbedingt alle Anweisungen, Warnungen, Vorsichtshinweise und Haftungsausschlüsse

**Σημαντική σημείωση**

Πριν από τη λειτουργία της συσκευής, πρέπει να διαβάσετε, να κατανοήσετε και να ακολουθήσετε όλες τις οδηγίες, προειδοποιήσεις, προφυλάξεις και νομικές αποποιήσεις.

**Nota importante**

Antes de usar el dispositivo, debe leer, comprender y seguir toda la información sobre instrucciones, advertencias, precauciones y renunciaciones de responsabilidad.

**Tärkeä huomautus**

Ennen laitteen käyttämistä on luettava ja ymmärrettävä kaikki ohjeet, vakavat varoitukset, varoitukset ja lakitiedotteet sekä noudatettava niitä.

**Remarque importante**

Avant d'utiliser l'appareil, vous devez lire, comprendre et suivre l'ensemble des instructions, avertissements, mises en garde et clauses légales de non-responsabilité.

**Fontos megjegyzés**

Az eszköz használatá elött figyelmesen olvassa el és tartsa be az összes utasítást, figyelmeztetést, óvintézkedést és jogi nyilatkozatot.

**Nota importante**

Prima di utilizzare il dispositivo, è importante leggere, capire e seguire tutte le istruzioni, avvertenze, precauzioni ed esclusioni di responsabilità legali.

**重要な注意**

デバイスをご使用になる前に、あらゆる指示、警告、注意事項、および免責条項をお読み頂き、その内容を理解して従ってください。

**중요한 참고 사항**

장치를 작동하기 전에 반드시 다음의 사용 설명서와 경고, 주의사항, 법적 책임제한을 읽고 이해하며 따라야 합니다.

**Viktig**

Før du bruker enheten, må du lese, forstå og følge instruksjoner, advarsler og informasjon om ansvarsfraskrivelse.

**Belangrijke opmerking**

Zorg ervoor dat u, voordat u het apparaat gaat gebruiken, alle instructies, waarschuwingen en juridische informatie hebt doorgelezen en begrepen, en dat u deze opvolgt en in acht neemt.

**Ważna uwaga**

Przed rozpoczęciem korzystania z urządzenia należy koniecznie zapoznać się z wszystkimi instrukcjami, ostrzeżeniami, przestrogami i uwagami prawnymi. Należy zawsze postępować zgodnie z zaleceniami tam zawartymi.

**Nota importante**

Antes de utilizar o dispositivo, deverá proceder à leitura e compreensão de todos os avisos, precauções, instruções e isenções de responsabilidade legal e assegurar-se do seu cumprimento.

**Важное примечание**

До того, как пользоваться устройством, вам необходимо прочитать и понять все предупреждения, предостережения и юридические ограничения ответственности и следовать им.

**Viktig information**

Innan du använder enheten måste du läsa, förstå och följa alla anvisningar, varningar, försiktighetsåtgärder och ansvarsfriskrivningar.

**Önemli not**

Cihazı çalıştırmadan önce tüm talimatları, uyarıları, ikazları ve yasal açıklamaları okumalı, anlamalı ve bunlara uymalısınız.

**重要注意事項**

在操作设备之前，您必须阅读、理解并遵循所有说明、警告、注意事项和法律免责声明。

**重要注意事項**

操作裝置之前，您務必閱讀、了解並遵循所有說明、警告、注意事項與法律免責聲明。



---

# User's manual FLIR T6xx series





# Table of contents

---

<b>1</b>	<b>Disclaimers</b>	<b>1</b>
1.1	Legal disclaimer	1
1.2	Usage statistics	1
1.3	Changes to registry	1
1.4	U.S. Government Regulations	1
1.5	Copyright	1
1.6	Quality assurance	1
1.7	Patents	1
1.8	EULA Terms	1
1.9	EULA Terms	2
<b>2</b>	<b>Safety information</b>	<b>3</b>
<b>3</b>	<b>Notice to user</b>	<b>7</b>
3.1	User-to-user forums	7
3.2	Calibration	7
3.3	Accuracy	7
3.4	Disposal of electronic waste	7
3.5	Training	7
3.6	Documentation updates	8
3.7	Important note about this manual	8
3.8	Note about authoritative versions	8
<b>4</b>	<b>Customer help</b>	<b>9</b>
4.1	General	9
4.2	Submitting a question	9
4.3	Downloads	10
<b>5</b>	<b>Quick start guide</b>	<b>11</b>
5.1	Procedure	11
<b>6</b>	<b>List of accessories and services</b>	<b>12</b>
<b>7</b>	<b>A note about ergonomics</b>	<b>14</b>
7.1	General	14
7.2	Figure	14
<b>8</b>	<b>Camera parts</b>	<b>15</b>
8.1	View from the right	15
8.1.1	Figure	15
8.1.2	Explanation	15
8.2	View from the left	16
8.2.1	Figure	16
8.2.2	Explanation	16
8.3	View from the rear	17
8.3.1	Figure	17
8.3.2	Explanation	17
8.4	View from the bottom	18
8.4.1	Figure	18
8.4.2	Explanation	18
8.5	Battery condition LED indicator	19
8.5.1	Figure	19
8.5.2	Explanation	19
8.6	Power LED indicator	19
8.6.1	Figure	19
8.6.2	Explanation	19



## Table of contents

---

8.7	Laser pointer .....	20
8.7.1	Figure .....	20
8.7.2	Laser warning label .....	20
8.7.3	Laser rules and regulations .....	20
<b>9</b>	<b>Screen elements .....</b>	<b>21</b>
9.1	Figure .....	21
9.2	Explanation .....	21
<b>10</b>	<b>Navigating the menu system .....</b>	<b>22</b>
10.1	Figure .....	22
10.2	Explanation .....	22
<b>11</b>	<b>Pairing Bluetooth devices .....</b>	<b>23</b>
11.1	General .....	23
11.2	Procedure .....	23
<b>12</b>	<b>Configuring Wi-Fi .....</b>	<b>24</b>
12.1	General .....	24
12.2	Setting up a peer-to-peer connection (most common use) .....	24
12.3	Connecting the camera to a wireless local area network (less common use) .....	24
<b>13</b>	<b>Handling the camera .....</b>	<b>26</b>
13.1	Charging the battery .....	26
13.1.1	Using the power supply to charge the battery .....	26
13.1.2	Using the stand-alone battery charger to charge the battery .....	26
13.2	Turning on the camera .....	26
13.2.1	Procedure .....	26
13.3	Turning off the camera .....	26
13.3.1	Procedure .....	26
13.4	Adjusting the viewfinder's dioptic correction .....	27
13.4.1	Figure .....	27
13.4.2	Procedure .....	27
13.5	Adjusting the angle of the lens .....	28
13.5.1	Figure .....	28
13.6	Adjusting the infrared camera focus manually .....	28
13.6.1	Figure .....	28
13.6.2	Procedure .....	28
13.7	Autofocusing the infrared camera .....	29
13.7.1	Figure .....	29
13.7.2	Procedure .....	29
13.8	Continuous autofocus .....	29
13.8.1	General .....	29
13.8.2	Procedure .....	30
13.9	Operating the laser pointer .....	30
13.9.1	Figure .....	30
13.9.2	Procedure .....	30
13.10	Using the digital zoom function .....	31
13.10.1	Figure .....	31
13.10.2	Procedure .....	31
13.11	Changing lenses .....	31
13.12	Calibrating the compass .....	33
13.12.1	Procedure .....	33

## Table of contents

---

13.13	Changing the viewfinder eyecup .....	34
13.14	Using the camera lamp as a flash .....	36
13.14.1	General .....	36
13.14.2	Procedure .....	36
<b>14</b>	<b>Working with images.....</b>	<b>37</b>
14.1	Saving an image .....	37
14.1.1	General.....	37
14.1.2	About UltraMax.....	37
14.1.3	Image capacity .....	37
14.1.4	Naming convention.....	37
14.1.5	Procedure .....	37
14.2	Previewing an image .....	38
14.2.1	General.....	38
14.2.2	Procedure .....	38
14.3	Opening a saved image.....	38
14.3.1	General.....	38
14.3.2	Procedure .....	38
14.4	Editing a saved image.....	38
14.4.1	General.....	38
14.4.2	Procedure .....	39
14.5	Adjusting an infrared image.....	39
14.5.1	General.....	39
14.5.2	Example 1 .....	39
14.5.3	Example 2 .....	40
14.5.4	Procedure .....	40
14.6	Performing a non-uniformity correction (NUC) .....	41
14.6.1	What is a non-uniformity correction?.....	41
14.6.2	When to perform a non-uniformity correction? .....	41
14.6.3	Procedure .....	41
14.7	Changing the temperature range .....	41
14.7.1	General.....	41
14.7.2	Procedure .....	41
14.8	Hiding overlay graphics (programmable button).....	41
14.8.1	General.....	41
14.8.2	Procedure .....	42
14.9	Changing the color palette .....	42
14.9.1	General.....	42
14.9.2	Procedure .....	42
14.10	Deleting an image .....	42
14.10.1	General.....	42
14.10.2	Procedure .....	42
14.11	Deleting all images.....	43
14.11.1	General.....	43
14.11.2	Procedure .....	43
14.12	Creating a PDF report in the camera .....	43
14.12.1	General.....	43
14.12.2	Naming convention.....	43
14.12.3	Procedure .....	43
<b>15</b>	<b>Working with image modes.....</b>	<b>44</b>
15.1	General .....	44

## Table of contents

---

15.2	Image examples .....	44
15.3	Selecting the image mode .....	45
<b>16</b>	<b>Working with measurement tools .....</b>	<b>46</b>
16.1	General .....	46
16.2	Adding/removing measurement tools .....	46
16.3	Working with user presets .....	46
	16.3.1 General.....	46
	16.3.2 Procedure .....	46
16.4	Resizing or moving a measurement tool.....	47
	16.4.1 General.....	47
	16.4.2 Procedure .....	47
16.5	Changing object parameters .....	48
	16.5.1 General.....	48
	16.5.2 Types of parameters .....	48
	16.5.3 Recommended values.....	48
	16.5.4 Procedure .....	49
	16.5.5 Related topics .....	50
16.6	Displaying values in the result table and displaying a graph .....	50
	16.6.1 General.....	50
	16.6.2 Procedure .....	50
16.7	Creating and setting up a difference calculation .....	51
	16.7.1 General.....	51
	16.7.2 Procedure .....	51
16.8	Setting a measurement alarm .....	51
	16.8.1 General.....	51
	16.8.2 Types of alarm .....	52
	16.8.3 Alarm signals .....	52
	16.8.4 Procedure .....	52
<b>17</b>	<b>Fetching data from external FLIR meters .....</b>	<b>54</b>
17.1	General .....	54
17.2	Supported FLIR meters .....	54
17.3	Technical support for external meters .....	54
17.4	Typical moisture measurement and documentation procedure .....	54
	17.4.1 General.....	54
	17.4.2 Procedure .....	55
17.5	More information .....	55
<b>18</b>	<b>Working with color alarms and isotherms.....</b>	<b>56</b>
18.1	Color alarms .....	56
	18.1.1 General.....	56
	18.1.2 Image examples .....	56
18.2	Setting up above, below, and interval alarms.....	57
18.3	Building isotherms .....	58
	18.3.1 About the <i>Condensation alarm</i> .....	58
	18.3.2 About the <i>Insulation alarm</i> .....	58
	18.3.3 Setting up condensation and insulation alarms .....	58
<b>19</b>	<b>Annotating images .....</b>	<b>59</b>
19.1	General .....	59
19.2	Adding a note .....	59
	19.2.1 General.....	59
	19.2.2 Procedure .....	59

## Table of contents

---

19.3	Adding a table.....	60
19.3.1	General.....	60
19.3.2	Procedure .....	60
19.4	Adding a voice annotation.....	60
19.4.1	General.....	60
19.4.2	Procedure .....	60
19.5	Adding a sketch.....	61
19.5.1	General.....	61
19.5.2	Procedure .....	61
<b>20</b>	<b>Programming the camera (time lapse) .....</b>	<b>62</b>
20.1	General .....	62
20.2	Procedure .....	62
<b>21</b>	<b>Recording video clips .....</b>	<b>63</b>
21.1	General .....	63
21.2	Procedure .....	63
<b>22</b>	<b>Screening alarm .....</b>	<b>64</b>
22.1	General .....	64
22.2	Procedure .....	64
<b>23</b>	<b>Changing settings .....</b>	<b>65</b>
23.1	General .....	65
23.1.1	<i>Define user presets</i> .....	65
23.1.2	<i>Save options</i> .....	65
23.1.3	<i>Programmable button</i> .....	65
23.1.4	<i>Reset options</i> .....	65
23.1.5	<i>Device settings</i> .....	65
23.2	Procedure .....	66
<b>24</b>	<b>Technical data.....</b>	<b>67</b>
24.1	Online field-of-view calculator .....	68
24.2	Note about technical data .....	68
24.3	Note about authoritative versions.....	68
24.4	FLIR T600 15° (incl. Wi-Fi and Ext. cal.).....	69
24.5	FLIR T600 15° (incl. Wi-Fi).....	75
24.6	FLIR T600 25° (incl. Wi-Fi and Ext. cal.).....	81
24.7	FLIR T600 25° (incl. Wi-Fi).....	87
24.8	FLIR T600 25° and 15° w/case.....	93
24.9	FLIR T600 25° and 45° w/case.....	99
24.10	FLIR T600 45° (incl. Wi-Fi and Ext. cal.).....	105
24.11	FLIR T600 45° (incl. Wi-Fi).....	111
24.12	FLIR T600bx 25° (incl. Wi-Fi and Ext. cal.).....	117
24.13	FLIR T600bx 25° (incl. Wi-Fi).....	123
24.14	FLIR T600bx 45° (incl. Wi-Fi and Ext. cal.).....	129
24.15	FLIR T600bx 45° (incl. Wi-Fi).....	135
24.16	FLIR T610 15° (incl. Wi-Fi).....	141
24.17	FLIR T610 25° (incl. Wi-Fi).....	147
24.18	FLIR T610 45° (incl. Wi-Fi).....	153
24.19	FLIR T620 15° (incl. Wi-Fi and Ext. cal.).....	159
24.20	FLIR T620 15° (incl. Wi-Fi).....	165
24.21	FLIR T620 25° (incl. Wi-Fi and Ext. cal.).....	171
24.22	FLIR T620 25° (incl. Wi-Fi).....	177
24.23	FLIR T620 25° and 15° (incl. Wi-Fi).....	183

## Table of contents

---

24.24	FLIR T620 25° and 45° (incl. Wi-Fi) .....	189
24.25	FLIR T620 45° (incl. Wi-Fi and Ext. cal.) .....	195
24.26	FLIR T620 45° (incl. Wi-Fi) .....	201
24.27	FLIR T620bx 15° (incl. Wi-Fi and Ext. cal.) .....	207
24.28	FLIR T620bx 15° (incl. Wi-Fi) .....	213
24.29	FLIR T620bx 25° (incl. Wi-Fi and Ext. cal.) .....	219
24.30	FLIR T620bx 25° (incl. Wi-Fi) .....	225
24.31	FLIR T620bx 45° (incl. Wi-Fi and Ext. cal.) .....	231
24.32	FLIR T620bx 45° (incl. Wi-Fi) .....	237
24.33	FLIR T630 15° (incl. Wi-Fi) .....	243
24.34	FLIR T630 25° (incl. Wi-Fi) .....	249
24.35	FLIR T630 45° (incl. Wi-Fi) .....	255
24.36	FLIR T630sc 15° (incl. Wi-Fi) .....	261
24.37	FLIR T630sc 25° (incl. Wi-Fi) .....	267
24.38	FLIR T630sc 25° and 45° w/case .....	273
24.39	FLIR T630sc 45° (incl. Wi-Fi) .....	279
24.40	FLIR T640 15° (incl. Wi-Fi and Ext. cal.) .....	285
24.41	FLIR T640 15° (incl. Wi-Fi) .....	292
24.42	FLIR T640 25° (incl. Wi-Fi and Ext. cal.) .....	298
24.43	FLIR T640 25° (incl. Wi-Fi) .....	305
24.44	FLIR T640 25° and 15° (incl. Wi-Fi) .....	311
24.45	FLIR T640 25° and 45° (incl. Wi-Fi) .....	318
24.46	FLIR T640 45° (incl. Wi-Fi and Ext. cal.) .....	325
24.47	FLIR T640 45° (incl. Wi-Fi) .....	332
24.48	FLIR T640bx 15° (incl. Wi-Fi and Ext. cal.) .....	338
24.49	FLIR T640bx 15° (incl. Wi-Fi) .....	345
24.50	FLIR T640bx 25° (incl. Wi-Fi and Ext. cal.) .....	352
24.51	FLIR T640bx 25° (incl. Wi-Fi) .....	359
24.52	FLIR T640bx 45° (incl. Wi-Fi and Ext. cal.) .....	366
24.53	FLIR T640bx 45° (incl. Wi-Fi) .....	373
24.54	FLIR T650sc 15° (incl. Wi-Fi) .....	380
24.55	FLIR T650sc 25° (incl. Wi-Fi) .....	387
24.56	FLIR T650sc 25° and 15° w/case .....	394
24.57	FLIR T650sc 25° and 45° w/case .....	401
24.58	FLIR T650sc 45° (incl. Wi-Fi) .....	408
24.59	FLIR T660 15° (incl. Wi-Fi and Ext. cal.) .....	415
24.60	FLIR T660 15° (incl. Wi-Fi) .....	422
24.61	FLIR T660 25° (incl. Wi-Fi and Ext. cal.) .....	429
24.62	FLIR T660 25° (incl. Wi-Fi) .....	436
24.63	FLIR T660 25° and 15° w/case .....	443
24.64	FLIR T660 25° and 45° w/case .....	450
24.65	FLIR T660 45° (incl. Wi-Fi and Ext. cal.) .....	457
24.66	FLIR T660 45° (incl. Wi-Fi) .....	464
<b>25</b>	<b>Mechanical drawings .....</b>	<b>471</b>
<b>26</b>	<b>CE Declaration of conformity .....</b>	<b>481</b>
<b>27</b>	<b>Cleaning the camera .....</b>	<b>483</b>
27.1	Camera housing, cables, and other items .....	483
27.1.1	Liquids .....	483
27.1.2	Equipment .....	483
27.1.3	Procedure .....	483

## Table of contents

---

27.2	Infrared lens .....	483
27.2.1	Liquids.....	483
27.2.2	Equipment.....	483
27.2.3	Procedure .....	483
27.3	Infrared detector .....	484
27.3.1	General.....	484
27.3.2	Procedure .....	484
<b>28</b>	<b>Application examples.....</b>	<b>485</b>
28.1	Moisture & water damage .....	485
28.1.1	General.....	485
28.1.2	Figure.....	485
28.2	Faulty contact in socket .....	485
28.2.1	General.....	485
28.2.2	Figure.....	486
28.3	Oxidized socket.....	486
28.3.1	General.....	486
28.3.2	Figure.....	486
28.4	Insulation deficiencies.....	487
28.4.1	General.....	487
28.4.2	Figure.....	487
28.5	Draft .....	488
28.5.1	General.....	488
28.5.2	Figure.....	488
<b>29</b>	<b>About FLIR Systems .....</b>	<b>490</b>
29.1	More than just an infrared camera .....	491
29.2	Sharing our knowledge .....	492
29.3	Supporting our customers.....	492
<b>30</b>	<b>Terms, laws, and definitions.....</b>	<b>493</b>
<b>31</b>	<b>Thermographic measurement techniques .....</b>	<b>495</b>
31.1	Introduction .....	495
31.2	Emissivity.....	495
31.2.1	Finding the emissivity of a sample .....	495
31.3	Reflected apparent temperature .....	499
31.4	Distance .....	499
31.5	Relative humidity .....	499
31.6	Other parameters.....	499
<b>32</b>	<b>History of infrared technology.....</b>	<b>500</b>
<b>33</b>	<b>Theory of thermography.....</b>	<b>503</b>
33.1	Introduction .....	503
33.2	The electromagnetic spectrum.....	503
33.3	Blackbody radiation.....	504
33.3.1	Planck's law .....	505
33.3.2	Wien's displacement law.....	506
33.3.3	Stefan-Boltzmann's law .....	507
33.3.4	Non-blackbody emitters.....	508
33.4	Infrared semi-transparent materials.....	510
<b>34</b>	<b>The measurement formula.....</b>	<b>511</b>
<b>35</b>	<b>Emissivity tables .....</b>	<b>515</b>
35.1	References.....	515

**Table of contents**

---

35.2	Tables .....	515
------	--------------	-----

## 1.1 Legal disclaimer

All products manufactured by FLIR Systems are warranted against defective materials and workmanship for a period of one (1) year from the delivery date of the original purchase, provided such products have been under normal storage, use and service, and in accordance with FLIR Systems instruction.

Uncooled handheld infrared cameras manufactured by FLIR Systems are warranted against defective materials and workmanship for a period of two (2) years from the delivery date of the original purchase, provided such products have been under normal storage, use and service, and in accordance with FLIR Systems instruction, and provided that the camera has been registered within 60 days of original purchase.

Detectors for uncooled handheld infrared cameras manufactured by FLIR Systems are warranted against defective materials and workmanship for a period of ten (10) years from the delivery date of the original purchase, provided such products have been under normal storage, use and service, and in accordance with FLIR Systems instruction, and provided that the camera has been registered within 60 days of original purchase.

Products which are not manufactured by FLIR Systems but included in systems delivered by FLIR Systems to the original purchaser, carry the warranty, if any, of the particular supplier only. FLIR Systems has no responsibility whatsoever for such products.

The warranty extends only to the original purchaser and is not transferable. It is not applicable to any product which has been subjected to misuse, neglect, accident or abnormal conditions of operation. Expendable parts are excluded from the warranty.

In the case of a defect in a product covered by this warranty the product must not be further used in order to prevent additional damage. The purchaser shall promptly report any defect to FLIR Systems or this warranty will not apply.

FLIR Systems will, at its option, repair or replace any such defective product free of charge if, upon inspection, it proves to be defective in material or workmanship and provided that it is returned to FLIR Systems within the said one-year period.

FLIR Systems has no other obligation or liability for defects than those set forth above.

No other warranty is expressed or implied. FLIR Systems specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.

FLIR Systems shall not be liable for any direct, indirect, special, incidental or consequential loss or damage, whether based on contract, tort or any other legal theory.

This warranty shall be governed by Swedish law.

Any dispute, controversy or claim arising out of or in connection with this warranty, shall be finally settled by arbitration in accordance with the Rules of the Arbitration Institute of the Stockholm Chamber of Commerce. The place of arbitration shall be Stockholm. The language to be used in the arbitral proceedings shall be English.

## 1.2 Usage statistics

FLIR Systems reserves the right to gather anonymous usage statistics to help maintain and improve the quality of our software and services.

## 1.3 Changes to registry

The registry entry "HKEY\_LOCAL\_MACHINE\SYSTEM\CurrentControlSet\Control\Lsa\LmCompatibilityLevel will be automatically changed to level 2 if the FLIR Camera Monitor service detects a FLIR camera connected to the computer with a USB cable. The modification will only be executed if the camera device implements a remote network service that supports network logons.

## 1.4 U.S. Government Regulations

This product may be subject to U.S. Export Regulations. Please send any inquiries to [exportquestions@flir.com](mailto:exportquestions@flir.com).

## 1.5 Copyright

© 2016, FLIR Systems, Inc. All rights reserved worldwide. No parts of the software including source code may be reproduced, transmitted, transcribed or translated into any language or computer language in any form or by any means, electronic, magnetic, optical, manual or otherwise, without the prior written permission of FLIR Systems.

The documentation must not, in whole or part, be copied, photocopied, reproduced, translated or transmitted to any electronic medium or machine readable form without prior consent, in writing, from FLIR Systems.

Names and marks appearing on the products herein are either registered trademarks or trademarks of FLIR Systems and/or its subsidiaries. All other trademarks, trade names or company names referenced herein are used for identification only and are the property of their respective owners.

## 1.6 Quality assurance

The Quality Management System under which these products are developed and manufactured has been certified in accordance with the ISO 9001 standard.

FLIR Systems is committed to a policy of continuous development; therefore we reserve the right to make changes and improvements on any of the products without prior notice.

## 1.7 Patents

000439161; 000653423; 000726344; 000859020; 001707738; 001707746; 001707787; 001776519; 001954074; 002021543; 002021543-0002; 002056180; 002249953; 002531178; 002816785; 002816793; 011200326; 014347553; 057692; 061608; 07002405; 100414275; 101796816; 101796817; 101796818; 102334141; 1062100; 11063060001; 11517895; 1226865; 12300216; 12300224; 1285345; 1299699; 1325808; 1336775; 1391114; 1402918; 1404291; 1411581; 1415075; 1421497; 1458284; 1678485; 1732314; 17399650; 1880950; 1886650; 2007301511414; 20073033395047; 2008301285812; 2009301900619; 20100603057; 2010301761271; 2010301761303; 2010301761572; 2010305959313; 2011304423549; 2012304717443; 2012306207318; 2013302676195; 2015202354035; 2015304259171; 204465713; 204967995; 2106017; 2107799; 2115696; 2172004; 2315433; 2381417; 2794760001; 3006596; 3006597; 303302011; 4358936; 483782; 484155; 4889913; 4937897; 4995790001; 5177595; 540838; 579475; 584755; 599392; 60122153; 6020040116815; 602006006500.0; 6020080347796; 6020110003453; 615113; 615116; 664580; 664581; 665004; 665440; 67023029; 6707044; 677298; 68657; 69036179; 70022216; 70028915; 70028923; 70057990; 7034300; 710424; 7110035; 7154093; 7157705; 7188011; 7238005; 7237946; 7312822; 7332716; 7336823; 734803; 7544944; 7606484; 7634157; 7667198; 7809258; 7826738; 8018649; 8153971; 8212210; 8289372; 8340414; 8354639; 8384783; 8520970; 8565547; 8595889; 8598262; 8654239; 8680468; 8803093; 8823803; 8853631; 8933403; 9171361; 9191583; 9279728; 9280812; 9338352; 9423940; 9471970; 9595087; D549758.

## 1.8 EULA Terms

- You have acquired a device ("INFRARED CAMERA") that includes software licensed by FLIR Systems AB from Microsoft Licensing, GP or its affiliates ("MS"). Those installed software products of MS origin, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. The SOFTWARE is licensed, not sold. All rights reserved.
- IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE DEVICE OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT FLIR Systems AB FOR INSTRUCTIONS ON RETURN OF THE UNUSED DEVICE(S) FOR A REFUND. **ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE DEVICE, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).**
- **GRANT OF SOFTWARE LICENSE.** This EULA grants you the following license:
  - You may use the SOFTWARE only on the DEVICE.
  - **NOT FAULT TOLERANT.** THE SOFTWARE IS NOT FAULT TOLERANT. FLIR Systems AB HAS INDEPENDENTLY DETERMINED HOW TO USE THE SOFTWARE IN THE DEVICE, AND MS HAS RELIED UPON FLIR Systems AB TO CONDUCT SUFFICIENT TESTING TO DETERMINE THAT THE SOFTWARE IS SUITABLE FOR SUCH USE.
  - **NO WARRANTIES FOR THE SOFTWARE.** THE SOFTWARE IS PROVIDED "AS IS" and with all faults. THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY, AND EFFORT (INCLUDING LACK OF NEGLIGENCE) IS WITH YOU. ALSO, THERE IS NO WARRANTY AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE OR AGAINST INFRINGEMENT. **IF YOU HAVE RECEIVED ANY WARRANTIES REGARDING THE DEVICE OR THE SOFTWARE, THOSE WARRANTIES DO NOT ORIGINATE FROM, AND ARE NOT BINDING ON, MS.**
  - No Liability for Certain Damages. **EXCEPT AS PROHIBITED BY LAW, MS SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL MS BE LIABLE FOR ANY AMOUNT IN EXCESS OF U.S. TWO HUNDRED FIFTY DOLLARS (U.S.\$250.00).**
  - **Limitations on Reverse Engineering, Decompilation, and Disassembly.** You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.
  - **SOFTWARE TRANSFER ALLOWED BUT WITH RESTRICTIONS.** You may permanently transfer rights under this EULA only as part of a permanent sale or transfer of the Device, and only if the recipient agrees to this EULA. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE.
  - **EXPORT RESTRICTIONS.** You acknowledge that SOFTWARE is subject to U.S. export jurisdiction. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments. For additional information see <http://www.micro-soft.com/exporting/>.



---

### 1.9 EULA Terms

Qt4 Core and Qt4 GUI, Copyright ©2013 Nokia Corporation and FLIR Systems AB. This Qt library is a free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version. This library is distributed in the hope that it will be useful,

but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License, <http://www.gnu.org/licenses/lgpl-2.1.html>. The source code for the libraries Qt4 Core and Qt4 GUI may be requested from FLIR Systems AB.


**WARNING**

**Applicability:** Class B digital devices.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


**WARNING**

**Applicability:** Digital devices subject to 15.19/RSS-247.

**NOTICE:** This device complies with Part 15 of the FCC Rules and with RSS-247 of Industry Canada. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.


**WARNING**

**Applicability:** Digital devices subject to 15.21.

**NOTICE:** Changes or modifications made to this equipment not expressly approved by FLIR Systems may void the FCC authorization to operate this equipment.


**WARNING**

**Applicability:** Devices subject to RSS-102/47CFR2.1093.

This device has been tested and meets the FCC/ISED RF exposure guidelines, or the device is exempted from SAR because of the low output power. Nevertheless, the device should be used in such a manner that the potential for human contact during normal operation is minimized.


**WARNING**

**Applicability:** Cameras with one or more laser pointers.

Do not look directly into the laser beam. The laser beam can cause eye irritation.


**WARNING**

**Applicability:** Cameras with one or more batteries.

Do not disassemble or do a modification to the battery. The battery contains safety and protection devices which, if damage occurs, can cause the battery to become hot, or cause an explosion or an ignition.


**WARNING**

**Applicability:** Cameras with one or more batteries.

If there is a leak from the battery and you get the fluid in your eyes, do not rub your eyes. Flush well with water and immediately get medical care. The battery fluid can cause injury to your eyes if you do not do this.

**WARNING**

**Applicability:** Cameras with one or more batteries.

Do not continue to charge the battery if it does not become charged in the specified charging time. If you continue to charge the battery, it can become hot and cause an explosion or ignition. Injury to persons can occur.

**WARNING**

**Applicability:** Cameras with one or more batteries.

Only use the correct equipment to remove the electrical power from the battery. If you do not use the correct equipment, you can decrease the performance or the life cycle of the battery. If you do not use the correct equipment, an incorrect flow of current to the battery can occur. This can cause the battery to become hot, or cause an explosion. Injury to persons can occur.

**WARNING**

Make sure that you read all applicable MSDS (Material Safety Data Sheets) and warning labels on containers before you use a liquid. The liquids can be dangerous. Injury to persons can occur.

**CAUTION**

Do not point the infrared camera (with or without the lens cover) at strong energy sources, for example, devices that cause laser radiation, or the sun. This can have an unwanted effect on the accuracy of the camera. It can also cause damage to the detector in the camera.

**CAUTION**

Do not use the camera in temperatures more than +50°C (+122°F), unless other information is specified in the user documentation or technical data. High temperatures can cause damage to the camera.

**CAUTION**

**Applicability:** Cameras with one or more laser pointers.

To prevent damage, put the protective cap on the laser pointer when you do not operate the laser pointer. Damage to the laser pointer can occur if you do not do this.

**CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not attach the batteries directly to a car's cigarette lighter socket, unless FLIR Systems supplies a specific adapter to connect the batteries to a cigarette lighter socket. Damage to the batteries can occur.

**CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not connect the positive terminal and the negative terminal of the battery to each other with a metal object (such as wire). Damage to the batteries can occur.

**CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not get water or salt water on the battery, or permit the battery to become wet. Damage to the batteries can occur.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not make holes in the battery with objects. Damage to the battery can occur.

 **CAUTION**


**Applicability:** Cameras with one or more batteries.

Do not hit the battery with a hammer. Damage to the battery can occur.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not put your foot on the battery, hit it or cause shocks to it. Damage to the battery can occur.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not put the batteries in or near a fire, or into direct sunlight. When the battery becomes hot, the built-in safety equipment becomes energized and can stop the battery charging procedure. If the battery becomes hot, damage can occur to the safety equipment and this can cause more heat, damage or ignition of the battery.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not put the battery on a fire or increase the temperature of the battery with heat. Damage to the battery and injury to persons can occur.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not put the battery on or near fires, stoves, or other high-temperature locations. Damage to the battery and injury to persons can occur.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not solder directly onto the battery. Damage to the battery can occur.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Do not use the battery if, when you use, charge, or put the battery in storage, there is an unusual smell from the battery, the battery feels hot, changes color, changes shape, or is in an unusual condition. Speak with your sales office if one or more of these problems occurs. Damage to the battery and injury to persons can occur.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Only use a specified battery charger when you charge the battery. Damage to the battery can occur if you do not do this.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Only use a specified battery for the camera. Damage to the camera and the battery can occur if you do not do this.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

The temperature range through which you can charge the battery is 0°C to +45°C (+32°F to +113°F). If you charge the battery at temperatures out of this range, it can cause the battery to become hot or to break. It can also decrease the performance or the life cycle of the battery.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

The temperature range through which you can remove the electrical power from the battery is -15°C to +50°C (+5°F to +122°F), unless other information is specified in the user documentation or technical data. If you operate the battery out of this temperature range, it can decrease the performance or the life cycle of the battery.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

When the battery is worn, apply insulation to the terminals with adhesive tape or equivalent materials before you discard it. Damage to the battery and injury to persons can occur if you do not do this.

 **CAUTION**

**Applicability:** Cameras with one or more batteries.

Remove any water or moisture on the battery before you install it. Damage to the battery can occur if you do not do this.

 **CAUTION**

Do not apply solvents or equivalent liquids to the camera, the cables, or other items. Damage to the battery and injury to persons can occur.

 **CAUTION**

Be careful when you clean the infrared lens. The lens has an anti-reflective coating which is easily damaged. Damage to the infrared lens can occur.

 **CAUTION**

Do not use too much force to clean the infrared lens. This can cause damage to the anti-reflective coating.

**Note** The encapsulation rating is only applicable when all the openings on the camera are sealed with their correct covers, hatches, or caps. This includes the compartments for data storage, batteries, and connectors.

 **CAUTION**

**Applicability:** Cameras with a viewfinder.

Make sure that the beams from the intensive energy sources do not go into the viewfinder. The beams can cause damage to the camera. This includes the devices that emit laser radiation, or the sun.

## 3.1 User-to-user forums

Exchange ideas, problems, and infrared solutions with fellow thermographers around the world in our user-to-user forums. To go to the forums, visit:

<http://forum.infraredtraining.com/>

## 3.2 Calibration

We recommend that you send in the camera for calibration once a year. Contact your local sales office for instructions on where to send the camera.

## 3.3 Accuracy

For very accurate results, we recommend that you wait 5 minutes after you have started the camera before measuring a temperature.

## 3.4 Disposal of electronic waste

Electrical and electronic equipment (EEE) contains materials, components and substances that may be hazardous and present a risk to human health and the environment when waste electrical and electronic equipment (WEEE) is not handled correctly.

Equipment marked with the below crossed-out wheeled bin is electrical and electronic equipment. The crossed-out wheeled bin symbol indicates that waste electrical and electronic equipment should not be discarded together with unseparated household waste, but must be collected separately.

For this purpose all local authorities have established collection schemes under which residents can dispose waste electrical and electronic equipment at a recycling centre or other collection points, or WEEE will be collected directly from households. More detailed information is available from the technical administration of the relevant local authority.



## 3.5 Training

To read about infrared training, visit:

- <http://www.infraredtraining.com>
- <http://www.irtraining.com>
- <http://www.irtraining.eu>

## 3.6 Documentation updates

Our manuals are updated several times per year, and we also issue product-critical notifications of changes on a regular basis.

To access the latest manuals, translations of manuals, and notifications, go to the Download tab at:

<http://support.flir.com>

It only takes a few minutes to register online. In the download area you will also find the latest releases of manuals for our other products, as well as manuals for our historical and obsolete products.

## 3.7 Important note about this manual

FLIR Systems issues generic manuals that cover several cameras within a model line.

This means that this manual may contain descriptions and explanations that do not apply to your particular camera model.

## 3.8 Note about authoritative versions

The authoritative version of this publication is English. In the event of divergences due to translation errors, the English text has precedence.

Any late changes are first implemented in English.

**FLIR Thermography and Instruments Customer Support Center**

Get support for thermography, fire fighting and instruments products

Welcome to the FLIR Instruments Customer Support Center. This portal will help you to get the most out of your FLIR Instruments products. The portal gives you access to:

- Instruments Knowledgebase
- Ask our support team (requires registration)
- Software and documentation (requires registration)
- Instruments service contacts

Find Answers

Search in our FAQ to find answers.

Search by Keyword

[Search All Answers](#)

[See All Popular Answers](#)

**Register Your Products**

[Register](#)

You will gain access to special discounts and offers, downloads, and software upgrades.

[Register for free today](#)

**FLIR Benefits Program**

FLIR has decided to offer existing customers holding a valid license for certain software a free upgrade.

[Enter Now](#)

**Infrared Training Center**

Your premier educational and training resource for infrared camera use.

[Get training](#)

E-learning (English)

Get training in Europe, Middle East and Africa

E-learning (multiple languages)

**Click this link to find a manual for a current product.**

To find a datasheet for a current product, click on a picture.  
To find a datasheet for a legacy product, click here.

<a href="#">FLIR T5xx</a>	<a href="#">FLIR A310f</a>	<a href="#">FLIR A310pt</a>	<a href="#">FLIR A3xx</a>	<a href="#">FLIR A6xx</a>	<a href="#">FLIR Aerial</a>
<a href="#">FLIR AX</a>	<a href="#">FLIR AxS</a>	<a href="#">FLIR Cx</a>	<a href="#">FLIR ETS3xx</a>	<a href="#">FLIR Ex</a>	<a href="#">More...</a>
<a href="#">Product catalogs</a>	<a href="#">Software</a>	<a href="#">Accessories</a>	<a href="#">Training</a>		

Important legal disclaimer, dangers, warnings, and cautions

## 4.1 General

For customer help, visit:

<http://support.flir.com>

## 4.2 Submitting a question

To submit a question to the customer help team, you must be a registered user. It only takes a few minutes to register online. If you only want to search the knowledgebase for existing questions and answers, you do not need to be a registered user.

When you want to submit a question, make sure that you have the following information to hand:

- The camera model
- The camera serial number
- The communication protocol, or method, between the camera and your device (for example, SD card reader, HDMI, Ethernet, USB, or FireWire)
- Device type (PC/Mac/iPhone/iPad/Android device, etc.)
- Version of any programs from FLIR Systems
- Full name, publication number, and revision number of the manual




## 4.3 Downloads

On the customer help site you can also download the following, when applicable for the product:

- Firmware updates for your infrared camera.
- Program updates for your PC/Mac software.
- Freeware and evaluation versions of PC/Mac software.
- User documentation for current, obsolete, and historical products.
- Mechanical drawings (in \*.dxf and \*.pdf format).
- Cad data models (in \*.stp format).
- Application stories.
- Technical datasheets.
- Product catalogs.

## 5.1 Procedure

Follow this procedure:

1. Put a battery into the battery compartment.
2. Charge the battery for 4 hours before starting the camera for the first time.
3. Insert a memory card into the card slot.
4. Push the On/off button  to turn on the camera.
5. Aim the camera toward the object of interest.
6. Adjust the focus.

**Note** It is very important to adjust the focus correctly. Incorrect focus adjustment affects how the image modes work. It also affects the temperature measurement.

7. Push the Autofocus/save button fully down to save an image.
8. Go to <http://support.flir.com/tools> and download FLIR Tools.
9. Install FLIR Tools on your computer.
10. Start FLIR Tools.
11. Connect the camera to the computer using a USB cable.
12. Import the images into FLIR Tools.
13. Select one or more images.
14. Click *Generate report*.
15. Click *Export* to export the report as a PDF file.
16. Send the PDF report to your client.