

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



# Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







#### **Americas**

Atlanta - 678-957-9614 Boston - 774-760-0087 Chicago - 630-285-0071 Cleveland - 216-447-0464 Dallas - 972-818-7423 Detroit - 248-538-2250 Kokomo - 765-864-8360

Phoenix - 480-792-7200 Santa Clara - 408-961-6444 Toronto - 905-673-0699

#### Asia/Pacific

Australia - Sydney - 61-2-9868-6733 China - Beijing - 86-10-8528-2100 China - Chengdu - 86-28-8665-5511

China - Naniing- 86-25-8473-2460 China - Qinadao - 86-532-8502-7355 China - Shanghai - 86-21-5407-5533 Los Angeles - 949-462-9523 China - Shenvang - 86-24-2334-2829

China - Shenzhen - 86-755-8203-2660 China - Wuhan - 86-27-5980-5300 China - Xiamen - 86-592-2388138

China - Xian - 86-29-8833-7252 China - Zhuhai - 86-756-3210040 India - Bangalore - 91-80-3090-4444 India - New Delhi - 91-11-4160-8631

Japan - Yokohama - 81-45-471-6166 Korea - Daegu - 82-53-744-4301 Korea - Seoul - 82-2-554-7200

India - Pune - 91-20-2566-1512

Malaysia - Kuala Lumpur - 60-3-6201-9857 Malaysia - Penang - 60-4-227-8870

Philippines - Manila - 63-2-634-9065 Singapore - 65-6334-8870

Taiwan - Hsin Chu - 886-3-6578-300 Taiwan - Kaohsiung - 886-7-536-4818 Taiwan - Taipei - 886-2-2500-6610 Thailand - Bangkok - 66-2-694-1351

#### Europe

Austria - Weis - 43-7242-2244-39 Denmark - Copenhagen - 45-4450-2828 France - Paris - 33-1-69-53-63-20 China - Hong Kong SAR - 852-2401-1200 Germany - Munich - 49-89-627-144-0 Italy - Milan - 39-0331-742611 Netherlands - Drunen - 31-416-690399 Spain - Madrid - 34-91-708-08-90 UK - Wokingham - 44-118-921-5869

03/26/09



Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199 www.microchip.com

The Microchip name and logo, the Microchip logo and MPLAB are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. PICkit is a trademark of Microchip Technology Incorporated in the U.S.A. and other countries. All other trademarks mentioned herein are property of their respective companies. © 2009, Microchip Technology Incorporated, Printed in the U.S.A. All Rights Reserved. 7/09



## MRF24J40MA/MB PICtail™/PICtail Plus **Daughter Board**

#### Overview

The MRF24J40MA/MB PICtail TM/PICtail Plus Daughter Board is a demonstration and development daughter board for the following modules:

- MRF24J40MA IEEE 802.15.4 2.4 GHz RF Transceiver module (AC164134-1)
- MRF24J40MB 2.4 GHz IEEE 802.15.4 20 dBm RF Transceiver module (AC164134-2)

The daughter board can plug into multiple Microchip Technology demonstration and development boards. For example, the board is appropriate for 8-bit microcontroller development using the PIC18 Explorer Board (DM183032) or for 16-bit microcontroller development using the Explorer 16 Development Board (DM240001).

#### User's Guide

The MRF24J40MA/MB PICtail/PICtail Plus Daughter Board User's Guide (DS51867) is available for download at http://www.microchip.com/wireless. The User's Guide contains more detailed information on the features, operation, schematics and the PCB (Printed Circuit Board).

#### Software

Sample source code is available from the Microchip Wireless Design Environment: Microchip Wireless Media Access Controller (MiMAC) and Microchip Wireless Application Programming Interface (MiApp), as described in application notes AN1283 and AN1284, respectively. A Quick Start Guide is included in the software installation package that explains the installation and operation of the demonstration program. The Quick Start Guide is available for download from the Microchip web site http://www.microchip.com/wireless.

#### Operation

Programming and configuration options for the MRF24J40MA and MRF24J40MB transceiver modules are provided in the MRF24J40 IEEE 802.15.4 2.4 GHz RF Transceiver Data Sheet (DS39776).

Sample source code is the best place to start. Refer to the compile options when enabling the MRF24J40MA and MRF24J40MB transceiver modules.

#### **IMPORTANT**

The MRF24J40MB module contains a power amplifier (PA) and low noise amplifier (LNA). It is important that the MRF24J40 be configured to control the PA and LNA. Refer to Section 4.2 External PA/LNA Control in the MRF24J40 IEEE 802.15.4 2.4 GHz RF Transceiver Data Sheet (DS39776). When using the sample source code, refer to the compile options to enable the PA and LNA.

#### CAUTION

Voltage and current to the MRF24J40MA/MB PICtail/PICtail Plus Daughter Board should be in the range of 2.4-3.6V and capable of supplying 130 mA. Ensure that the daughter board is plugged into a development/demonstration board that meets this power requirement; otherwise, damage to the MRF24J40 may occur.

### **Jumper Configuration**

Power Disconnect/Current Measure Jumpers (JP1/JP2) - Two, 2-pin headers are connected in parallel. A shunt connects power to the MRF24J40 module. A current meter can be placed on the header and the shunt removed to measure current consumption.

TIP: To prevent power interruption to the MRF24J40 module, keep the shunt on the header while connecting the current meter. Once connected, remove the shunt to measure current. INT2 Jumper (JP3) - For the PIC18 Explorer Board, jumpering JP3 with a shunt allows the connection of RA5 to RB2/INT2 and enables push-button switch S2 to trigger an interrupt.