

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







Americas

Atlanta - 678-957-9614 Boston - 774-760-0087 Chicago - 630-285-0071 Cleveland - 216-447-0464 Dallas - 972-818-7423 Detroit - 248-538-2250 Indianapolis - 317-773-8323 Los Angeles - 949-462-9523 Phoenix - 480-792-7200 Santa Clara - 408-961-6444 Toronto - 905-673-0699

Europe

Austria - Wels - 43-7242-2244-39 Denmark - Copenhagen - 45-4450-2828 France - Paris - 33-1-69-53-63-20 Germany - Munich - 49-89-627-144-0 Italy - Milan - 39-0331-742611 Netherlands - Drunen - 31-416-690399 Spain - Madrid - 34-91-708-08-90 UK - Wokingham - 44-118-921-5869

Asia/Pacific

Australia - Sydney - 61-2-9868-6733 China - Beijing - 86-10-8569-2100 China - Chengdu - 86-28-8665-5511 China - Chongqing - 86-23-8980-9588

Asia/Pacific (Continued)

China - Hangzhou - 86-571-2819-3187 China - Hong Kong SAR - 852-2401-1200 China - Nanjing- 86-25-8473-2460 China - Qingdao - 86-532-8502-7355 China - Shanghai - 86-21-5407-5533 China - Shenyang - 86-24-2334-2829 China - Shenzhen - 86-755-8203-2660 China - Wuhan - 86-27-5980-5300 China - Xiamen - 86-592-2388138 China - Xian - 86-29-8833-7252 China - Zhuhai - 86-756-3210040 India - Bangalore - 91-80-3090-4444 India - New Delhi - 91-11-4160-8631 India - Pune - 91-20-2566-1512 Japan - Osaka - 81-66-152-7160 Japan - Yokohama - 81-45-471-6166 Korea - Daegu - 82-53-744-4301 Korea - Seoul - 82-2-554-7200 Malaysia - Kuala Lumpur - 60-3-6201-9857 Malaysia - Penang - 60-4-227-8870 Philippines - Manila - 63-2-634-9065 Singapore - 65-6334-8870

Taiwan - Kaohsiung - 886-7-536-4818 Taiwan - Taipei - 886-2-2500-6610 Thailand - Bangkok - 66-2-694-1351

Taiwan - Hsin Chu - 886-3-5778-366





Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199

www.microchip.com

The Microchip name and logo, the Microchip logo, and MPLAB are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. All other trademarks mentioned herein are property of their respective companies. © 2012, Microchip Technology Incorporated, Printed in the U.S.A. All Rights Reserved. 11/11

DS52091A

VGA Camera Sensor PICtail™ Plus Daughter Board Information Sheet

Thank you for purchasing a VGA Camera Sensor PICtail Plus Daughter Board. This information sheet provides some important details that will help you successfully use the board as quickly as possible.

Additional information can be accessed at: http://www.microchip.com

Basic Requirements

The VGA Camera Sensor PICtail Plus Daughter Board was designed to work with a PICtail™ Plus connector. This connector can be found on many boards including the Explorer 16 Development Board (DM240001) and the Starter Kit I/O Expansion Board (DM320002).

The VGA Camera Sensor PICtail Plus Daughter Board uses an OmniVision Technologies CameraCubeChip™ to receive digital video images. These images are then controlled by the microcontroller via I/O ports. Depending on the desired use, there are eight DATAx jumpers on the daughter board that can be used to switch between I/O lines. There is another jumper (J10) that can be used to switch between using an external clock source or the microcontroller as a clock source for the OmniVision Technologies CameraCubeChip™.

Getting Started

To get started with the VGA Camera Sensor PICtail Plus Daughter Board, follow these steps:

- 1. Ensure that MPLAB® IDE is installed.
- 2. Download a project file for the daughter board from the Microchip web site.
- 3. Power the daughter board.
- 4. Connect a debugger/programmer.
- 5. Using MPLAB IDE, open the project that was previously downloaded.
- 6. Select a debugger/programmer in MPLAB IDE.
- 7. Click **Build**. This builds the downloaded project.
- 8. Click Program all memories.
- 9. Click Run.

Your VGA Camera Sensor PICtail Plus Daughter Board should now be up and running. To begin viewing the camera sensor image, either online or on an LCD, follow the guide that accompanies the chosen demonstration.

