



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





ASSET IDENTIFICATION KIT

AT24RF08-EK Quick Start

Kit Contents

Atmel Asset Identification Kit CD-ROM
4 RFID Tags
1 Reader with Serial Port Cable
1 9V Power Supply

Minimum System Requirements

Windows®
- 386, 486, or Pentium® processor-based computer
- Microsoft Windows 3.1, 95 or 98, or Windows NT® 3.5 or later
- 4M bytes of RAM
- CD-ROM Drive

CD-ROM Contents

Quick Start.doc (Evaluation Kit)
Evaluation Kit Manuals (Commands and Theory of Operation)
Application Notes (U2270B Antenna Design Hints)
IBM® Asset ID™ Specs
Datasheets (AT88RF08C, AT90S8515, U2270B)
Gerber Files (for reader/writer)
Schematic (ATMEL SCH REV G)
Source Files (for reader/writer)
IBM® Asset ID™ Videos

INSTRUCTIONS:

1. **Connect the power supply to the reader and plug it in (see Note1).**
2. **Connect data cable to PC serial port (either COM1 or COM2).**
3. **Start Windows HyperTerminal In Windows 95 or 98, click on START – Programs – Accessories – Communications – HyperTerminal.**
4. **Double-click on HyperTerminal.**

Choose a connection name and icon.

In the "Connect To" window, select "Direct to COM N ", where N is the number of the serial port used.

For the port settings, enter 9600 bps, 8 bit data, no parity, 1 stop bit, no flow control.

5. **To verify that a connection is established with the demo board, type dv and then <ENTER>.**

The screen should read:

AT24RF08-EK Rev. 1.15

Copyright 1999 Atmel Corp.

6. **With a tag in reading range (see Note 2), type WI Name, where Name is a string of 12 characters or less and then press <ENTER>.**

The chip should respond with: **Write Successful.**

7. **With the tag still in range (see Note 2), type AR and then <ENTER>. The chip should respond with the character string.**

Note 1: The power supply included in the kit is for US 120V only. Outside the US, AC power may have to be converted. Alternate DC power may be used (9V, 200mA DC Power Supply, center positive).

Note 2: This demonstration has been optimized for an operating distance from 0.5 to 1 inch. Being too far from the reader will put the tag out of range. Being too close to the reader will activate a protection circuit that may make data transmission unreliable. In actual applications, the range may be optimized for any desired read/write distance.

Have fun!