mail

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





DEMO MANUAL DC1871A

LTC2995 Temperature Sensor and Dual Voltage Monitor with Alert Outputs

DESCRIPTION

Demonstration circuit 1871A features the LTC2995, a high performance temperature and voltage monitor that has resistor configurable alert levels.

DC1871A is designed to allow easy evaluation of the LTC2995 and may be connected directly to the target appli-

cation's analog and digital signals to measure performance.

Design files for this circuit board are available at http://www.linear.com/demo

∠7, LT, LTC, LTM, µModule, Linear Technology and the Linear logo are registered trademarks of Linear Technology Corporation. All other trademarks are the property of their respective owners.



Figure 1. Proper Measurement Equipment Setup



QUICK START PROCEDURE

Jumper Settings

DS: This jumper allows the user to set the LTC2995 to use the internal temp sensor, an external temp sensor, or alternate between the two choices. When set to INT&EXT, VPTAT changes every 3.5ms from the voltage corresponding to the temperature of the internal sensor to the voltage corresponding to the temperature of the external temperature.

PS: This jumper selects the polarity of the VT1/VT2 pins. Depending on the position of this jumper, the VT1 and VT2 pins can either be used to indicate OT or UT.

PS	VT1	VT2
V _{CC}	UT	OT
Open	OT	OT
GND	UT	UT

DIODE SELECT: Allows the user to either select the on board FMMT3904 (Q1) or attach their own diode through the D+/D- turrets.

LED ON/OFF: Turns on or off the digital indicator lights that reflect the status of $\overline{\text{OV}}$, $\overline{\text{UV}}$, TO2, TO1.

Analog Connections

Analog signal connections are made via the row of turret posts along the edge of the board.

GND: (6 turrets)These turrets are connected directly to the internal ground planes.

 $V_{\mbox{CC}}$: User should connect a 2.25V to 5.5V power supply to this turret.

 V_{IN1} : This is set up to be a 5V ±10% monitor input. This, however, can be adjusted by changing the VH1/VL1 resistors (RA1, RB1, RC1). Please refer to the LTC2995 manual for resistor value formulas.

 V_{IN2} : This is setup to be a 12V ±10% monitor input. This, however, can be adjusted by changing the VH2/VL2 resistors (RA2, RB2, RC2). Please refer to the LTC2995 manual for resistor value formulas.

 V_{REF} : OUTPUT ONLY. This nominally outputs 1.8V that can drive up to $\pm 200 \mu A$ of load.

VPTAT: The voltage on this turret is proportional to the sensor's absolute temperature, with a slope of 4mV/k. VPTAT can drive up to a $\pm 200\mu$ A load and up to 1000pF capacitive load.



dc1871af

QUICK START PROCEDURE

Digital Connections

 $\overline{\text{UV}}$: Status of the LTC2995 $\overline{\text{UV}}$ pin can be read at this turret. If a UV fault is triggered the LED will also light up.

 \overline{OV} : Status of the LTC2995 \overline{OV} pin can be read at this turret. If a OV fault is triggered the LED will also light up.

TO2: Status of the LTC2995 TO2 pin can be read at this turret. If a TO2 fault is triggered the LED will also light up. The function of the TO2 fault is determined by the PS jumper and the state of the VT2 pin.

TO1: Status of the LTC2995 TO1 pin can be read at this turret. If a TO1 fault is triggered the LED will also light up. The function of the TO1 fault is determined by the PS jumper and the state of the VT1 pin.



DEMO MANUAL DC1871A

PARTS LIST

ITEM	QTY	REFERENCE	PART DESCRIPTION	MANUFACTURER/PART NUMBER	
Required Circuit Components					
1	1	C1	CAP., COG 470pF 50V 5% 0603	AVX, 06035A471JAT2A	
2	1	C2	CAP., X7R 0.1µF 16V 10% 0402	AVX, 0402YC104KAT2A	
3	1	C3	CAP., X7R 22nF 50V 5% 0402	AVX, 04025C222JAT2A	
4	17	E1-E17	TESTPOINT, TURRET .094"	MILL-MAX, 2501-2-00-80-00-00-07-0	
5	2	JP1, JP2	HEADER, 3 PIN 0.079 SINGLE ROW	SAMTEC, TMM-103-02-L-S	
6	2	JP3, JP4	HEADER, 12 PIN 0.079 DOUBLE ROW	SAMTEC, TMM-106-02-L-D	
7	4	LED1, LED2, LED3, LED4	LED, RED J-TYPE SMD 1206	PANASONIC, LN1251CTR	
8	1	LED5	LED, GRN, J-TYPE	PANASONIC, LN1351CTR	
9	1	Q1	TRANS., NPN, SOT23-3	DIODE/ZETEX, MMBT3904-7-F	
10	2	RA1, RA2	RES., CHIP, 4.53k, 1/16W, 1%, 1206	YAGEO, RC1206FR-074K53L	
11	2	RB1, RB2	RES., CHIP, 1k, 1/16W, 5%, 1206	YAGEO, RC1206JR-071KL	
12	1	RC1	RES., CHIP, 44.2k, 1/16W, 1%, 1206	YAGEO, RC1206FR-0744K2L	
13	1	RC2	RES., CHIP, 115k, 1/16W, 1%, 1206	YAGEO, RC1206FR-07115KL	
14	1	RTA	RES., CHIP, 110k, 1/16W, 5%, 1206	YAGEO, RC1206JR-07110KL	
15	1	RTB	RES., CHIP, 40.2k, 1/16W, 1%, 1206	YAGEO, RC1206FR-0740K2L	
16	1	RTC	RES., CHIP, 30.9k, 1/16W, 1%, 1206	YAGEO, RC1206FR-0730K9L	
17	5	R1, R2, R3, R4, R5	RES., CHIP, 330Ω, 1/16W, 1%, 0603	YAGEO, RC0603FR-07330RL	
18	4	R6, R7, R8, R9	RES., CHIP, 10k, 1/16W, 5%, 0603	YAGEO, RC0603JR-0710KL	
19	0	R10	RES., CHIP, 0402	OPT	
20	1	U1	I.C., LTC2995IUD, QFN20UD-3X3	LINEAR TECH., LTC2995IUD#TRPBF	
21	4		SHUNT, .079" CENTER	SAMTEC, 2SN-BK-G	
22	1	SHOWN ON ASSY DWG	FAB, PRINTED CIRCUIT BOARD	DEMO CIRCUIT 1871A	
23	2	STENCIL BOTH SIDES	STENCIL (TOP & BOTTOM)	STENCIL DC1871A	







(Л



DEMO MANUAL DC1871A

DEMO MANUAL DC1871A

DEMONSTRATION BOARD IMPORTANT NOTICE

Linear Technology Corporation (LTC) provides the enclosed product(s) under the following AS IS conditions:

This demonstration board (DEMO BOARD) kit being sold or provided by Linear Technology is intended for use for **ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY** and is not provided by LTC for commercial use. As such, the DEMO BOARD herein may not be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including but not limited to product safety measures typically found in finished commercial goods. As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may or may not meet the technical requirements of the directive, or other regulations.

If this evaluation kit does not meet the specifications recited in the DEMO BOARD manual the kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY THE SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THIS INDEMNITY, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user releases LTC from all claims arising from the handling or use of the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge. Also be aware that the products herein may not be regulatory compliant or agency certified (FCC, UL, CE, etc.).

No License is granted under any patent right or other intellectual property whatsoever. LTC assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or any other intellectual property rights of any kind.

LTC currently services a variety of customers for products around the world, and therefore this transaction is not exclusive.

Please read the DEMO BOARD manual prior to handling the product. Persons handling this product must have electronics training and observe good laboratory practice standards. **Common sense is encouraged**.

This notice contains important safety information about temperatures and voltages. For further safety concerns, please contact a LTC application engineer.

Mailing Address:

Linear Technology 1630 McCarthy Blvd. Milpitas, CA 95035

Copyright © 2004, Linear Technology Corporation

dc1871at

6