# imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



LTC1408

### DESCRIPTION

Demonstration circuit 887 features the LTC1408 6channel, 14-Bit, simultaneous sampling ADC. Total throughput is 600KSPS; 100KSPS per channel, with a typical channel-to-channel aperture skew of 200ps. The board is designed to be used with the DC890B Fast DAACS data collection board to show the AC performance of the LTC1408. Alternatively, the board can be directly connected to an application to evaluate the ADC's performance.

# Design files for this circuit board are available. Call the LTC factory.

LTC is a trademark of Linear Technology Corporation

### **QUICK START PROCEDURE**

#### **BASIC CONNECTIONS**

Connect DC887 to a DC890B USB High Speed Data Collection Board using connector J2. Connect DC890B to a host PC with a standard USB A/B cable. Apply 5-7V DC to the VIN and GND terminals. Apply a 10MHz 3.3Vp-p sine wave or square wave to connector J3. Note that J3 has a 50 Ohms termination resistor to ground. CH0-CH5 are provided through connector J1 (See schematic for details.). Run the QuickEval II (Pscope.exe) evaluation software supplied with DC890 or download it from www.linear.com/software.





Figure 1. CONNECTION DIAGRAM

#### Figure 2. SOFTWARE SCREENSHOT



#### Figure 3. CONFIGURE MENUS

Configure Help AutoDetect Device Use Internal Generator Device... Signal Generator...

Switch Colors

Device Selection		
Detected	DC887A	Select
Selected	User Configure	~
Bits	14	6 🔽 Channs
Alignment	14	🔲 Bipolar
FPGA	Serial 1408 Class 🛛 🔽	Positive-Edge Clk
Jumper Options		
	Cancel	ОК

### SOFTWARE CONFIGURATION

#### **CONFIGURE DEVICE**

The Pscope software should automatically configure itself after detecting the demo board. To change from Bipolar to Unipolar mode it will be necessary to manually configure the software. In the CONFIGURE menu (See Figure 3) select Device, which will bring up another window. In this window, select User Configure and adjust the other settings as follows:

Bits: 14

Alignment: 14

Bipolar: Checked if BIP jumper is set high, Un-Checked if BIP jumper is set to low. (Default is checked)

Channels: 6

Positive Edge Clk: UN-Checked

FPGA: Serial 1408 Class.

#### **CONFIGURE SOFTWARE SCREEN**

The software interface is highly configurable and displays any combination of time domain data, frequency domain data, primitive wave and performance parameters (SNR, THD, SINAD, etc.). The screen can be broken into multiple panes as shown in Figure 2. Complete documentation on configuring PSCOPE can be found in the help file.

Click the COLLECT button to begin acquiring data.

Complete software documentation is available from the Help menu item, as features may be added periodically.

### HARDWARE SET-UP

#### JUMPERS

**JP1, JP2** - Select number of channels to convert and Unipolar / Bipolar selection. NCH2, NCH1, NCH0 are set to 111 which selects all six channels. These switches should be left in this position when running Pscope software. UNI/BIP selection applies to all channels. Refer to Figure 4.

**JP3** – Enable Oscillator and Oscillator Division. Presently not used. This may be used in the future as serial clock, to allow a convert signal at 1X the conversion rate.

**JP4** – Digital Interface Header. Provides direct connection to the LTC1408 CONV, SDO, and SCK pins. This can be used to either monitor signals with a logic analyzer or to drive the LTC1408 directly from the customer's test equipment or prototype circuitry. DC890B should be disconnected before driving the LTC1408 externally with JP4. Note that R34 should be removed if the CONV signal is being driven externally.

**JP5** – Currently not used

#### SIGNAL CONNECTIONS

**J1** – 40 pin connector with CH0-CH5 differential inputs, multiple grounds, a mid-supply bias voltage and Vref. Refer to schematic for pin out. The mid-supply bias voltage can be used to bias the minus ADC inputs for bipolar conversions.

**J2** – Data connections to DC890B collection board.

**J3** – Conversion Clock Input. This input has a 50 ohm termination resistor, and is intended to be driven by a 3.3Vpp sine or square wave. This clock is divided by 98 in the DC890B collection board to control the serial interface and convert pulse. To run the LTC1408 at maximum conversion rate, apply a 10MHz signal to this input.


#### **GROUNDING AND POWER CONNECTION**

Connect a 5V to 7V power supply to the Vin and GND turret posts. For optimum performance, this supply should be floating with respect to any signal generators connected to the analog inputs.



Figure 4 – JP1, JP2 CONFIGURATION

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 887 14-BIT, 6-CHANNEL, 600KSPS SIMULTANEOUS ADC



6

