

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China









RLY-8-RS485 8 Relay Controller SKU:DFR0290



Contents

- 1 Introduction
- 2 Specification
- 3 Tutorial
 - 3.1 Requirements
 - 3.2 Connection Diagram
 - 3.3 PC Control of POE Relay
 - 3.3.1 Open the Software
 - 3.3.2 Select the network, and then select the network Control button, enter the network control interface
 - 3.3.3 Network Control of POE Relay
 - 3.3.4 Control the POE relay with RS485 BUS
 - 3.3.5 Reset and Restore Factory Settings
 - 3.4 Control

Introduction

The RLY-8 is a network relay controller with open source communication protocol. It integrates 8 channel relays and each relay could stand 277VAC-10A or 125VAC-12A power. Meanwhile most of the household appliances are under 250VAC, it means you could use it almost everywhere. The RLY-8 is using STM32 microcontroller. It supports 2 types of power supply: Wall adapter or PoE (Power over Ethernet) power supply. You could reduce its connection cable via PoE power supply. In addition, you also could control it via RS485 port or TCP/IP protocol. And RS485 and JSON protocol has been opened on the website.

This Ethernet relays are really great for IoT projects - with 8 relays, you have plenty of scope to try different things. Like a remote control light, a autoflowering greenhouse. With the open source protocol, you could add it in plenty of things you can do with this besides, just use your imagination!

Specification

Operating Voltage: DC:7-23V

• Relay number: 8

Data Communication: Ethernet/RS485

Network Configuration: Supports DHCP and Static IP

Power Consumption: Max 3.5W

Maximum Control: 277VAC-10A/125VAC-12A

Control Mode: Ethernet/RS485

• Factory Settings: IP: 192.168.1.10 (port: 2000)

Working Temperature: -30~85°C

Weight: 530g

• Size: 145mm * 90mm * 40mm (5.7in * 3.5in * 1.6in)

Tutorial

Requirements

Hardware

POE relay x1 PC X1 USB to RS485 transfer line or ethernet cable POE Ethernet switch or ordinary Ethernet switch


Software


PC Software (Windows) Click to Download

Connection Diagram

RLY-8-PoE-RS485 supports 2 types of control mode: **Ethernet** and **RS485** In this section, we will introduce some typical connection:

Ethernet






NOTE: If you directly connect to the computer, you will need to set a static IP. Going by RLY factory settings, you can set your computer IP to 192.168.1.x(x is 0~254 except 10), Subnetmask 255.255.255.0, gateway 192.168.1.1

RS485 BUS




PC Control of POE Relay

Open the Software




Select the network, and then select the network Control button, enter the network control interface




NOTE: It may take some time when the RLY-8 has just been powered on, please be patient waiting for the network list


Network Control of POE Relay



NOTE: It is recommended to click the "Get Status" button to get the current state when you want to control the relay.

Control the POE relay with RS485 BUS





Reset and Restore Factory Settings

To reset the factory default settings, hold the reset button until the lights begin to flash.



Control





For any questions/advice/cool ideas to share, please visit **DFRobot Forum**.