imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





Bluno Beetle SKU:DFR0339



Contents

- 1 Introduction
- 2 Specification
- 3 Pinout Diagram
- 4 Power Supply
- 5 Bluno Beetle Basic Demo
- 6 Wireless Programming via BLE
- 7 Configure the BLE through AT command
- 8 Update BLE Firmware
- 9 ICSP interface

Introduction

Bluno Beetle is another milestone in wearable electronics device area, which makes DIY users have more options in the project design. It is fully compatible with Bluno in instructions and procedures, supporting Bluetooth HID and ibeacon modes.

And it not only supports USB programming, but also wireless programming method. With the V shaped gilded I/O interface, it is convenient to screw conductor wire on it, which could a good choice in the wearable market.

More instruction about Bluno Beetle can refer to DFRobot Bluno。

| Specification Bluetooth Chip | CC2540 | |
|---------------------------------|--------------------|--|
| Sensitivity | (-93dBm) | |
| Working Temperature : | (-10 °C ~ +85 °C) | |
| Maximun Distance | 50m(Open field) | |
| Microcontroller: | ATmega328P | |
| Clock frequency: | 16 MHz | |
| Working voltage: | 5V DC | |
| Digital Pin | x4 | |
| Analog Pin | x4 | |
| PWM Output | x2 | |
| UART interface | x1 | |
| I2C interface | x1 | |
| Micro USB interface | x1 | |
| Power port | x2 | |

Pinout Diagram



• Pin Mapping

| Silkscreen | Digital Pin | PWM Channel | Analog Channel | UART | I2C |
|------------|-------------|-------------|----------------|---------|-----|
| RX | 0 | | | | |
| ТХ | 1 | | | Serial1 | |
| SDA | A4 | | | | SDA |
| SCL | A5 | | | | SCL |
| D2 | 2 | | | | |
| D3 | 3 | 3 | | | |
| D4 | 4 | | | | |
| D5 | 5 | 5 | | | |
| A0 | A0 | | A0 | | |
| A1 | A1 | | A1 | | |
| A2 | A2 | | A2 | | |
| A3 | A3 | | A3 | | |

• Power interface description :

| Silkscreen | Description |
|------------|--------------------------|
| VIN | external power supply<8V |
| 5V | 5V positive supply |
| GND | GND |

Power Supply

- USB cable or external power supply: 5V
- External power supply <8V

Bluno Beetle Basic Demo

In this section, you can use the BLUNO Beetle to connect with the Android phone or iPhone .The Step by Step tutorial of the BLUNO Beetle is almost the same with the Bluno.

Wireless Programming via BLE

In this section, we will learn how to Upload the sketch on air via BLE. It is really amazing that you can do uploading process without a line. The Step by Step tutorial of

the Bluno Beetle is almost the same with the Bluno.

Configure the BLE through AT command

There are three revolutionary BLE firmware versions now, maybe it will be more. For the reason of unified management, we will put all BLE AT command on the BLUNO wiki page Configure the BLE through AT command.

Update BLE Firmware

It is better to update the newest firmware for the better experience. As Bluno Beetle is using CC2540 chip, the method of the updating is very close to BLUNO. Please choose "Bluno" firmware. Or it won't work.

ICSP interface



- ICSP1: Atmega 328P
- ICSP2: CC2540