



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China




2111 Comprehensive Drive
Aurora, Illinois 60505
Phone: 630-851-4722
Fax: 630-851-5040
www.conwin.com

Q
U
I
C
K

S
T
A
R
T

G
U
I
D
E



General Instructions

1. Insert the unit into the eval board socket
 - Pin 1 of the socket is indicated by the "1" on the board silk-screen on the lower left.
 - Press the unit down firmly
2. Connect power
 - Connect the Vcc banana plug on the right to a +3.3V power supply capable of ~ 800mA of current.
3. Connect output:
 - Connect the "CMOS OUT" BNC J6 on the upper right to an oscilloscope or frequency counter input. Use a high impedance probe if possible.
4. Connect voltage control:
 - For DOC-series parts with voltage control (VCOCXO) option, connect "CV Input" BNC J5 on the upper left to a 1.65Vdc supply.

