



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



# Fluke 1621

## Basic Earth Ground Tester

## Technical Data



The Fluke 1621 is an easy-to-use earth ground tester. The first line of defense in detecting reliable ground connections, the unit features basic ground testing methods including 3-pole Fall-of-Potential as well as 2-pole ground resistance. Its convenient size, rugged holster, and large, clear LCD display make it an ideal field earth tester, for most work environments. With a simple user interface and intuitive functionality, the Fluke 1621 is a handy tool for electrical contractors, utility test engineers, and earth ground specialists.

- 3-pole Fall-of-Potential earth testing for basic measurements
- 2-pole resistance measurements for added versatility
- Easily capture values with single-button operation
- Ensure accurate measurements with automatic 'noise' voltage detection
- Hazardous voltage warning offers increased user protection
- Clearly read and record data with a large, backlit display
- Rugged holster and design for tough work environments
- Portable size allows for easy transportation
- Instantly be alerted to measurements outside of your set limit, when you use the adjustable limit setting

### General specifications

<b>Measuring functions</b>	3-pole earth ground resistance, 2 pole ac resistance of a conductor, Interference voltage
<b>Intrinsic error</b>	Refers to the reference temperature range and is guaranteed for one year
<b>Measuring rate</b>	2 measurements/second
<b>Battery</b>	One 9 volt alkaline (LR61)
<b>Battery condition</b>	LO-BAT is displayed if voltage drops below 6.5 V
<b>Voltages</b>	Between jacks H/C2 and E/C1: 250 Veff maximum (effective voltage) Between jacks S/P2 and E/C1: 250 Veff maximum
<b>Climatic class</b>	VDE/VDI 3540 RZ (conforming to KWG as per DIN 40040, 4/87)
<b>Temperature performance</b>	Working: -10 °C to +50 °C (+14 °F to +122 °F) Operating: 0 °C to +35 °C (+32 °F to +95 °F) Storage: -20 °C to +60 °C (+68 °F to +140 °F) Reference: +23 °C ± 2 °C (+73 °F ± 4 °F)

**Note:** If the tester is not going to be used, or is being stored for a long period, remove the battery and store separately from the tester to avoid damage from battery leakage.

**Note:** The four temperature ranges for the tester exists to satisfy European Standards requirements; the instrument can be used over the full working temperature range by using the temperature coefficient to calculate accuracy at the ambient temperature of use.

## General specifications cont.

<b>Temperature coefficient</b>	± 0.1 % of range per degree Kelvin
<b>Safety</b>	IEC/EN 61010-1, 600 V CAT II, pollution degree 2
<b>Dimensions</b>	113 mm x 54 mm x 216 mm (4.5 in x 2.1 in x 8.5 in.), including holster
<b>Weight</b>	850 g (1.9 lb), including standard accessories, volume approximately 600 cm <sup>3</sup>

## Electrical specifications

### Maximum deviations

Parameter	Influence factor	Deviation influence
E <sub>1</sub>	Position	0 %
E <sub>2</sub>	Supply voltage	0 %
E <sub>3</sub>	Temperature E <sub>3</sub>	2.3 %
E <sub>4</sub>	Serial interference voltage (20 V)	0.6 %
E <sub>5</sub>	Probe- and auxiliary probe resistance	10 %

<b>Test voltage</b>	3.7 kV
<b>Protection type</b>	IP 40; IEC/EN 60529
<b>Electromagnetic compatibility</b>	Emission: IEC/EN 61326 Class B
	Immunity: IEC/EN 61326 Annex C

### R<sub>E</sub> resistance measurement

<b>Measuring method</b>	Current-voltage measurement with improved cross-talk attenuation, no compensation of measuring lead resistance, with probe (3-pole) or without probe (2-pole), as per IEC/EN 61557-5
<b>Open circuit voltage</b>	23 to 24 V ac
<b>Short circuit current</b>	> 50 mA ac
<b>Measuring frequency</b>	128 Hz
<b>Maximum permissible overload</b>	250 V <sub>eff</sub>

Measuring range	Resolution	Display range	Intrinsic uncertainty	Operating uncertainty IEC 61557 <sup>[1]</sup>
0.15 Ω to 20 Ω	0.01 Ω	0 to 19.99 Ω	± (6 % of measured value + 5D)	± (18 % of measured value + 5D)
200 Ω	0.1 Ω	20 to 199.9 Ω		
2 kΩ	1 Ω	200 to 1999 Ω		

#### Notes:

[1] Covers all deviations caused by influence quantities E<sub>1</sub>-E<sub>5</sub>.

If the deviation E<sub>4</sub> caused by high probe or auxiliary probe resistance is higher than specified  $\Delta$  flashes. Measured values are outside of the specified operating uncertainty.

<b>Measuring time</b>	8 seconds (average from when START is pressed)
<b>Limit input</b>	Tester retains set value even if instrument is turned off (assuming battery power supply is sufficient)

**Note:** If tester detects stray interference voltage ≥ 20 V, Ω is displayed and the measurement is not started.

### Automatic changeover of resolution

R <sub>H</sub>	Resolution
< 7 kΩ	0.01 Ω
< 50 kΩ	0.1 Ω
> 50 kΩ	1 Ω

### Interference voltage display dc + ac

<b>V<sub>max</sub></b>	30 V <sub>eff</sub>
<b>Common mode rejection</b>	> 80 dB at 50 Hz and 60 Hz
<b>R<sub>i</sub></b>	680 kΩ
<b>Measuring uncertainty</b>	< 10 % for pure ac and dc signals

## Ordering information

Fluke-1621 Earth Ground Tester

#### Includes:

- Users manual
- Two measuring leads with alligator clips, 2 m (6 ft)
- One battery, 9 V alkaline (LR61)
- One protective holster, yellow
- One CD-ROM

#### Optional accessories

- Cable-Reel 50 m Ground/Earth Cable Reel 50 M Wire (162.5 ft)
- Cable-Reel 25 m Ground/Earth Cable Reel 25 M Wire (81.25 ft)
- Earth Stake Ground/Earth Stake
- ES-162P3 Stake Set for 3-Pole Measurement (includes three stakes, one 50 M cable reel, and one 25 M cable reel)

**Fluke.** Keeping your world up and running.®

#### Fluke Corporation

PO Box 9090, Everett, WA USA 98206

#### Fluke Europe B.V.

PO Box 1186, 5602 BD Eindhoven, The Netherlands

#### For more information call:

In the U.S.A. (800) 443-5853 or Fax (425) 446-5116

In Europe/M-East/Africa +31 (0) 40 2675 200 or Fax +31 (0) 40 2675 222

In Canada (800)-36-FLUKE or Fax (905) 890-6866

From other countries +1 (425) 446-5500 or Fax +1 (425) 446-5116

Web access: <http://www.fluke.com>

©2007 Fluke Corporation. All rights reserved. Specifications subject to change without notice. Printed in U.S.A. 6/2007 3057417 D-EN-N Rev A