



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





Quick Reference

FRDM-STBC-AGM04

Sensor Toolbox Development Platform for
MMA8652FC 3-axis digital accelerometer,
FXAS21002C 3-axis digital angular rate gyroscope, and
MAG3110 3-axis digital magnetometer

SENSOR TOOLBOX SHIELD DEVELOPMENT BOARD




Quick Reference

GET TO KNOW THE FRDM-STBC-AGM04

MMA8652FC 3-axis, 12-bit,
digital accelerometer
10-pin DFN (2 mm x 2 mm x 1 mm)

MAG3110 3-axis, digital magnetometer
10 DFN (2 mm x 2 mm x 0.85 mm)



FXAS21002C 3-axis digital angular rate gyroscope
24 QFN (4 mm x 4 mm x 1 mm)

Figure 1: FRDM-STBC-AGM04

HOW TO GET STARTED

1. Connect the FRDM-STBC-AGM04 development board to an NXP Freedom development board, such as the FRDM-K64F (or any Arduino R3 compatible board). Refer to the NXP Freedom development board Quick Start Guide for driver information. The latest drivers for the FRDM boards can be found at:

www.nxp.com/openSDA

2. Plug one end of a USB cable into the SDA port on the assembly. Plug the other end of the cable into the USB port on the computer.

3. Download and install the latest Sensor Toolbox software at:

www.nxp.com/sensortoolbox




Figure 2: Connect board to computer

www.nxp.com

NXP and the NXP logo are trademarks of NXP B.V. All other product or service names are the property of their respective owners. © 2016 NXP B.V.

Document Number: FRDM-STBC-AGM04 REV 0
Agile Number: 920-29415 REV A

